

Table of Contents

| | |
|--|------------|
| Chapter 1 Product Overview | 1-1 |
| 1.1 Introduction | 1-1 |
| 1.2 S5624P/S5624P-PWR/S5624F Ethernet Switch..... | 1-3 |
| 1.2.1 Front Panel..... | 1-3 |
| 1.2.2 Rear Panel | 1-12 |
| 1.2.3 Expansion Module..... | 1-13 |
| 1.3 S5648P/S5648P-PWR Ethernet Switch | 1-17 |
| 1.3.1 Front Panel..... | 1-17 |
| 1.3.2 Rear panel..... | 1-18 |
| 1.3.3 Expansion Module..... | 1-19 |
| 1.4 S5600 Series Technical Specifications | 1-22 |
| Chapter 2 Preparing for Installation | 2-1 |
| 2.1 Safety Precautions..... | 2-1 |
| 2.2 Installation Site..... | 2-1 |
| 2.2.1 Temperature/Humidity..... | 2-1 |
| 2.2.2 Cleanness | 2-2 |
| 2.2.3 Electromagnetic Susceptibility | 2-2 |
| 2.2.4 Laser Safety | 2-3 |
| 2.3 Installation Tools..... | 2-3 |
| Chapter 3 Installing the Switch | 3-1 |
| 3.1 Mounting the Switch in a Rack or on a Tabletop | 3-1 |
| 3.1.1 Rack-Mounting the Switch | 3-1 |
| 3.1.2 Mounting the Switch on a Tabletop/Workbench | 3-3 |
| 3.2 Installing/Removing the Power Module | 3-4 |
| 3.2.1 Installing the Power Module..... | 3-4 |
| 3.2.2 Removing the Power Module..... | 3-4 |
| 3.3 Connecting the Power Cord and the Ground Wire..... | 3-5 |
| 3.3.1 Connecting the AC-Input Power Cord..... | 3-5 |
| 3.3.2 Connecting the DC-Input Power Cord | 3-6 |
| 3.3.3 Connecting the Ground Wire..... | 3-7 |
| 3.4 Connecting the Switch to a Console Terminal..... | 3-9 |
| 3.4.1 Console Cable..... | 3-9 |
| 3.4.2 Connecting the Console Cable | 3-10 |
| 3.5 Installing/Removing the Stack Cable..... | 3-11 |
| 3.5.1 Stack Cable | 3-11 |
| 3.5.2 Installing the Stack Cable..... | 3-11 |
| 3.5.3 Removing the Stack Cable..... | 3-11 |

| | |
|---|------------|
| 3.6 Installing/Removing the Optional Interface Module | 3-12 |
| 3.7 Verifying Installation..... | 3-13 |
| Chapter 4 Starting up the Switch at the Initial Boot | 4-1 |
| 4.1 Setting up a Configuration Environment..... | 4-1 |
| 4.2 Connecting the Console Cable..... | 4-1 |
| 4.3 Setting Terminal Parameters | 4-1 |
| 4.4 Booting the Switch | 4-5 |
| 4.4.1 Verifying Installation before Power-up | 4-5 |
| 4.4.2 Powering up the Switch..... | 4-5 |
| Chapter 5 Loading Boot ROM and Host Software | 5-1 |
| 5.1 Introduction to Loading Approaches..... | 5-1 |
| 5.2 Loading Software Locally..... | 5-1 |
| 5.2.1 Boot Menu | 5-1 |
| 5.2.2 Loading Software from Console Port Using XModem | 5-3 |
| 5.2.3 Loading Software from an Ethernet Port Using TFTP | 5-7 |
| 5.2.4 Loading Software from an Ethernet Port Using FTP..... | 5-9 |
| 5.3 Loading Software Remotely..... | 5-10 |
| 5.3.1 Loading Software Remotely Using FTP..... | 5-10 |
| 5.3.2 Loading Software Remotely Using TFTP..... | 5-11 |
| Chapter 6 Maintenance and Troubleshooting | 6-1 |
| 6.1 Dealing with Loading Failures..... | 6-1 |
| 6.2 Dealing with Password Loss..... | 6-1 |
| 6.3 Dealing with Power System Failures | 6-1 |
| 6.4 Dealing with Configuration System Failures..... | 6-1 |
| Appendix A Lightning Protection of the Switch..... | A-1 |
| A.1 Installation of Lightning Arrester for AC Power (Socket Strip with Lightning Protection) .. | A-1 |
| A.2 Installation of Lightning Arrester for Network Port..... | A-2 |

List of Figures

| | |
|---|------|
| Figure 1-1 Front panel of the S5624P/S5624P-PWR | 1-3 |
| Figure 1-2 Front panel of the S5624F | 1-3 |
| Figure 1-3 Rear panel of the S5624P/S5624P-PWR/S5624F | 1-12 |
| Figure 1-4 8-port 1000 Mbps SFP module..... | 1-13 |
| Figure 1-5 RJ-45 connector | 1-14 |
| Figure 1-6 2-port 10 Gbps XFP module..... | 1-15 |
| Figure 1-7 1-port 10 Gbps XENPAK module | 1-16 |
| Figure 1-8 Front panel of the S5648P/S5648P-PWR | 1-17 |
| Figure 1-9 Rear panel of the S5648P/S5648P-PWR..... | 1-18 |
| Figure 1-10 8-port 1000 Mbps SFP module..... | 1-19 |
| Figure 1-11 RJ-45 connector | 1-20 |
| Figure 1-12 2-port 10 Gbps XFP module..... | 1-21 |
| Figure 1-13 1-port 10 Gbps XENPAK module | 1-22 |
| Figure 3-1 Installing the switch in a 19-inch rack..... | 3-1 |
| Figure 3-2 Installing with the front mounting brackets | 3-2 |
| Figure 3-3 Fixing the front mounting brackets to the square-holed strip | 3-2 |
| Figure 3-4 Positions for screws on the switch | 3-3 |
| Figure 3-5 Completion (1) | 3-3 |
| Figure 3-6 Completion (2) | 3-3 |
| Figure 3-7 Power socket (recommended)..... | 3-5 |
| Figure 3-8 DC-input power connector (partial)..... | 3-6 |
| Figure 3-9 RPS DC-input connector | 3-6 |
| Figure 3-10 Fix RPS connector to the cabinet..... | 3-7 |
| Figure 3-11 Grounding the switch through a grounding strip..... | 3-8 |
| Figure 3-12 Grounding the switch by burying the grounding body into the earth..... | 3-8 |
| Figure 3-13 Grounding through the AC PE wire | 3-9 |
| Figure 3-14 Grounding through the PGND of a power cabinet | 3-9 |
| Figure 3-15 Console cable..... | 3-10 |
| Figure 3-16 Diagram for stack cable..... | 3-11 |
| Figure 4-1 Network diagram for configuring the switch at initial boot..... | 4-1 |

| | |
|--|-----|
| Figure 4-2 Setting up a new connection | 4-2 |
| Figure 4-3 Setting the connection port..... | 4-2 |
| Figure 4-4 Setting communications parameters | 4-3 |
| Figure 4-5 HyperTerminal window | 4-4 |
| Figure 4-6 Settings tab..... | 4-4 |
| Figure 5-1 Properties dialog box..... | 5-4 |
| Figure 5-2 Console Port Configuration dialog box..... | 5-5 |
| Figure 5-3 <Disconnect> and <Connect> buttons..... | 5-5 |
| Figure 5-4 Send File dialog box | 5-6 |
| Figure 5-5 Sending File interface..... | 5-6 |
| Figure A-1 Diagram of lightning arrester..... | A-1 |
| Figure A-2 Installation diagram of lightning arrester for network port..... | A-3 |

List of Tables

| | |
|---|------|
| Table 1-1 Combo port list | 1-2 |
| Table 1-2 LEDs on the S5624P/S5624P-PWR | 1-4 |
| Table 1-3 LEDs on the S5624F | 1-8 |
| Table 1-4 Attributes of the Console port | 1-10 |
| Table 1-5 Specifications of 1000 Mbps SFP port cable | 1-11 |
| Table 1-6 Fabric port LEDs | 1-13 |
| Table 1-7 Optical port module | 1-14 |
| Table 1-8 Pinouts of the RJ-45 GE port | 1-14 |
| Table 1-9 XFP optical port module | 1-15 |
| Table 1-10 XK1 optical port module | 1-16 |
| Table 1-11 Optical port module | 1-20 |
| Table 1-12 Pinouts of the RJ-45 GE port | 1-20 |
| Table 1-13 XFP optical port module | 1-21 |
| Table 1-14 XENPAK optical port module | 1-22 |
| Table 1-15 System specifications of the S5600 series | 1-22 |
| Table 2-1 Dust content limits in an equipment room | 2-2 |
| Table 2-2 Harmful gas limits in the equipment room | 2-2 |
| Table 3-1 Console cable pinouts | 3-10 |