



## *Service Manual*

**Lexmark Optra™ T**

**4069-0XX**

- ***Table of Contents***
- ***Start Diagnostics***
- ***Safety and Notices***
- ***Trademarks***
- ***Index***
- ***Manuals Menu***



*Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.*

## **First Edition (September 1999)**

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:** LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time. Publications are not stocked at the address given below; requests for publications should be made to your point of purchase.

A form for reader's comments is provided at the back of this publication. If the form has been removed, comments may be addressed to Lexmark International, Inc., D22A/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Lexmark and Optra are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

**©Copyright Lexmark International, Inc. 1999**  
**All rights reserved.**

### **UNITED STATES GOVERNMENT RESTRICTED RIGHTS**

This software and documentation are provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and in applicable FAR provisions: Lexmark International, Inc., Lexington, KY 40550.

# Contents

<b>Notices and Safety Information</b> .....	<b>ix</b>
Laser Notices. ....	ix
Safety Information .....	xvii
<b>Preface</b> .....	<b>xxii</b>
<b>General Information</b> .....	<b>1-1</b>
Options .....	1-2
Maintenance Approach .....	1-3
Tools Required For Service .....	1-3
Acronyms .....	1-4
<b>Diagnostic Information</b> .....	<b>2-1</b>
Start .....	2-1
Service Error Codes .....	2-2
User Status Messages .....	2-12
User Error Messages .....	2-16
Power-On Self Test (POST) .....	2-24
Symptom Tables .....	2-25
Service Checks .....	2-28
Charge Roll Service Check .....	2-29
Cover Open Switch/Cable Service Check .....	2-31
Dead Machine Service Check .....	2-32
Duplex Option Service Check .....	2-35
Envelope Feeder Option Service Check .....	2-38
Erase Lamp Service Check .....	2-45
Fan Service Check .....	2-46
Fuser Service Check .....	2-47
Fuser Solenoid Service Check .....	2-50
Input Sensor Service Check .....	2-51
Input Tray(s) Option Service Check .....	2-52
High Capacity Feeder Input Tray Service Check .....	2-55
Main Drive Service Check .....	2-68
Operator Panel Service Check .....	2-69
Options Service Check .....	2-71
Output Bin Sensor Standard Tray Service Check .....	2-73
Output Expander Service Check .....	2-74
High-Capacity Output Stacker Service Check .....	2-79
5-Bin Mailbox Service Check .....	2-82
Paper Feed Service Check .....	2-88
Parallel Port Service Check .....	2-90

Printhead Service Check . . . . .	2-90
Print Quality Service Check . . . . .	2-91
Smart Cartridge Service Check . . . . .	2-102
Serial Port Service Check . . . . .	2-104
Toner Sensor Service Check . . . . .	2-104
Transfer Roll Service Check . . . . .	2-105
<b>Diagnostic Aids . . . . .</b>	<b>3-1</b>
Diagnostic Mode . . . . .	3-1
Device Tests . . . . .	3-2
Quick Disk Test . . . . .	3-2
Disk Test/Clean . . . . .	3-2
Flash Test . . . . .	3-3
Disabling Download Emulations . . . . .	3-3
Duplex Tests . . . . .	3-4
Duplex Quick Test . . . . .	3-4
Duplex Sensor Test . . . . .	3-5
Duplex Motor Test . . . . .	3-5
Duplex Feed 1 Test . . . . .	3-7
Duplex Feed 2 Test . . . . .	3-7
Error Log . . . . .	3-8
Viewing the Error Log . . . . .	3-8
Clearing the Error Log . . . . .	3-8
Hardware Tests . . . . .	3-9
LCD Test . . . . .	3-9
Button Test . . . . .	3-9
SDRAM Memory Test . . . . .	3-10
ROM Memory Test . . . . .	3-10
Parallel Wrap Test . . . . .	3-11
Serial Wrap Test . . . . .	3-12
Input Tray Tests . . . . .	3-14
Input Tray Feed Test . . . . .	3-14
Input Tray Sensor Test . . . . .	3-14
Output Bin Test - Standard Bin . . . . .	3-15
Output Bin Feed Test . . . . .	3-15
Output Bin Sensor Test . . . . .	3-16
Output Bin X Sensor Test . . . . .	3-16
Base Sensor Test . . . . .	3-17
5-Bin Mailbox Diverter Test . . . . .	3-18
Print Registration . . . . .	3-19
Printer Setup . . . . .	3-20
Setting the Page Count . . . . .	3-20
Viewing the Permanent Page Count . . . . .	3-20

## 4069-0XX

Maintenance Page Count . . . . .	3-21
Setting Configuration ID . . . . .	3-21
Restore EP Factory Defaults . . . . .	3-22
Print Tests . . . . .	3-23
Print Quality Test Pages . . . . .	3-24
Printing Menu Settings Page . . . . .	3-25
Autocompensator Operation . . . . .	3-26
Autoconnect System, Paper Tray Options, Envelope Feeder and Output Expander Operations . . . . .	3-27
Fuser Operation . . . . .	3-28
Paper Feed Jams . . . . .	3-29
<b>Repair Information . . . . .</b>	<b>4-1</b>
Handling ESD-Sensitive Parts . . . . .	4-1
Adjustment Procedures . . . . .	4-2
Duplex Motor Drive Belts . . . . .	4-2
Fuser Solenoid Adjustment . . . . .	4-3
Gap Adjustment . . . . .	4-3
Printhead Assembly Adjustment . . . . .	4-4
Paper Alignment Assembly Adjustment . . . . .	4-5
Screw Identification Table . . . . .	4-7
Removal Procedures . . . . .	4-12
Covers . . . . .	4-12
Center Pan Assembly . . . . .	4-16
Controller Board . . . . .	4-17
Developer Drive Assembly . . . . .	4-18
Duplex Board . . . . .	4-19
Duplex Front Cover Assembly . . . . .	4-19
Duplex Front Cover Door . . . . .	4-19
Duplex Front Cover Door Switch . . . . .	4-19
Duplex Motor . . . . .	4-20
Engine Board . . . . .	4-21
EP Frame Assembly . . . . .	4-21
Fans . . . . .	4-22
Fuser . . . . .	4-24
Fuser Board . . . . .	4-25
Fuser Cover . . . . .	4-26
Fuser Detack Fingers . . . . .	4-27
Fuser Detack Housing Assembly . . . . .	4-27
Fuser Transfer Plate . . . . .	4-28
Fuser Envelope Conditioner Solenoid (614/616) . . . . .	4-29
Fuser Exit Flag Assembly . . . . .	4-29
Fuser Exit Roll Assembly . . . . .	4-30

**4069-0XX**

Fuser Lamp . . . . .	4-31
Fuser Lower Exit Guide Assembly. . . . .	4-31
High Voltage Power Supply . . . . .	4-32
Inner EMC Shield. . . . .	4-33
Inner Paper Deflector Assembly . . . . .	4-34
Integrated Tray Compensator Assembly . . . . .	4-35
Integrated Tray Compensator Pick Roll Assembly . . . . .	4-36
Interconnect Board Assembly . . . . .	4-37
Left Side Frame . . . . .	4-39
Low Voltage Power Supply . . . . .	4-41
Main Drive Assembly . . . . .	4-42
Main Drive Motor . . . . .	4-43
Multipurpose Tray/Lower Deflector Assembly . . . . .	4-44
Operator Panel . . . . .	4-46
Operator Panel Cable/Cover Open Switch Assembly . . . . .	4-47
Optional 250/500 Paper Tray Assembly . . . . .	4-48
Outer EMC Shield . . . . .	4-49
Paper Alignment Assembly . . . . .	4-50
Paper Input Sensor . . . . .	4-51
Paper Size Sensing Board. . . . .	4-52
Pick Roll. . . . .	4-52
Printhead . . . . .	4-53
Redrive Assembly . . . . .	4-54
Right Side Frame. . . . .	4-55
Smart Cartridge Contacts . . . . .	4-56
Toner Sensor. . . . .	4-57
Transfer Roll Assembly . . . . .	4-58
Upper Paper Deflector Assembly . . . . .	4-58
Upper Front Cover Hinge Assembly . . . . .	4-59
Upper Front Cover Interlock Switch Assembly . . . . .	4-60

**Connector Locations . . . . . 5-1**

Low Voltage Power Supply . . . . .	5-1
High Voltage Power Supply . . . . .	5-3
Engine Board. . . . .	5-4
Fuser Board. . . . .	5-11
Interconnect Board . . . . .	5-12
Envelope Option Board . . . . .	5-15
Duplex Option Board . . . . .	5-17
Autoconnect - Top . . . . .	5-19
Output Expander Control Board . . . . .	5-20
High-Capacity Output Stacker Board. . . . .	5-22

**Preventive Maintenance. . . . . 6-1**

Safety Inspection Guide . . . . .	6-1
Lubrication Specifications . . . . .	6-1
Scheduled Maintenance . . . . .	6-2
<b>Parts Catalog . . . . .</b>	<b>7-1</b>
How To Use This Parts Catalog . . . . .	7-1
Assembly 1: Covers . . . . .	7-2
Assembly 2: Frame. . . . .	7-4
Assembly 3: Printhead . . . . .	7-8
Assembly 4: Paper Feed (Autocompensator). . . . .	7-10
Assembly 5: Paper Feed - Multipurpose Unit. . . . .	7-12
Assembly 6: Paper Feed - Alignment. . . . .	7-14
Assembly 7: Paper Feed - Output . . . . .	7-16
Assembly 8: Integrated Paper Tray - 250 Sheet . . . . .	7-18
Assembly 9: Integrated Paper Tray - 500 Sheet . . . . .	7-20
Assembly 10: Main Drive . . . . .	7-22
Assembly 11: Developer Drive . . . . .	7-24
Assembly 12: Fuser . . . . .	7-26
Assembly 13: Transfer . . . . .	7-30
Assembly 14: Charging . . . . .	7-32
Assembly 15: Electronics . . . . .	7-34
Assembly 16: 250 Sheet Tray . . . . .	7-46
Assembly 17: 500 Sheet Tray . . . . .	7-50
Assembly 18: Duplex . . . . .	7-54
Assembly 19: Output Expander . . . . .	7-60
Assembly 20: Envelope Feeder . . . . .	7-64
Assembly 21: High Capacity Feeder . . . . .	7-68
Assembly 22: Kiosk - Vertical Paper Adapter. . . . .	7-80
Assembly 23: Kiosk - Horizontal Paper Adapter. . . . .	7-82
Assembly 24: High-Capacity Output Stacker . . . . .	7-84
Assembly 25: 5-Bin Mailbox . . . . .	7-90
Assembly 26: Options . . . . .	7-94
Assembly 27: Miscellaneous . . . . .	7-96

**4069-0XX**




# Notices and Safety Information

## Laser Notices

The following laser notice labels may be affixed to this printer as shown:


### Laser Advisory Label



<b>CAUTION -</b>	Invisible laser radiation when open and interlock defeated. Avoid exposure to beam.
<b>ATTENTION -</b>	Radiation laser invisible si le dispositif est ouvert et non bloqué. Éviter l'exposition au rayon.
<b>VORSICHT -</b>	Unsichtbare Laserstrahlung wenn drucker offen und sperre gelöst. Nicht dem strahl aussetzen.
<b>VOORZICHTIG -</b>	Onzichtbare laserstraling wanneer open en niet vergrendeld. Vermijd blootstelling aan straal.
<b>ATTENZIONE -</b>	Radiazioni laser invisibili se il dispositivo è aperto e non bloccato. Evitare l'esposizione diretta.
<b>AVISO -</b>	Radiación laser invisible si la puerta está abierta y el dispositivo no está bloqueado. Evite exponerse a la radiación.
<b>CUIDADO -</b>	Radiação laser invisível quando a tampa é aberta. Evite exposição aos raios.
<b>VARO!</b>	Avartuessa ja suojalukitus ohittamassa olet aittina näkymättömälle laser säteilylle. Älä katso säteeseen.
<b>VARNING -</b>	Osynlig laserstrålning när denna del är öppnad och spärrar är urkopplade. Strålen är farlig.
<b>ADVARSEL -</b>	Usynlig laserstråling når døren åpnes og sikkerhetslåsen brytes. Unngå eksponering for strålen.
<b>ADVARSEL -</b>	Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.
<b>ATENCIÓN -</b>	Radiació laser invisible si s'obre i el tancament intern no és correcte. Eviteu exposat-vos-hi.
<b>注意：</b>	開閉時會有看不到的雷射輻射線外洩，請避免曝露於光線下。
<b>注意：</b>	トップカバーを開ける際スイッチが作動し、保護できないレーザーが放射されるので、絶対に注視してくだない。
<b>주의：</b>	개방과 인타복이 실패 시 눈에 보이지 않는 레이저가 방사됩니다. 레이저 빛에 노출되지 않도록 하십시오

**4069-0XX**

## **Class 1 Laser Statement Label**



**CLASS 1 LASER PRODUCT  
LASER KLASSE 1  
LOUKAN 1 LASERLAITE  
APPAREIL A LASER DE CLASSE 1  
TO IEC 60825**

---

## Laser Notice

The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR Subchapter J for Class I (1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 60825.

Class I laser products are not considered to be hazardous. The printer contains internally a Class IIIb (3b) laser that is nominally a 5 milliwatt gallium arsenide laser operating in the wavelength region of 770-795 nanometers. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service condition.

---

## Laser

Der Drucker erfüllt gemäß amtlicher Bestätigung der USA die Anforderungen der Bestimmung DHHS (Department of Health and Human Services) 21 CFR Teil J für Laserprodukte der Klasse I (1). In anderen Ländern gilt der Drucker als Laserprodukt der Klasse I, der die Anforderungen der IEC (International Electrotechnical Commission) 60825 gemäß amtlicher Bestätigung erfüllt.

Laserprodukte der Klasse I gelten als unschädlich. Im Inneren des Druckers befindet sich ein Laser der Klasse IIIb (3b), bei dem es sich um einen Galliumarsenlaser mit 5 Milliwatt handelt, der Wellen der Länge 770-795 Nanometer ausstrahlt. Das Lasersystem und der Drucker sind so konzipiert, daß im Normalbetrieb, bei der Wartung durch den Benutzer oder bei ordnungsgemäßer Wartung durch den Kundendienst Laserbestrahlung, die die Klasse I übersteigen würde, Menschen keinesfalls erreicht.

---

## Avis relatif à l'utilisation de laser

Pour les Etats-Unis : cette imprimante est certifiée conforme aux provisions DHHS 21 CFR alinéa J concernant les produits laser de Classe I (1). Pour les autres pays : cette imprimante répond aux normes IEC 60825 relatives aux produits laser de Classe I.

## **4069-0XX**

Les produits laser de Classe I sont considérés comme des produits non dangereux. Cette imprimante est équipée d'un laser de Classe IIIb (3b) (arséniure de gallium d'une puissance nominale de 5 milliwatts) émettant sur des longueurs d'onde comprises entre 770 et 795 nanomètres. L'imprimante et son système laser sont conçus pour impossible, dans des conditions normales d'utilisation, d'entretien par l'utilisateur ou de révision, l'exposition à des rayonnements laser supérieurs à des rayonnements de Classe I .

---

### **Avvertenze sui prodotti laser**

Questa stampante è certificata negli Stati Uniti per essere conforme ai requisiti del DHHS 21 CFR Sottocapitolo J per i prodotti laser di classe 1 ed è certificata negli altri Paesi come prodotto laser di classe 1 conforme ai requisiti della norma CEI 60825.

I prodotti laser di classe non sono considerati pericolosi. La stampante contiene al suo interno un laser di classe IIIb (3b) all'arseniuro di gallio della potenza di 5mW che opera sulla lunghezza d'onda compresa tra 770 e 795 nanometri. Il sistema laser e la stampante sono stati progettati in modo tale che le persone a contatto con la stampante, durante il normale funzionamento, le operazioni di servizio o quelle di assistenza tecnica, non ricevano radiazioni laser superiori al livello della classe 1.

---

### **Avisos sobre el láser**

Se certifica que, en los EE.UU., esta impresora cumple los requisitos para los productos láser de Clase I (1) establecidos en el subcapítulo J de la norma CFR 21 del DHHS (Departamento de Sanidad y Servicios) y, en los demás países, reúne todas las condiciones expuestas en la norma IEC 60825 para productos láser de Clase I (1).

Los productos láser de Clase I no se consideran peligrosos. La impresora contiene en su interior un láser de Clase IIIb (3b) de arseniuro de galio de funcionamiento nominal a 5 milivatios en una longitud de onda de 770 a 795 nanómetros. El sistema láser y la impresora están diseñados de forma que ninguna persona pueda verse afectada por ningún tipo de radiación láser superior al nivel de

la Clase I durante su uso normal, el mantenimiento realizado por el usuario o cualquier otra situación de servicio técnico.

---

## **Declaração sobre Laser**

A impressora está certificada nos E.U.A. em conformidade com os requisitos da regulamentação DHHS 21 CFR Subcapítulo J para a Classe I (1) de produtos laser. Em outros locais, está certificada como um produto laser da Classe I, em conformidade com os requisitos da norma IEC 60825.

Os produtos laser da Classe I não são considerados perigosos. Internamente, a impressora contém um produto laser da Classe IIIb (3b), designado laser de arseneto de potássio, de 5 milliwatts, operando numa faixa de comprimento de onda entre 770 e 795 nanómetros. O sistema e a impressora laser foram concebidos de forma a nunca existir qualquer possibilidade de acesso humano a radiação laser superior a um nível de Classe I durante a operação normal, a manutenção feita pelo utilizador ou condições de assistência prescritas.

---

## **Laserinformatie**

De printer voldoet aan de eisen die gesteld worden aan een laserprodukt van klasse I. Voor de Verenigde Staten zijn deze eisen vastgelegd in DHHS 21 CFR Subchapter J, voor andere landen in IEC 60825.

Laserprodukten van klasse I worden niet als ongevaarlijk aangemerkt. De printer is voorzien van een laser van klasse IIIb (3b), dat wil zeggen een gallium arsenide-laser van 5 milliwatt met een golflengte van 770-795 nanometer. Het lasergedeelte en de printer zijn zo ontworpen dat bij normaal gebruik, bij onderhoud of reparatie conform de voorschriften, nooit blootstelling mogelijk is aan laserstraling boven een niveau zoals voorgeschreven is voor klasse 1.

---

## Lasermeddelelse

Printeren er godkendt som et Klasse I-laserprodukt, i overensstemmelse med kravene i IEC 60825.

Klasse I-laserprodukter betragtes ikke som farlige. Printeren indeholder internt en Klasse IIIB (3b)-laser, der nominelt er en 5 milliwatt galliumarsenid laser, som arbejder på bølglængdeområdet 770-795 nanometer. Lasersystemet og printeren er udformet således, at mennesker aldrig udsættes for en laserstråling over Klasse I-niveau ved normal drift, brugervedligeholdelse eller obligatoriske servicebetingelser.

---

## Huomautus laserlaitteesta

Tämä kirjoitin on Yhdysvalloissa luokan I (1) laserlaitteiden DHHS 21 CFR Subchapter J -määrittelyn mukainen ja muualla luokan I laserlaitteiden IEC 60825 -määrittelyn mukainen.

Luokan I laserlaitteiden ei katsota olevan vaarallisia käyttäjälle. Kirjoittimessa on sisäinen luokan IIb (3b) 5 milliwatin galliumarsenidilaser, joka toimii aaltoalueella 770 - 795 nanometriä. Laserjärjestelmä ja kirjoitin on suunniteltu siten, että käyttäjä ei altistu luokan I määrittelyä voimakkaammalle säteilylle kirjoittimen normaalin toiminnan, käyttäjän tekemien huoltotoimien tai muiden huoltotoimien yhteydessä.

VARO! Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.

VARNING! Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.

---

## Laser-notis

Denna skrivare är i USA certifierad att motsvara kraven i DHHS 21 CFR, underparagraf J för laserprodukter av Klass I (1). I andra länder uppfyller skrivaren kraven för laserprodukter av Klass I enligt kraven i IEC 60825.

## 4069-0XX

Laserprodukter i Klass I anses ej hälsovärdliga. Skrivaren har en inbyggd laser av Klass IIIb (3b) som består av en laserenhet av gallium-arsenid på 5 milliwatt som arbetar i våglängdsområdet 770-795 nanometer. Lasersystemet och skrivaren är utformade så att det aldrig finns risk för att någon person utsätts för laserstrålning över Klass I-nivå vid normal användning, underhåll som utförs av användaren eller annan föreskriven serviceåtgärd.

---

## Laser-melding

Skriveren er godkjent i USA etter kravene i DHHS 21 CFR, underkapittel J, for klasse I (1) laserprodukter, og er i andre land godkjent som et Klasse I-laserprodukt i samsvar med kravene i IEC 60825.

Klasse I-laserprodukter er ikke å betrakte som farlige. Skriveren inneholder internt en klasse IIIb (3b)-laser, som består av en gallium-arsenlaserenhet som avgir stråling i bølgelengdeområdet 770-795 nanometer. Lasersystemet og skriveren er utformet slik at personer aldri utsettes for laserstråling ut over klasse I-nivå under vanlig bruk, vedlikehold som utføres av brukeren, eller foreskrevne serviceoperasjoner.

---

## Avís sobre el Làser

Segons ha estat certificat als Estats Units, aquesta impressora compleix els requisits de DHHS 21 CFR, apartat J, pels productes làser de classe I (1), i segons ha estat certificat en altres llocs, és un producte làser de classe I que compleix els requisits d'IEC 60825.

Els productes làser de classe I no es consideren peril·losos. Aquesta impressora conté un làser de classe IIIb (3b) d'arseniür de gal.li, nominalment de 5 mil.liwats, i funciona a la regió de longitud d'ona de 770-795 nanòmetres. El sistema làser i la impressora han sigut concebuts de manera que mai hi hagi exposició a la radiació làser per sobre d'un nivell de classe I durant una operació normal, durant les tasques de manteniment d'usuari ni durant els serveis que satisfacin les condicions prescrites.

---

## Japanese Laser Notice

レーザーに関するお知らせ

このプリンターは、米国ではDHHS 21 CFRサブチャプターJのクラスI（1）の基準を満たしたレーザー製品であることが証明されています。また米国以外ではIEC 825の基準を満たしたクラスIのレーザー製品であることが証明されています。

クラスIのレーザー製品には危険性はないと考えられています。このプリンターはクラスIII b（3 b）のレーザーを内蔵しています。このレーザーは、波長が770 ～ 795ナノメートルの範囲で、通常5ミリワットのガリウム砒化物を放射するレーザーです。このレーザーシステムとプリンターは、通常の操作、ユーザのメンテナンス、規定された修理においては、人体がクラスIのレベル以上のレーザー放射に晒されることのないよう設計されています。

---

## Chinese Laser Notice

注意：

本打印机被美国认证合乎 DHHS 21 CFR Subchapter I 对分类 I (1) 激光产品的标准，而在其他地区则被认证合乎 IEC 825 的标准。

分类 I 激光产品一般认为不具危险性，本打印机内部含有分类 IIIb (3b) 的激光，在操作过程中会产生 5 毫瓦含镓及砷的微量激光，其波长范围在 770-795 nm 之间。本激光系统及打印机的设计，在一般操作、使用者维护或规定内的维修情况下，不会使人体接触分类 I 以上等级的辐射。



---

## Korean Laser Notice

본프린터는 1등급 레이저 제품들에 대한 DHHS 21 CFR Subchapter 3의 규정을 준수하고 있음을 미국에서 인증받았으며, 그외의 나라에서도 IEC 825 규정을 준수하는 1등급 레이저 제품으로서 인증을 받았습니다.

1등급 레이저 제품들은 안전한 것으로 간주됩니다. 본 프린터는 5 밀리와트 갈륨 아르세나이드 레이저로서 770-795 나노미터의 파장대에서 활동하는 Class III (3b) 레이저를 내부에 갖고 있습니다. 본 레이저 시스템과 프린터는 정상 작동 중이나 유지 보수 중 또는 규정된 서비스 상태에서 상기의 Class I 수준의 레이저 방출에 사람이 절대 접근할 수 없도록 설계되어 있습니다.

---

## Safety Information

- This product is designed, tested and approved to meet strict global safety standards with the use of specific Lexmark components. The safety features of some parts may not always be obvious. Lexmark is not responsible for the use of other replacement parts.
- The maintenance information for this product has been prepared for use by a professional service person and is not intended to be used by others.
- There may be an increased risk of electric shock and personal injury during disassembly and servicing of this product. Professional service personnel should understand this and take necessary precautions.

---

## Consignes de Sécurité

- Ce produit a été conçu, testé et approuvé pour respecter les normes strictes de sécurité globale lors de l'utilisation de composants Lexmark spécifiques. Les caractéristiques de

sécurité de certains éléments ne sont pas toujours évidentes. Lexmark ne peut être tenu responsable de l'utilisation d'autres pièces de rechange.

- Les consignes d'entretien et de réparation de ce produit s'adressent uniquement à un personnel de maintenance qualifié.
- Le démontage et l'entretien de ce produit pouvant présenter certains risques électriques, le personnel d'entretien qualifié devra prendre toutes les précautions nécessaires.

---

## **Norme di sicurezza**

- Il prodotto è stato progettato, testato e approvato in conformità a severi standard di sicurezza e per l'utilizzo con componenti Lexmark specifici. Le caratteristiche di sicurezza di alcune parti non sempre sono di immediata comprensione. Lexmark non è responsabile per l'utilizzo di parti di ricambio di altri produttori.
- Le informazioni riguardanti la manutenzione di questo prodotto sono indirizzate soltanto al personale di assistenza autorizzato.
- Durante lo smontaggio e la manutenzione di questo prodotto, il rischio di subire scosse elettriche e danni alla persona è più elevato. Il personale di assistenza autorizzato, deve, quindi, adottare le precauzioni necessarie.

---

## **Sicherheitshinweise**

- Dieses Produkt und die zugehörigen Komponenten wurden entworfen und getestet, um beim Einsatz die weltweit gültigen Sicherheitsanforderungen zu erfüllen. Die sicherheitsrelevanten Funktionen der Bauteile und Optionen sind nicht immer offensichtlich. Sofern Teile eingesetzt werden, die nicht von Lexmark sind, wird von Lexmark keinerlei Verantwortung oder Haftung für dieses Produkt übernommen.
- Die Wartungsinformationen für dieses Produkt sind ausschließlich für die Verwendung durch einen Wartungsfachmann bestimmt.
- Während des Auseinandernehmens und der Wartung des Geräts besteht ein zusätzliches Risiko eines elektrischen Schlags und körperlicher Verletzung. Das zuständige

Fachpersonal sollte entsprechende Vorsichtsmaßnahmen treffen.

---

## **Pautas de Seguridad**

- Este producto se ha diseñado, verificado y aprobado para cumplir los más estrictos estándares de seguridad global usando los componentes específicos de Lexmark. Puede que las características de seguridad de algunas piezas no sean siempre evidentes. Lexmark no se hace responsable del uso de otras piezas de recambio.
- La información sobre el mantenimiento de este producto está dirigida exclusivamente al personal cualificado de mantenimiento.
- Existe mayor riesgo de descarga eléctrica y de daños personales durante el desmontaje y la reparación de la máquina. El personal cualificado debe ser consciente de este peligro y tomar las precauciones necesarias.

---

## **Informações de Segurança**

- Este produto foi concebido, testado e aprovado para satisfazer os padrões globais de segurança na utilização de componentes específicos da Lexmark. As funções de segurança de alguns dos componentes podem não ser sempre óbvias. A Lexmark não é responsável pela utilização de outros componentes de substituição.
- As informações de segurança relativas a este produto destinam-se a profissionais destes serviços e não devem ser utilizadas por outras pessoas.
- Risco de choques eléctricos e ferimentos graves durante a desmontagem e manutenção deste produto. Os profissionais destes serviços devem estar avisados deste facto e tomar os cuidados necessários.

---

## Informació de Seguretat

- Aquest producte està dissenyat, comprovat i aprovat per tal d'acomplir les estrictes normes de seguretat globals amb la utilització de components específics de Lexmark. Les característiques de seguretat d'algunes peces pot ser que no sempre siguin òbvies. Lexmark no es responsabilitza de l'ús d'altres peces de recanvi.
- La informació pel manteniment d'aquest producte està orientada exclusivament a professionals i no està destinada a ningú que no ho sigui.
- El risc de xoc elèctric i de danys personals pot augmentar durant el procés de desmuntatge i de servei d'aquest producte. El personal professional ha d'estar-ne assabentat i prendre les mesures convenients.

---

## Chinese Safety Information

### 安全资讯

- 本产品使用特有的 Lexmark 元件，并依照严格的世界安全标准来设计、测试及验证。有些零件的安全功能可能不明显。对于其他厂牌更换零件的使用，Lexmark 概不负责。
- 本产品的维护资讯仅供专业服务人员使用，而非针对一般使用者。
- 本产品在拆卸、维修的时候，遭受电击或人员受伤的危险性会增高，专业服务人员对这点必须有所了解，并采取必要的预防措施。

---

## Korean Safety Information

### 안전 사항

- 본 제품은 특정 Lexmark 구성 요소의 사용에 있어 엄격한 세계 안전 표준에 맞도록 설계, 테스트되었으며 승인받았습니다. 일부 부품의 안전성은 항상 보장되지 않습니다. Lexmark는 다른 교체 부품의 사용에 대한 책임을 지지 않습니다.
- 본 제품에 관한 유지 보수 설명서는 전문 서비스 기술자용으로 작성된 것이므로 비 전문가는 사용할 수 없습니다.
- 본 제품을 해체하거나 정비할 경우 전기적인 충격을 받거나 상처를 입을 위험이 커집니다. 전문 서비스 기술자는 이 사실을 숙지하고 필요한 예방 조치를 취하도록 하십시오.

---

## Ozone Information

This product does not produce measurable amounts of ozone gas.

## **Preface**

This manual is divided into the following chapters:

- “General Information” contains a general description of the printer, options, and the maintenance approach used to repair it. General environmental and safety instructions as well as special tools and test equipment are listed in this chapter.
- “Diagnostic Information” contains a service error code table, user status message table, user error message table, symptom table, and service checks used to isolate failing field replaceable units (FRUs).
- “Diagnostic Aids” contains tests and checks used to locate or repeat symptoms of printer problems. Printer operation information is provided to enhance the tests and checks.
- “Repair Information” provides instructions for making printer adjustments and removing and installing FRUs.
- “Connector Locations” uses illustrations to identify the major components and test points on the printer.
- “Preventive Maintenance” contains safety inspection guidelines, lubrication specifications, and maintenance information to prevent problems and maintain performance.
- “Parts Catalog” contains illustrations and part numbers for individual FRUs.

## **1. General Information**

The Optra™ T laser printers are letter quality page printers designed to attach to IBM-compatible PC's and to most computer networks.

The Optra T laser printer is available in eight models. The model designations are as follows:

4069-01N, 4069-21N, 4069-41N, 4069-61N, 4069-010, 4069-212  
4069-414, 4069-616

---

## Options

The following options are available. Some options are not available in every country. Contact your point of purchase for options available in your country.

Memory options of 4MB, 8MB, 16MB, 32MB, 64MB and 128MB  
SDRAM DIMM

Flash memory options of 2MB, 4MB, 8MB and 16MB DIMM

Integrated network options

Token-Ring

Ethernet

Tri-Port Adapter

IR Adapter

IPDS

SCS

USB/Parallel Port

250 and 500-sheet paper trays of A5, letter, and legal size.

250 Sheet Special Media Tray Assembly

500 Sheet Special Media Tray

2000 Sheet High Capacity Feeder

Envelope feeder

Duplex option - 250 Sheet

Duplex option - 500 Sheet

Hard Disk - 2.1 GB

Forms Hard Disk - 2.1 GB

Infrared Adapter

Vertical Kiosk Presenter

Horizontal Kiosk Presenter

Output Expander

5-Bin Mailbox

High Capacity Output Stacker



---

## Maintenance Approach

The diagnostic information in this manual leads you to the correct field replaceable unit (FRU) or part. Use the service error codes, user status messages, user error messages, service checks, and diagnostic aids to determine the printer problem and repair the failure. After you complete the repair, perform tests as needed to verify the repair.

---

## Tools Required For Service

- Flat-blade screwdriver
- #1 Phillips screwdriver
- #2 Phillips screwdriver
- T10 Torx Screwdriver
- 7.0 mm nut driver
- 5.5 mm wrench
- Needlenose pliers
- Diagonal pliers
- Spring hook
- Feeler gauges
- Analog or digital multimeter
- Parallel wrap plug 1319128
- Serial wrap plug 1329048
- Twinax/serial debug cable 1381963
- Coax/serial debug cable 1381964

---

## Acronyms

CSU	Customer Setup
DIMM	Dual In-Line Memory Module
DRAM	Dynamic Random Access Memory
EDO	Enhanced Data Out
EP	Electrophotographic Process
EPROM	Erasable, Programmable Read-Only Memory
ESD	Electrostatic Discharge
FRU	Field Replaceable Unit
GB	Gigabyte
HVPS	High Voltage Power Supply
LASER	Light Amplification by Stimulated Emission of Radiation
LCD	Liquid Crystal Display
LED	Light-Emitting Diode
LVPS	Low Voltage Power Supply
MROM	Masked Read Only Memory
NVRAM	Nonvolatile Random Access Memory
OEM	Original Equipment Manufacturer
PC	Photoconductor
POR	Power-On Reset
POST	Power-On Self Test
RIP	Raster Imaging Processor
ROM	Read Only Memory
SIMM	Single In-Line Memory Module
SDRAM	Synchronous Dual Random Access Memory
SRAM	Static Random Access Memory
UPR	Used Parts Return
V ac	Volts alternating current
V dc	Volts direct current

---

## 2. Diagnostic Information

---

### Start

**CAUTION:** Remove power from the printer before you connect or disconnect any cable or electronic board or assembly for personal safety and to prevent damage to the printer. Use the handholds on the side of the printer. Make sure your fingers are not under the printer when you lift or set the printer down.

Use the service error code, user status message, user error message, symptom table, service checks, and diagnostic aids in this chapter to determine the corrective action necessary to repair a malfunctioning printer.

Service error codes are indicated by a three-digit error code. If a service error code is displayed, go to the **“Service Error Codes” on page 2-2**.

User status messages provide the user with information on the current status of the printer. Ready is displayed on the first line of the display unless Power Saver is invoked, and then Power Saver is displayed. If a user status message is displayed, go to the **“User Status Messages” on page 2-12**.

User error messages are indicated by a two or three-digit error code that provides the user with information that explains a problem with a print cartridge, paper jam, option, port, and so on. If a user error message is displayed, go to the **“User Error Messages” on page 2-16**.

If your machine completes the **“Power-On Self Test (POST)” on page 2-24** without an error, and you have a symptom, go to the **“Symptom Tables” on page 2-25**. Locate your symptom and take the appropriate action.

If a service error code appears while you are working on the machine, go to the **“Service Error Codes” on page 2-2** and take the indicated action for that error.

## 4069-0XX

### Service Error Codes

Service Error Codes are generally non-recoverable except in an intermittent condition when you can POR the printer to temporarily recover from the error condition.

Error Code	Action
900 RIP Software	Replace the controller board.
901 Engine Flash	Indicates that the flash which the engine board code is programmed into is bad. Replace the engine board.
902 General Engine Software	These errors indicate an unrecoverable engine software error. Replace the engine board.
903 Paperport Link Driver Error	
904 Interface Violation by the controller software	
905 Interface Violation by Paperport Device	
906 Controller-Engine Link Driver Error	
910 DC Pick Motor DC Pick Motor Stall	Error Codes 910,911,912,913 and 914 are indications that a Tray 1 paper feed problem has been detected. Go to the <b>"Input Tray(s) Option Service Check"</b> on <b>page 2-52</b> .
911 DC Pick Motor Excessive PWM	
912 DC pick motor below speed	
913 DC pick motor over speed	
914 DC pick motor: No encoder feedback	

**4069-0XX**

<b>Error Code</b>	<b>Action</b>
917 Transfer Roll	Indicates a problem in the transfer roll area. Go to the <b>"Transfer Roll Service Check" on page 2-105.</b>
920 Fuser Error	Indicates that the fuser is below temperature when printing. Go to the <b>"Cold Fuser Service Check" on page 2-47.</b>
921 Fuser Error	Indicates that the fuser is below standby temperature when the printer is idle. Go to the <b>"Cold Fuser Service Check" on page 2-47.</b>
922 Fuser Error	Fuser failed to reach standby temperature. Go to the <b>"Cold Fuser Service Check" on page 2-47.</b>
923 Fuser Error	Fuser is too hot during printing or when printer is idle. Go to the <b>"Hot Fuser Service Check" on page 2-49.</b>
924 Fuser Error	An open circuit has been detected in the Fuser Thermistor Circuit. Go to the <b>"Hot Fuser Service Check" on page 2-49.</b>
925 Fuser Error	Wrong fuser lamp installed. Check the fuser lamp for the correct type of lamp that should be installed.
927 Fan Stalled	Indicates a printer fan stalled. Go to the <b>"Fan Service Check" on page 2-46.</b>
928 Erase Lamps	Indicates that the engine has detected that either the erase lamp assembly is missing or disconnected. Go to the <b>"Erase Lamp Service Check" on page 2-45.</b>
929 Toner Sensor	The toner sensor is not operating properly, the developer drive assembly is not operating properly or the print cartridge is defective. Go to the <b>"Toner Sensor Service Check" on page 2-104.</b>
930 Printhead Error	The wrong printhead is installed. Replace with the correct printhead.

## 4069-0XX

Error Code	Action
931-935 Printhead Error	These errors represent a problem with the printhead. Go to the <b>"Printhead Service Check"</b> on page 2-90.
932 - Printhead: Lost Hsync	
933 - Mirror Motor Locks/Lost Hsync	
934 - Mirror Motor Lost Lock	
935 - Mirror Motor unable to reach operating speed.	
936-937 Transport Motor	Indicates a problem with the main drive motor. Go to the <b>"Main Drive Service Check"</b> on page 2-68.
936 - Main Drive Motor initial lock failure	
937 - Main Drive Motor lost lock	
939 Controller - Engine Communications Error	<p>The controller board and the engine board cannot communicate with one another. The controller board, engine board or interconnect board is defective. Check each board for correct installation and secure ground. If no problem is found, replace the FRUs in the following order:</p> <p>controller board</p> <p>engine board</p> <p>interconnect board</p> <p><b>Note:</b> The controller software also can cause a 939 error code. Contact your next level for software support.</p>
941 Controller Code CRC	Replace the controller board.
941 Controller Font CRC	Replace the controller board.

## 4069-0XX

Error Code	Action
943 Controller Font Version	Indicates that the controller code and FONT ROM are incompatible.
944 Controller Board Failure	Replace the controller board.
945 Controller Board Failure - ASIC Failure	Replace the controller board.
946 Controller Board Failure - SRAM Failure	Replace the controller board.
947 Engine Board	Replace the engine board.
953 NVRAM Failure	Indicates the NVRAM chip on the engine board has failed. Replace the engine board.
954 NVRAM Failure	Indicates the NVRAM experienced a CRC failure. Replace the engine board.
956 Configuration ID	<p>Indicates a problem with the Configuration ID. This error occurs because the engine received a configuration ID from the controller software which is not valid for the level of engine code existing in the printer. Setting the configuration ID correctly should fix this error. The ID can be set via the NPA data stream or operator panel.</p> <p>Note: This error is not generated at POR to allow the servicer a method of resetting the configuration ID. However, setting the configuration ID is the only operation that the servicer can perform. See <b>“Setting Configuration ID”</b> on page 3-21.</p>
960 RAM Memory Error	Indicates a DRAM Memory Error on the controller board. Replace the controller board.
961 RAM in Slot 1 is Bad.	Replace the DIMM in Slot 1. If this does not fix the problem, replace the controller board.
962 RAM in Slot 2 is Bad.	Replace the DIMM in Slot 2. If this does not fix the problem, replace the controller board.

## 4069-0XX

Error Code	Action
964 Emulation Error	<p>Indicates a failure within the Download Emulation which is programmed into the code overlay SIMM. The specific error is as follows:</p> <p>964 - Download Emulation CRC Failure. Checksum Failure.</p> <p>965 - Download Emulation Outdated, The Download Emulation and the controller code are incompatible. Go to <b>"Disabling Download Emulations"</b> on page 3-3.</p>
965 Emulation Error	
975 - 979 Network Card X	<p>The following errors indicate a failure with the network card in the specified slot. X=any card installed in slots 1,2 or 3.</p> <p>975 - Unrecognizable Network Card x. Replace Network Card x.</p> <p>976 - Unrecoverable software error in Network Card x.</p> <p>977 - Controller software detects that a Network Card is installed in slot x but cannot establish communications with it.</p> <p>978 - Bad checksum while programming Network Card x. Replace Network Card x.</p> <p>979 - Flash parts failed while programming Network Card x.</p> <p>If the printer is a network model, replace the controller board.</p>
980 <device> Comm	The engine is experiencing unreliable communications to the specified device.
981 <device>	The engine protocol violation detected by the specified device.
982 <device> Comm	Communications error detected by the specified device.
983 <device>	Invalid command received by the specified device.
984 <device>	<p>Invalid command parameter received by the specified device.</p> <p><b>Note:</b> Service Errors 980 thru 984 &lt;device&gt; can be one of the following: engine board, duplex, tray x (1,2,3,4 or 5), envelope feeder or bin x (1,2 or 3).</p>



## 4069-0XX

Error Code	Action
990 <device>	Indicates an equipment check condition has occurred in the specified device, but the device is unable to identify the exact component failure.  <b>Note:</b> <device> can be one of the following: duplex, tray x (1,2,3,4 or 5), envelope feeder or output bin x(1,2 or 3).
991 <device> Card	The specified device has detected an equipment check in its system card.  <b>Note:</b> <device> can be one of the following: duplex, tray x(1,2,3,4 or 5), envelope feeder or output bin x (1,2 or 3).

### Sub Error Codes For 9XX and 2XX Error Codes

The sub error codes are helpful troubleshooting a paper path problem, especially paper jams in the base printer, envelope feeder and duplex unit.

Press and hold return and press select to enter for sub error codes.

The following is an example of how the printer displays a duplex unit sub error code.

	Byte 1	Byte 2	Byte 3	Byte 4
DU	XX	XX	XX	XX
DU	XX	XX	XX	XX
	Byte 5	Byte 6	Byte 7	Byte 8

## 4069-0XX

### Base Printer Sub Error Codes

Each status byte has a different level of troubleshooting value for each area of the printer. The following table displays status bytes 1, 2 and 3. This set of status bytes is designed to help isolate paper jams and paper feed problems in the base printer.

Status Bytes 1, 2,3	Explanation
84 xx 00	The input sensor is still covered by the first sheet of paper through the printer and the second sheet is ready to arrive at the sensor.
84 xx 01	Video information has not started on the page at the input sensor within two inches after activating the input sensor flag.
84 xx 02	The media takes too long to complete a pass through the input sensor.
84 xx 04	This can occur when a sheet of paper is in the machine during POST and the input sensor flag has tripped the input sensor.
84 xx 05	This error is generated whenever media is seen at the input sensor before the sensor flag activates the input sensor.
84 xx 06	A paper jam is detected by the tray you are trying to feed from.
84 xx 07	A paper jam is detected by a smart option and an error message displays.
84 xx 08	Paper Tray 5 pass thru sensor is not activated by a sheet of paper.
84 xx 09	Paper Tray 4 pass thru sensor is not activated by a sheet of paper.
84 xx 0A	Paper Tray 3 pass thru sensor is not activated by a sheet of paper.
84 xx 0B	Paper Tray 2 pass thru sensor is not activated by a sheet of paper.
84 xx 0C	Paper Tray 5 pass thru sensor is not activated and never deactivated. A sheet of paper may still be over the sensor or the flag is still activated.

**4069-0XX**

<b>Status Bytes 1, 2,3</b>	<b>Explanation</b>
84 xx 0D	Paper Tray 4 pass thru sensor is not activated and never deactivated. A sheet of paper may still be over the sensor or the flag is still activated.
84 xx 0E	Paper Tray 3 pass thru sensor is not activated and never deactivated. A sheet of paper may still be over the sensor or the flag is still activated.
84 xx 0F	Paper Tray 2 pass thru sensor is not activated and never deactivated. A sheet of paper may still be over the sensor.
84 xx 11	The paper activated the input sensor too soon.
84 xx 13	The paper activated the input sensor too soon.
84 xx 1D	The envelope feeder pass thru sensor is activated and never deactivated.
84 xx 1E	The envelope feeder pass thru sensor is not activated.
84 xx 1F	The paper fed too early from Tray 1.
84 xx 21	The smart option did not pick the paper.
84 xx 22	The smart option did not pick the paper.
8E xx 02	The input sensor is not activated even though the paper is picked from the source.
8E xx 0B	The autocompensator DC motor stalls when attempting to pick a sheet of paper.
8E xx 11	The autocompensator DC motor takes too long to ramp up.

## 4069-0XX

### Envelope Feeder Sub Error Codes

Status byte 1 contains the most valuable information to help isolate a feed problem with the envelope feeder and is the only byte contained in the following table.

Status Byte 1	Explanation
00	There was no envelope feeder error reported.
10	Printer failed POST - Homing of Envelope feeder
11	Printer failed POST - Halted Envelope Feeder
21	The envelope feeder failed to feed, envelope jam.
30	The D.C. motor failed to reach operating speed.
32	The motor stalled.
36	The motor failed to stop.

### Duplex Unit Sub Error Codes

Status byte 4 contains the most valuable information to help isolate a failing part or assembly in the duplex option and is the only byte contained in the following table.

Status Byte 4	Explanation
00	No duplex error. No problem was reported to the engine by the duplex system card.
01	The leading edge of the sheet of paper never arrived at the input sensor.
02	The duplex option system board never received media notification from the printer.
03	The trailing edge of the sheet of paper never cleared the input sensor.

## 4069-0XX

Status Byte 4	Explanation
04	The leading edge of the sheet of paper never arrived at the exit sensor. <b>Note:</b> This error is the most common due to the long length of the paper path between the input sensor and the exit sensor.
05	The duplex logic thinks a sheet of paper is feeding to the duplex unit due to a sensor malfunction in the paper path when in fact the printer has not sent a command to send a sheet of paper to the duplex unit.
06	The exit sensor detected a sheet of paper too early.
07	The sheet of paper's trailing edge did not clear the exit sensor in the desired length of time.
08	The feed motor experienced a complete motor stall.
0E	The D.C. motor is under speed. The motor never reached the correct operating speed.
13	There is paper left in the duplex option. Paper was sensed during the homing operation during POST.
15	There is paper left in the duplex option. Paper was sensed during the DC motor diagnostic test during POST.
18	The D.C. motor experienced an acceleration error.
3D	There is paper left in the duplex option. Paper was sensed during IR clear during POST.

## User Status Messages

User Status Message	Status	Action
Ready	The printer is ready to receive and process data.	Press Menu> or <Menu to take the printer out of Ready and enter all the Menus except the TESTS MENU (Busy State).
Ready/Hex	The printer is ready and HEX Trace is active, which is known as HEX Trace Ready.	Press Menu> or <Menu to take the printer out of Ready and enter the TESTS MENU (Busy State). Press Select for the values. Press Menu> until Reset Printer is on the second line of the display. Press Select to Reset the printer.
Busy	<p>The printer is busy receiving or processing data, or printing data.</p> <p><b>Note:</b> The printer indicator light blinks while the printer is processing data.</p>	Press Stop to take the printer out of Busy. The Not Ready message is displayed. No more data is processed, but the printer processes all paper currently in the printer paper path. Press Go to return to Ready.
Flushing Buffer	The printer is flushing corrupted print data and the current print job is being discarded.	No button actions are possible while this message is displayed.

User Status Message	Status	Action
Printing Menu Settings	The printer is processing or printing a list of current settings menus because Print Menu Settings is selected from the menu.	Press Stop to take the printer out of Ready. The Not Ready message is displayed. No more data is processed, but the printer processes all paper currently in the printer paper path. Press Go to return to Ready after the page prints. Press Menu> or <Menu to take the printer out of Ready and enter the TESTS MENU (Busy State). Press Select for the values. Press Menu> until Reset Printer is on the second line of the display. Press Select to reset the printer.
Printing Directory List	A directory of the flash and disk contents is processing or printing because Print Directory is selected from the menu.	Press Stop to take the printer out of Ready. The Not Ready message is displayed. No more data is processed, but the printer processes all paper currently in the paper path. Press Go to return to Ready after the page prints. Press Menu> or <Menu to take the printer out of Ready and enter the TESTS MENU (Busy Stat). Press Select for the values. Press Menu> until Reset Printer is on the second line of the display. Press Select to reset the printer.

## 4069-0XX

User Status Message	Status	Action
Restoring Factory Defaults	The printer is restoring factory defaults.	No button actions are possible while this message is displayed.
Performing Self Tests	The printer is running the normal series of start-up tests after it is powered On. When the tests are complete, the printer returns to Ready.	No button actions are possible while this message is displayed.
Not Ready (Press Go)	The printer is in the Not Ready state, which means it is not ready to receive or process data. This message displays when Menu> or <Menu is pressed during a print job.	Press Go to take the printer out of the Not Ready state. Press Menu> or <Menu to take the printer out of Ready and enter the TESTS MENU (Busy state). Press Menu> until Reset Printer is on the second line of the display. Press Select to reset the printer.
Resetting Printer	The printer is deleting any print jobs in process and restoring all settings to user defaults.	No button actions are possible while this message is displayed.
Formatting Flash (Do Not Power Off)	The flash memory is being formatted.	No button actions are possible while this message is displayed.
Program Flash (Do Not Power Off)	The flash memory is being programmed, which means fonts or macros are being written to flash memory.	Do not perform any button actions while this message is displayed.
Formatting Disk	The disk is being formatted.	No button actions are possible while this message is displayed.



## 4069-0XX

User Status Message	Status	Action
Programming Disk (Do Not Power Off)	The disk is being programmed, which means fonts or macros are being written to disk.	No button actions are possible while this message is displayed.  <b>Note:</b> If information is written to flash memory and to disk at the same time, the Program Flash message is displayed.
Menus Disabled	The printer menus have been disabled. This occurs when Menu> or <Menu is pressed while the printer is Ready and Menu Lockout is active. The printer display shows this message for one second and then returns to the Ready message.	No button actions are possible while this message is displayed.
Activating Menu Changes	The printer is reset to activate a printer setting changed in the menus.	No button actions are possible while this message is displayed.

## User Error Messages

User Error Message	Explanation
200 Paper Jam Remove Cartridge	Paper is jammed at the printer Input Sensor. Open the printer's upper front door and remove the print cartridge to access the paper jam area.
201 Paper Jam Remove Cartridge	Paper is jammed between the printer's input and exit sensors. Open the printer's upper front door and remove the print cartridge to access the jam area.
202 Paper Jam Open Rear Door	Paper is jammed at the printer exit sensor. Open the printer rear door to access the jam area.
230 Paper Jam Check Duplex	The paper is most likely jammed in the Duplex Unit. Remove the duplex front cover to access the jam area. If the paper is jammed in the rear of the duplex, then replace the duplex front cover and open the duplex rear door. If the paper is not jammed in the duplex unit, then it may be jammed in the rear of the printer. Open the printer rear door to access the jam.
24X Paper Jam Check Tray X	Paper is jammed around Tray X (X=tray 1 thru 5). Try opening Tray X. If the tray is difficult to remove, then you may have to remove the tray above or below tray X to remove the jammed pages.
250 Paper Jam Check MP Feeder	Paper is jammed in the multipurpose feeder.
260 Paper Jam Check Envelope Feeder	Paper is jammed in the envelope feeder.
27X Paper Jam Check Output Bin X	Paper is jammed in output bin X (X=1 thru 3). Open the rear door of Output Bin X to access the jammed pages.
Insert Cartridge or Close Door	This message displays when the printer's front door is open or the print cartridge is missing. If this message cannot be cleared go to " <b>Cover Open Switch/Cable Service Check</b> " on page 2-31.

User Error Message	Explanation
31 Defective Print Cartridge	<p>Error code 31 is displayed when the top front cover is closed and a defective print cartridge is detected. It may take the printer 10-20 seconds to determine if the print cartridge is defective. Depending on the setting of the Machine Class ID the printer may be allowed to print pages during this 10-20 second interval. If pages are allowed to print, they are not reprinted once a good print cartridge is inserted.</p> <p><b>Note:</b> This error indicates the printer was able to read the cartridge ID, but the ID did not pass the verification test. To pass the verification test, the ID read from the print cartridge must match the ID from the last "good" print cartridge or the same ID must be read from the print cartridge twice. The last "good" print cartridge ID is stored in NVRAM.</p>
32 Unsupported Print Cartridge	<p>Error 32 is displayed when the top cover is closed and an unsupported print cartridge is detected. It may take the printer 10-20 seconds to determine if the print cartridge is supported. Depending on the setting of the Machine Class ID the printer may be allowed to print pages during this 10-20 second interval. If pages are allowed to print, then they are not reprinted once a good print cartridge is inserted. If this does not fix the problem, go to <b>"Smart Cartridge Service Check" on page 2-102.</b></p>
34 Short Paper	<p>The printer determines the paper length is too short to print the formatted data. This occurs when the printer does not know the actual paper size loaded in the tray. For auto-size sensing trays, this error occurs if the paper stop is in the incorrect position. Make sure the Paper Size setting is correct for the size paper that is being used.</p>
36 Resolution Reduced	<p>The resolution of the page has been reduced from 600 dpi to 300 dpi in order to prevent a Memory Full error. This message can only occur if the Resolution Reduction setting is turned on.</p> <p><b>Note:</b> 1200 dpi pages are not resolution reduced. If a 1200 dpi job runs out of memory, a Memory Full error is displayed.</p>

User Error Message	Explanation
37 Insufficient Collation Memory	This message is displayed when the printer memory used to store pages is too full to collate the print job.
38 Memory Full	This message is displayed when the printer memory used to store pages is full.
39 Complex Page	This message is displayed when the page is too complex to print.
51 Defective Flash	This message is displayed when the printer detects a defective flash. This error may occur at power on, or during flash format and write operations. Press Go to clear the message. The flash is marked as bad and normal operation continues. Flash operations are not allowed until the problem is resolved.
52 Flash Full	This message is displayed when there is not enough free space in the flash memory to hold the resources that have been requested to be written to flash.
53 Unformatted Flash	This message is displayed when the printer detects an unformatted flash at power on. Press Go to clear the message. The flash is marked as bad and normal operation continues. Flash operations are not allowed until the flash is formatted.
54 Standard Serial Error	This error is displayed when a serial error (framing or parity) is detected on the standard serial port. This usually indicates the serial port is not set up correctly.
54 Serial Option X Error	This error is displayed when a serial error (framing or parity) is detected on the optional serial port. This usually indicates the optional serial port is not set up correctly.
56 Standard Serial Disabled	This error is displayed when data is sent to the printer across the standard serial port, but the port has been disabled.

User Error Message	Explanation
56 Parallel Port Disabled	This error is displayed when data is sent to the printer across the parallel port, but the parallel port has been disabled. Once this message is displayed, reporting of further errors is suppressed until the menus are entered, or the printer is reset.
58 Too Many Trays Attached	This error code is displayed when too many input trays are attached to the printer.
58 Too Many Bins Attached	This error code is displayed when too many optional output bins are attached to the printer.
58 Too Many Disks Installed	This error is displayed when too many disks are attached to the printer.
61 Defective Disk	This error code is displayed when the printer detects a defective disk. This error may occur at power on or during disk format and write operations. The following actions may be taken while this message is displayed: Press Go to clear the message. The disk is marked defective and normal printer operations continue. Disk operations are not allowed with a defective disk. The Format Disk menu is not shown.
62 Disk Full	This error code is displayed when there is not enough free space on the disk to hold the resources that have been requested to be written to the disk. This message displays for both resource and PostScript Disk operators when the disk is full.
63 Unformatted Disk	This error code displays when the printer detects an unformatted disk at power on. Press Go to clear the message. The disk is marked as bad and normal operation continues. Disk operations are not allowed until the disk is formatted.
80 Scheduled Maintenance	The operator panel displays this message at each 250K page count interval. It is necessary to replace the fuser assembly, transfer roller, and charge roll at this interval to maintain the print quality and reliability of the printer. The parts are available as a maintenance kit. For more information, go to <b>"Scheduled Maintenance" on page 6-2.</b>

## 4069-0XX

User Error Message	Explanation
81 Engine Code CRC Failure	This error displays when the microcode to be programmed in the engine flash code module has failed a CRC check. Press Go to clear the message. The microcode data is discarded and must be re-transmitted from the host computer.
88 Toner Low	This error displays when toner low occurs and the toner low alarm is activated. Press Go to clear this message.

### User Line 2 Messages

If none of the conditions exist that are listed in the following table, line 2 is blank. If any of the messages in the table are displayed the following actions can be taken:

Press Menu> or <Menu to take the printer offline and access the Ready Menu group.

**Note:** The Menu buttons are not active if Menu Lockout is turned on.

Press Stop to take the printer offline. The Not Ready message is displayed. No more data is processed from the host computer. Press the Go button to return the printer to the Ready state.

User Message	Explanation
Toner Low	If the toner cartridge is low, then "Toner Low" displays. The Toner Low condition clears whenever the upper front door is opened, and Toner Low displays again if the condition exists after the upper front door is closed.
Tray X Missing	If any of the input trays are missing, then "Tray X Missing" displays (where X designates which Tray (1 through 5) is missing. If multiple trays are missing, they are prioritized in this order: Tray 1, 2..., then tray 5. Tray X Missing status clears whenever Tray X is reinserted.

User Message	Explanation
Tray X Empty	<p>If any of the input trays are empty, then “Tray X Empty” displays where X designates which tray (Tray 1 through 5) is empty. If multiple trays are empty, then they are prioritized in this order: Tray 5, Tray 4,...Tray 1.</p> <p><b>Note:</b> Tray X Empty status clears whenever Tray X is removed. When Tray X is reinserted, it is examined and the appropriate status, if any, displays. Also note that Empty status is not displayed for the Envelope Feeder or Multipurpose Feeder.</p>
Tray X Low	<p>If any of the input trays are low, then “Tray X Low” displays where X designates which tray (1 through 5) displays. If multiple trays are low, they are prioritized in the following order: Tray 5,4,3,2,1.</p> <p><b>Note:</b> Tray X Low clears whenever Tray X goes empty, or Tray X is removed. When Tray X is reinserted, it is examined and the appropriate status, if any, displays.</p> <p><b>Note:</b> The printer cannot detect when the envelope feeder or multipurpose feeder are low.</p>

### User Line 2 Link Messages

If the printer is locked on a particular link, the link indication displays. If the printer is ready to process any link, no messages display. The link messages are listed in the following table.

User Message	Explanation
Parallel	Standard Parallel Port, if available.
Serial	Standard Serial Port, if available.
Serial X	Serial Port, where X=1,2,3, is attached to PCI connector X.
Network X	Network card X, X=1,2,3, is attached to PCI connector X.

## 4069-0XX

User Message	Explanation
LocalTalk X	LocalTalk Card X, X=1,2,3, is attached to PCI connector X.
Infrared	Standard Infrared port, if available.
Infrared X	Infrared Port X, X=1,2,3, is attached to PCI connector X.

## Check Device Connection Messages

The messages in the following table display when the printer loses communications with one of the following devices.

User Status Message	Explanation
Check Output Bin X Connection	Check Output Bin X (X=1,2,or 3).
Check Env Feeder Connection	Check Envelope Feeder Option Connection.
Check Tray X Connection	Check Tray X (X=1,2,3,4 or 5).
Check Duplex Connection	Check Duplex Option Connection.



## 4069-0XX

The messages in the following table can occur in two ways. The specified device could have been removed from the printer, for instance to clear a paper jam. Otherwise, the device can still be attached to the printer, but is experiencing a communications problem, not fully connected, or having a hardware failure.

- If the device is temporarily removed or not connected properly, then reattach it. When the option is recognized, the printer automatically clears the error and continues.
- If the option is experiencing a hardware problem, turn the printer off and back on. If the error occurs again, turn the printer off, remove the option and call for service.

User Status Message	Explanation
Turn Printer OFF to Enable Option	This message displays when a printer option, Input Tray, Output Bin or Envelope Feeder, has been attached while the printer is powered On. In order to use the option, the printer must first be powered off and back on again. Data loss results if print jobs are active when the printer is power cycled. If a print job is active, then remove the option and finish the job. The printer automatically clears the message once the option is removed. Once the job is complete, turn off the printer and attach the option again.
Insert Duplex Front Cover	This message displays when the duplex front access cover is not installed.
Close Duplex Rear Door	This message displays when the duplex rear door is open.

## **Power-On Self Test (POST)**

When you turn the printer On, it performs a Power-On Self Test. Check for correct POST functioning of the base printer by observing the following:

1. The LED comes on.
2. The operator panel displays one and a half row of pels, and then clears.
3. Diamonds scroll across the display, and then clear.
4. The operator panel displays one and a half row of pels, and then clears.
5. The top line of the operator panel displays one square block of pels that turn on one at a time until all sixteen blocks display and then they all turn off.
6. "Performing Self Test" appears on the display.
  - The 2000 sheet high capacity option elevator tray moves to the uppermost position if installed.
  - The duplex option is checked if installed.
  - The output expander option exit rollers turn if installed.
7. "Busy" appears on the display.
8. The fuser lamp turns on. The fuser takes longer to warm up from a cold start than a warm start.
9. The main fan turns on.
10. The main drive motor turns on.
11. The developer drive assembly drives the developer shaft in the toner cartridge.
12. The exit rollers turn.
13. The operator panel LED starts blinking.
14. Models 614 and 616 only - The auxiliary fan turns on and continues to run until the printer is powered off.
15. "Ready" appears on the display.

## Symptom Tables

### Symptom Table - Base Printer

Symptom	Action
Auxiliary Fan (414/616) fails to run or is noisy.	Go to the <a href="#">“Auxiliary Fan Service Check”</a> on page 2-46.
Dead Machine	Go to the <a href="#">“Dead Machine Service Check”</a> on page 2-32.
Operator Panel - One or more buttons do not work.	Go to the <a href="#">“Operator Panel Buttons Service Check”</a> on page 2-69.
Operator Panel - Display is blank. Printer sounds 5 beeps.	Go to the <a href="#">“Operator Panel Service Check”</a> on page 2-69.
Operator Panel - Display is blank. Printer does not sound 5 beeps.	Replace the operator panel assembly.
Operator Panel continuously displays all diamonds, sounds 5 beeps and does not complete POST.	Go to the <a href="#">“Operator Panel Service Check”</a> on page 2-69.
Paperfeed problems - Base printer or Integrated 250 Paper Tray	Go to the <a href="#">“Paper Feed Service Check”</a> on page 2-88.
Paper jams at exit of Redrive Assembly - No Duplex Option installed.	Go to the <a href="#">“Paper Feed Service Check”</a> on page 2-88.
Paper jams at exit of Redrive Assembly - Duplex Option installed	Go to the <a href="#">“Duplex Option Service Check”</a> on page 2-35.
Fuser Solenoid (414/616) fails to operate.	Go to the <a href="#">“Fuser Solenoid Service Check”</a> on page 2-50.
Print quality - Black page	Go to <a href="#">“Print Quality - All Black Page”</a> on page 2-92.
Print quality - Blank page	Go to <a href="#">“Print Quality - Blank Page”</a> on page 2-93.
Print quality - Light print	Go to <a href="#">“Print Quality - Light Print”</a> on page 2-101.

## 4069-0XX

Symptom	Action
Print quality - Background	Go to "Print Quality - Background" on page 2-96.
Print quality - Residual image	Go to "Print Quality - Residual Image" on page 2-100.
Print quality - Skew	Go to the "Paper Feed Service Check" on page 2-88.
Print quality - Banding	Go to "Print Quality - Banding" on page 2-99.
Print quality - Random marks	Go to "Print Quality - Random Marks" on page 2-94.
Print quality - Toner on backside of printed page	Go to "Print Quality - Toner on backside of printed page" on page 2-102.
Print quality - Vertical black bands on edge of copy	Go to "Print Quality - Black bands on outer edges of the page" on page 2-99.
Unable to clear a "32-Unsupported Print Cartridge" User Error Message	Go to "Smart Cartridge Service Check" on page 2-102

### Symptom Table - High Capacity Feeder Option (2000 Sheet)

Symptom	Action
The printer does not recognize the high capacity feeder option installed.	Go to the "High Capacity Feeder Input Tray Service Check" on page 2-55.
Paper feed problem with the high capacity feeder option.	Go to the "High Capacity Feeder Input Tray Service Check" on page 2-55.

**Symptom Table: Paper Tray Options**

Symptom	Action
Paper feed problem with 250 Sheet Paper Tray Option.	Go to the "Input Tray(s) Option Service Check" on page 2-52.
Paper feed problem with 500 Sheet Paper Tray Option.	Go to the "Input Tray(s) Option Service Check" on page 2-52.
Media fails to pass thru from the lower attached Paper Tray option to the next higher mounted option.	Go to the "Input Tray(s) Option Service Check" on page 2-52.

**Symptom Table - Duplex**

Symptom	Action
Paper feed problem with Duplex	Go to the "Duplex Option Service Check" on page 2-35.
Paper jams at Paper Removal Tray	Go to the "Duplex Option Service Check" on page 2-35.
Paper skews in the Duplex Option	Go to the "Duplex Option Service Check" on page 2-35.
Paper fails to pass from lower option thru the Duplex Option.	Go to the "Duplex Option Service Check" on page 2-35.

**Symptom Table - Envelope Feeder Option**

Symptom	Action
Envelopes do not feed from the envelope feeder.	Go to the "Envelope Feeder Option Service Check" on page 2-38.
Envelopes do not feed properly into base printer.	Go to the "Envelope Feeder Option Service Check" on page 2-38.

Symptom Table - Output Expander

Symptom	Action
Printer does not display Output Bin Full	Go to the <b>“Output Bin Sensor Standard Tray Service Check”</b> on page 2-73.
Paper does not feed all the way into the output tray.	Go to the <b>“Output Expander Service Check”</b> on page 2-74

---

## Service Checks

**Note:** Anytime the engine board is replaced, the Configuration ID must be reset in NVRAM on the new engine board. Go to **“Setting Configuration ID”** on page 3-21.

Review the following information before performing any service checks.

- Paperfeed Problems (especially paper jams): Go to **“Viewing the Error Log”** on page 3-8 and check the printer error log for indications of repetitive entries that help to isolate a problem to a particular area of the printer or option.
- Paperfeed Problems with error message: Use the **“Sub Error Codes For 9XX and 2XX Error Codes”** on page 2-7 to help diagnose the problem.
- Print Quality Problems: Go to **“Print Quality Test Pages”** on page 3-24 and print a test page to help diagnose problems before changing any settings or working on the printer.
- Use the resident diagnostics test provided to help isolate a problem before taking the machine apart or removing any options.

## Charge Roll Service Check

Service Tip: Close and evenly spaced repetitive marks 47.19 mm (1.86 inch) apart or spots on the page can be caused by a damaged or contaminated charge roll.

To remove the charge roll:

1. Wrap a piece of plain white paper around the charge roll to prevent contamination or damage.
2. Carefully remove the roll by pressing outward and to the right on the charge roll link arm and remove the charge roll from the right side charge roll bearing.
3. Remove the charge roll from the left side charge roll bearing and remove the roll from the printer. Leave the paper wrapped around the charge roll until it is reinstalled.

	FRU	Action
1	Charge Roll Assembly	Check the charge roll for correct installation, toner buildup, marks, cuts or other signs of contamination or damage. Replace as necessary.
2	Left Side Charge Roll Link	Check the left side charge roll link assembly for correct assembly operation. Check for damage to the arm or bearing assembly.

	FRU	Action
3	Right Side Charge Roll Link	<p>Check the right side charge roll link assembly for correct assembly operation. If incorrect, replace the charge roll link assembly with the charge roll link assembly kit. If correct, check the right charge roll link assembly bearing for signs of wear or contamination. Excessive contamination could cause intermittent charging of the charge roll. If incorrect, replace the link assembly. Check for continuity of the right link assembly from the bearing to the charge roll high voltage contact on the right side frame. If incorrect, replace the link assembly.</p> <p><b>Note:</b> The screw that attaches the charge roll lead to the contact must be secure.</p>



## Cover Open Switch/Cable Service Check

	FRU	Action
1	Toner Cartridge	Check the toner cartridge to make sure it is correctly installed and that the right and left cartridge tracks are not loose or broken. Check to make sure the cover open switch activation tab on the toner cartridge is not broken and that the tab correctly activates the cover open switch spring.
2	Cover Open Switch/Cable Assembly	<p>Check the cover open switch for proper mechanical operation. If incorrect, repair as necessary. Disconnect the cover open switch cable from J4 at the engine board and measure the voltage at J4-3. It measures approximately +5 V dc. If the voltage is incorrect, replace the engine board. If the voltage is correct, check the voltage at J4-1. If the voltage measures greater than +1.0 V dc, replace the engine board. If the voltage is correct, check the continuity between J4-1 and J4-3 on the cable. If no change in continuity occurs as the switch is activated, replace the cover open switch/cable assembly. If the continuity changes as the switch is activated, replace the engine board.</p> <p><b>Note:</b> It is easier to check the voltages on J4 with the controller board removed.</p>

# Dead Machine Service Check

**Note:** If a high capacity input tray is installed, remove the option and check the base printer for correct operation. If the base printer operates correctly, go to **“High Capacity Feeder Input Tray Service Check” on page 2-55**. If the base printer continues to not operate correctly, remove any other attached paper handling options. Observe all necessary ESD precautions when removing and handling the controller board, engine board or any of the installed option cards or assemblies.

**Service Tip:** When removing the LVPS from the printer observe the following:

1. The LVPS uses a self docking connector that mates with another connector mounted on the left side frame assembly. Some force may be required to pull the LVPS loose from the connector.
2. Gently remove the LVPS supply using caution not to damage the printed circuit board. Pull the LVPS out far enough to reach the fuser lamp cable.
3. The fuser lamp cable uses a locking type of connector system. Unlock the fuser lamp cable connector, disconnect the cable and remove the LVPS from the printer.

**Note:** If the LVPS is blowing fuses, remove the LVPS from the printer. Check the metal LVPS shield for signs of damage that causes the shield to touch components on the LVPS board assembly.

	FRU	Action
1	Line Voltage	Check the AC line voltage. If the line voltage is incorrect, inform the customer.
2	AC Line Cord	Check the line cord for any signs of damage. If correct, check the continuity of the line cord and replace if necessary.

	FRU	Action
3	+5 V dc at any Option Connector	Check for +5 V dc on any of the option connectors. The easiest to access is the envelope feeder connector located behind the lower front door. If +5 V dc is present at any of the connectors, go to step 9. If +5 V dc is not present, go to step 4.
4	+5 V dc at the controller board test point	Check for +5 V dc at the +5 V dc test pad located on the controller board. If correct, go to step 9.
5	+5 V dc at the engine board Test Point	Check for +5 V dc at the +5 V dc test point on the engine board. If correct, replace the engine board. If incorrect, go to step 6.
6	LVPS Fuse F1	Remove the LVPS from the printer and check fuse F1. Replace the fuse if the fuse is blown.
7	LVPS Fuse F1 - Continues to blow after LVPS installed in the printer.	<p>Replace fuse F1 if necessary. Turn the LVPS on/off switch Off and connect the AC line cord and turn the LVPS On.</p> <p><b>CAUTION:</b> Before checking fuse F1 turn the LVPS Off and disconnect the AC line cord. Check fuse F1. If the fuse is blown, replace the LVPS.</p>
8	LVPS	<p>Remove the LVPS from the machine.</p> <p><b>CAUTION:</b> Before making any measurements on the LVPS output connector, observe all necessary safety precautions before applying AC power. Measure the voltage on LVPS output connector CN3. The voltage measures +5 V dc. If incorrect, replace the LVPS.</p>

	FRU	Action
9	Engine Board	<p>Turn the printer off and disconnect all the cables from the engine board. Check for +5 V dc at the engine board test point. If incorrect, replace the FRUs in the following order:</p> <p>engine board</p> <p>interconnect board</p> <p>If correct, turn the printer off and reconnect one cable at a time until you find the defective assembly.</p> <p>Service Tip: A short or low resistance load that is attached to the engine board can cause the LVPS to overcurrent and shut the +5 V dc supply down to 0 V dc.</p> <p>Service Tip: Check the engine board for burn marks or other damage, especially R20,R21, R22 and R23 located next to the upper left engine board mounting screw. If this screw is overtightened it might deform the engine board shield and cause it to short out these resistors.</p>

## Duplex Option Service Check

The printer does not recognize the Duplex Option is attached. The printer does not recognize tray options below the duplex option are installed.

	FRU	Action
1	Fuse F1 on Duplex Option System Board	If fuse F1 is blown, replace the fuse. If fuse F1 continues to blow, check the stepper motor for a short between the motor case and pins J3-1 through J3-4. If no problem is found, check the D.C. servo motor pins J1-1 and J1-2 to the motor housing for a short. If a short is found, replace the motor assembly. If no short is found, replace the system board.
2	Autoconnect Cables/ Connectors	Check the autoconnect cables for damage to the cables or the pins in the connectors. If damaged, replace the cable(s). If no damage is found, check to make sure the cables are connected to J9, J10, J11 and J12 on the duplex system board. If no problem is found, replace the duplex system board.

**4069-0XX****POST fails, 230 Paper Jam, Check Duplex message displays.**

	<b>FRU</b>	<b>Action</b>
1	Duplex D.C. Servo Drive Motor	<p>Check the D.C. servo motor cables for signs of cuts or other damage. Check the D.C. servo motor sensor cable connector for pin damage. If no problem is found, replace the FRUs in the following order:</p> <p>D.C. motor assembly</p> <p>duplex option system board</p>
2	Input Sensor, Input Sensor Flag	<p>Run the Duplex Sensor Test from the diagnostics menu. If the test fails, check the input sensor cable at J5 on the system board for correct installation. If no problem is found, replace the FRUs in the following order:</p> <p>input sensor assembly</p> <p>duplex option system board</p>
3	Paper Exit Sensor and Flag	<p>Check the duplex exit sensor for correct installation and free movement of the sensor flag. Check to make sure the sensor cable is connected to J8 on the system board. If no problem is found, replace the FRUs in the following order:</p> <p>exit sensor assembly</p> <p>duplex option system board</p>

**230 Paper Jam - Check Duplex message displays. The page is not duplexed and only exits half way out of the redrive.**

	FRU	Action
1	Duplex Stepper Motor	Check the stepper motor cable for cuts or pinched wiring. Check the routing of the motor leads along the left side of the bottom tray. Check for correct installation of the motor cable connector at J3 on the system board. Check for any shorts between each pin of the motor cable and the motor housing. If shorts are found, replace the motor. Check the resistance of the stepper motor between J3-1 (Stpmtr A-) to J3-2 (Stpmtr A+). The resistance measures approximately 10 ohms. The resistance between J3-3 (Stpmtr B-) to J3-4 (Stpmtr B+) measures approximately 10 ohms. If the resistance is incorrect, replace the stepper motor. Check for shorts between windings on pins J3-1 to J3-2 and pins J3-3 to J3-4. If a short is found, replace the stepper motor assembly. If no short is found, replace the duplex system board.

## Envelope Feeder Option Service Check

Service Tip: Check the envelope feeder paper path for any debris, pieces of envelope and so on. If any other options are installed make sure they are operating normally. If only the envelope feeder is failing to operate correctly, continue with this service check, otherwise go to the Interconnect Card Service Check.

Service Tip: The envelope feeder option receives its +5 V dc operating voltage from the +24 V dc bulk at J1-7. If +24 V dc is not present at J1-7, tray 1 is the only tray option that is recognized.

**Note:** If a 260 Paper Jam Check Envelope message displays, check the **“Sub Error Codes For 9XX and 2XX Error Codes”** on page 2-7.

**Printer does not recognize the envelope feeder as an attached input option.**

	FRU	Action
1	Envelope Feeder	Check to make sure the envelope feeder is correctly installed and mated to the autoconnect at the front of the printer.
2	Front Autoconnect on Printer	Check the connector for signs of damage to the connector or contacts. If you find damage, replace the damaged cable/connector assembly. Remove the envelope feeder option and check the voltages at the autoconnect on the front of the printer. If incorrect, check the interconnect board. If correct, reinstall the envelope option and continue with step 3.



	FRU	Action
3	Autoconnect on the Envelope Option	<p>Check the connector for any signs of damage to the connector or contacts. If you find damage, replace the damaged cable/connector assembly. Disconnect the autoconnect cable at J1 on the envelope system board and measure the following voltages:</p> <p>J1-3 measures +5 V dc  J1-5 measures +5 V dc  J1-7 measures +24 V dc</p> <p>If any of the voltages are incorrect, replace the autoconnect cable/connector. If the voltages are correct, replace the envelope system board.</p>

**4069-0XX**

**Operator panel displays 260 Paper Jam immediately when envelope feed is requested - POST incomplete.**

	FRU	Action
1	Pass through Sensor	<p>Check for any debris, pieces of envelope and so on over the pass thru sensor. Check for correct installation of the pass thru sensor flag. Make sure the sensor cable is attached to the envelope system board. Perform an envelope feeder sensor test to check both the sensor and sensor flag.</p> <p><b>Note:</b> It may be necessary to use a small tool to actuate the sensor flag because it is located under the front cover. Be careful not to damage the flag.</p> <p>If the test fails, check the flag for any signs of damage or binds. If incorrect, replace the flag. If the flag is operating correctly, check the voltage at J3-3. The voltage measures approximately +5 V dc. If incorrect, replace the envelope system board. If correct, check the voltage at J3-2. The voltage changes from 0 to +5 V dc when the flag is moved in and out of the sensor. If incorrect, replace the sensor assembly. If this does not fix the problem, replace the envelope system board.</p>

## 4069-0XX

**Operator panel displays 260 Paper Jam after attempted feed but before envelopes are put in the hopper OR the operator panel continues to display "Load Envelopes" after envelopes are placed in the hopper.**

Service Tip: The kick rolls rotate during the attempted feed cycles.

	FRU	Action
1	Envelope Out Hopper Sensor Flag	Check the envelope out sensor flag for damage, correct installation and operation. If incorrect, repair or replace the flag.
2	Envelope Out Hopper Input Sensor	Check the sensor to make sure it is installed correctly and the sensor cable is properly connected to the envelope system board. If correct, perform the Envelope Feed Sensor Test to check both the sensor and flag. If the test fails, remove any envelopes in the hopper, turn the printer off and disconnect J3 from the system board. Turn the printer on and check the voltage at J3-3 on the system board. The voltage measures approximately +5 V dc. If incorrect, replace the envelope system board. If correct, replace the input sensor assembly.

## 4069-0XX

### 990 Service Error, Envelopes fail to feed from the hopper.

	FRU	Action
1	D.C. Feed Motor Assembly	Check the motor and motor cable for any signs of loose wires or poor connections. Check to make sure the motor cable is connected to the envelope system board.
2	Envelope Feeder System Board	Check the voltage on J4-1. The voltage measures approximately +24 V dc. If incorrect, replace the envelope system board, if correct, measure the voltage at J4-6. The voltage measures approximately +5 V dc. If incorrect, disconnect J4 and measure the voltage again. If incorrect, replace the envelope feeder system board. If correct, replace the D.C. motor assembly.

### 260 Paper Jam displays, unable to clear and envelopes fail to feed from the hopper. Kick rolls ARE NOT rotating.

	FRU	Action
1	Main Drive Belt	Check the belt for correct installation and for signs of damage. Replace as necessary.
2	Gears	Check all the gears for correct installation and for signs of damage. Repair or replace parts as necessary.
3	Clutch Latch Assembly	Check the clutch latch assembly to make sure it moves freely.
4	Master Cam Gear Master/Kick Gear	Check the master cam gear and master/kick gear to make sure they rotate together. If not, then the tenons on the master kick gear may be sheared off. If incorrect, replace the master kick gear.

## 4069-0XX

**260 Paper Jam displays, unable to clear and envelopes fail to feed from the hopper. Kick rolls ARE rotating.**

Check the deflector gap adjustment before continuing this service check.

	FRU	Action
1	Deflector Gap Adjustment	Check the deflector gap adjustment. The adjustment may be too narrow.
2	Weight Assembly	Check the weight assembly to make sure it moves up and down freely without any binds. Also check to make sure the weight assembly rests on all the rear kick rollers when the hopper is empty. Replace the weight assembly if it is damaged or does not operate properly.
3	Envelope Edge Guide	Check the envelope edge guide to make sure it is not warped or set too close to the envelopes in the hopper. Replace the edge guide if it is damaged or does not operate properly.

## 4069-0XX

**260 Paper Jam displays, envelope stops in feeder paper path.**

	FRU	Action
1	Kick Rolls/Feed Rolls/Drive Rolls	Check all the rolls for any signs of oil, grease or other contamination. If you find a problem, clean or replace parts as required.
2	Deflector Gap Adjustment	Check the deflector gap adjustment. The adjustment may be too narrow.

**Envelope Feeder multifeeds or may not display a 260 Paper Jam message.**

	FRU	Action
1	Envelopes	Check the envelopes being used in the feeder. Check for signs of the envelopes being stuck together or signs of glue. Check to make sure the flaps are not interleaved.
2	Deflector	Check the deflector gap adjustment. The adjustment may be too wide.
3	Restraint Roll Bias Spring	Check for a missing, broken or incorrectly installed restraint roll bias spring. If incorrect, reinstall or replace the spring.

**260 Paper Jam displays. An envelope stopped in the paper path of the feeder and an envelope also stopped in the base printer paper path.**

	FRU	Action
1	Latch Lever	Check to make sure the tip of the latch lever is centered in the opening in the floor of the paper path. The latch lever may not be detented on the latch.

## Erase Lamp Service Check

Error code 928 may be displayed when the printer detects that the erase lamp assembly, cable or engine board is defective.

**Note:** If the erase lamp assembly is defective, both the erase lamp and lens are replaced as a kit.

Make the following checks when a 928 service error displays.

	FRU	Action
1	Cable, Front Harness	Check the connection of the front harness to connector J10 on the engine board for correct installation. If incorrect, repair as necessary. Check the front harness to erase lamp assembly for correct installation. If incorrect, repair as necessary.
2	Engine Board	Remove the controller board and toner cartridge from the machine. Ground pin J10-15. The erase lamps turn on. The lamps can be observed through the front of the machine with the cover open and print cartridge removed. If the lamps do not turn on, measure the voltage on J10-14. The voltage reads approximately +24 V dc. If incorrect, replace the engine board. If correct, check the voltage at J10-15. The voltage reads between +15 V dc to +20 V dc. If incorrect, check the continuity of the erase lamp lines in the main harness. If incorrect, replace the cable harness. If correct, replace the erase lamp assembly.

# Fan Service Check

## Auxiliary Fan Service Check

The auxiliary fan is in models 414 and 616.

### Fan does not run or is noisy.

	FRU	Action
1	Fan Assembly	Check the fan for proper installation and for excessive noise. If incorrect, replace the fan and cable assembly.
2	Engine Board	<p>Check to make sure the auxiliary fan cable is seated on connector J7 on the engine board. If correct, check for +24 V dc on J7-1 on the engine board. If incorrect, replace the engine board. If correct, replace the fan assembly.</p> <p><b>Note:</b> When the printer is in warm-up the voltage at J7-1 measures approximately +12 V dc. When the printer is running, the voltage measures approximately +24 V dc.</p>

## Main Fan Service Check

Check the cable connections at J1 on the engine board and at the main fan assembly. The main fan runs continuously when the printer is powered on unless the printer is in the Power Saver mode.

	FRU	Action
1	Main Fan	Manually spin the fan and check that it rotates freely. Check the cable connection to the engine board, J1 for correct installation.
2	Main Fan to Engine Board Cable	Check the continuity of the cable. If incorrect, replace the cable.



	FRU	Action
3	Error Code 927 (Fan runs)	Check the voltage at J1-1 on the engine board. The voltage measures +5 V dc (static) 0 V dc (fan running). If incorrect, replace the main fan. If this does not fix the problem, replace the engine board.
4	Error Code 927 (Fan not running)	Check the voltage at J1-3 on the engine board. The voltages are as follows:  +22 V dc to +24 V dc (printer and fan running)  +12 V dc to +15 V dc (printer not running - fan running about half speed).  If incorrect, replace the engine board. If this does not fix the problem, replace the main fan.

## Fuser Service Check

### Cold Fuser Service Check

Error codes 920, 921, and 922 may display for a cold fuser failure. A 920 error caused by low line voltage can sometimes be cleared by turning the machine off and then on again. A 925 service error indicates the wrong fuser lamp is installed in the printer and does not match the one stored in the printer code.

**Note:** Make sure the fuser is correctly installed before proceeding with this service check. The fuser must be firmly seated in the two rear connectors. Both the right and left lock down screws must be tight.

Service Tip: Set the Fuser Temperature to NORMAL before starting this service check.

	FRU	Action
1	Fuser Lamp (Incorrect Lamp/925 Service Error)	Install the correct voltage and wattage lamp or fuser assembly.
2	Fuser Lamp	Remove the controller board. Run the Diagnostic Print Test and observe the lamp through the left side frame. If the lamp doesn't come on, unplug the printer and check the continuity between the two pins on the fuser lamp cable going to the fuser assembly. If you do not measure continuity, remove the fuser assembly and check the continuity of the lamp. If incorrect, replace the lamp. If correct, replace the fuser cover assembly.
3	LVPS LVPS to Fuser Auto Docking Connector Fuser AC Cable	Turn the printer off. Remove the fuser assembly. Turn the printer power on. Measure across the AC fuser cable pins for line voltage with the cable connected. If incorrect, turn the printer off and disconnect the power cord. Check the continuity of the LVPS to fuser AC cable. If incorrect, replace the cable. If correct, replace the LVPS.
4	Fuser Top Cover Assembly (Thermal Fuse/Thermistor Assembly)	Disconnect the thermistor cable from the fuser board at J2. The resistance is as follows:  HOT - J2-1 - J2-2 = 2.5K ohms  COLD = 150K ohms to 260K ohms

## 4069-0XX

### Hot Fuser Service Check

Error codes 923 and 924 may display for a hot fuser failure.

**CAUTION:** The fuser may be hot, use caution before removing or servicing.

	FRU	Action
1	Fuser Cover Assembly (Assembly includes Thermistor and Thermal Fuses.)	<p>Check for damage to the thermistor assembly. Check the resistance of the thermistor:</p> <p>HOT - J2-1 to J2-2 = 2.5K ohms</p> <p>COLD =150K ohms to 260K ohms</p> <p>Check the continuity from each pin of J2 to ground. If there is continuity, replace the fuser cover assembly</p>
2	Engine Board	<p>Error code 924 indicates the engine board detects an open circuit in the thermistor circuit for the fuser assembly. The voltage on J2-6 on the engine board measures approximately +5 V dc. If incorrect, replace the engine board. If correct, check the continuity of the DC fuser cable (fuser board to auto docking connector) in the fuser assembly and the DC fuser cable (engine board to auto docking connector) in the printer. If there is no continuity, replace the cable. If there is continuity, check the voltage on J2-2 on the fuser control board. It measures approximately +5 V dc. If incorrect, replace the fuser control board.</p>
3	Fuser Hot Roll Backup Roll Bearings	<p>Examine the fuser assembly for signs of overheating or damage. Check the hot roll and backup roll for signs of excessive toner, label glue, labels or other contaminants. If any are found, repair as necessary or replace the fuser assembly.</p>

Fuser Solenoid Service Check

The fuser solenoid is in models 614 and 616.

Service Tip: Try changing the envelope enhance level setting. A different setting may correct the problem.

**Note:** Check the fuser envelope conditioner solenoid adjustment as described in the adjustment section “Fuser Solenoid Adjustment” on page 4-3.

	FRU	Action
1	Fuser Envelope Conditioner Solenoid	The operation of the fuser solenoid can be observed by removing the redrive assembly. Check for proper mechanical operation of the solenoid and associated hardware, link and so on. If correct, check the resistance of the solenoid between J4-1 and J4-2. The resistance measures between 5 ohms and 10 ohms. If incorrect, replace the solenoid assembly.
2	Fuser Control Board	The solenoid receives power from the engine board. The fuser control board receives +42Vdc from the LVPS via the interconnect board. Check for approximately +42 V dc at the +42 V dc test point on the fuser control board. If the voltage is correct, replace the fuser control board.

	FRU	Action
3	LVPS Interconnect Board	If the +42 V dc test point does not measure approximately +42 V dc, check the voltage at CN3-18 on the LVPS. The voltage measures approximately +42 V dc. If the voltage is correct, replace the interconnect board assembly. If the voltage is incorrect, replace the LVPS.
4	Fuser DC Cable (Engine Board to Fuser Board Cable) Engine Board	Check for continuity of the DC fuser cable that is attached between J2 on the engine board and J1 on the fuser control board. If the cable does not measure continuity, replace the cable. If the cable measures continuity, replace the engine board.

## Input Sensor Service Check

Service Tip: Run the Base Sensor Test. Check the input sensor for proper operation. The display changes from open to closed as the sensor flag is manually moved in and out of the sensor.

Service Tip: Run a Diagnostic Print Test in the continuous mode with the controller board removed. A defective input sensor or circuit causes the first copy to exit only partially through the fuser assembly.

	FRU	Action
1	Input Sensor Flag	Check the input sensor flag for damage and proper operation. If a problem is found, repair as necessary.
2	Engine Board	Check for approximately +5 V dc at J10-10 on the engine board. If incorrect, replace the engine board.
3	Input Sensor Cable	Check the continuity of the input sensor cable. If incorrect, replace the cable. If correct, replace the input sensor assembly.

Input Tray(s) Option Service Check

250 Sheet and 500 Sheet Trays

Service Tip: Try all the other input paper sources to make sure they are properly feeding paper.

For 990 Error Code- Service Tray X, X= displays the number of the tray that has a problem or needs service.

	FRU	Action
1	Tray X option System Board or Compensator Assembly or Autoconnect Cable	<p>Check the autoconnect cables and connectors for any signs of damage. Replace if necessary. Check the cables for continuity. If incorrect, replace the compensator assembly cable. If the cables, connectors and connections are good, replace the FRUs in the following order:</p> <p>autocompensator assembly option</p> <p>system board</p>

**4069-0XX**

**24X Paper Jam message displays, Paper jammed over the Pass Thru Sensor. (The printer displays the value of X for the paper tray where the error occurs. Example: 241 is a Paper Jam Tray 1)**

	<b>FRU</b>	<b>Action</b>
1	Pass Thru Sensor and Flag Assembly	The tray x option system board did not detect a piece of paper actuating the pass thru sensor. Remove any jammed sheets of paper from the printer and check the pass thru sensor and flag for proper operation by running the appropriate Tray Sensor Test from the diagnostics menu. If the test fails, check the sensor for correct installation and the flag for proper operation. Also check the sensor cable to make sure it is correctly connected to the option system board. If incorrect, replace the tray x option pass thru sensor assembly.
2	Power Takeoff Shaft and Spring, Bevel Gear, Feedroll Gear, Drive Roll Assembly, Wear Plate, Drive Shaft Bearings and Skewed Backup Roller	Check these parts for signs of broken or damaged parts, contamination on the drive rollers or wear plate and wear or damage to the drive shaft bearings. Check the drive roll assembly and skewed backup roller for signs of wear, slick spots, material buildup, and oil or grease on the rollers. Also check for proper operation of the paper aligning assembly. Repair or replace parts as necessary.

# 4069-0XX

Tray X Low message displays when Tray X is full or has adequate paper in the tray.

	FRU	Action
1	Paper Low Sensor Assembly Paper Low Sensor Flag Tray X Option System Board	<p>Run the Tray X Sensor Test and check the sensor for proper operation. If incorrect, check the following:</p> <p>Paper low sensor flag for smooth and correct operation.</p> <p>Paper low sensor for correct installation on the autocompensator housing.</p> <p>Paper low sensor cable for signs of cuts, pinched wiring or other damage especially at connector J5 on the system board.</p> <p>If no problem is found, replace the paper low sensor assembly. If this does not correct the problem, replace the option system board.</p>

Tray X Empty message displays when Tray X has paper in the tray.

	FRU	Action
1	Paper Out Sensor Flag	Check the paper out sensor flag for correct operation and installation. If correct, replace the option system board. (The paper out sensor is mounted on the system board).
2	Paper Out Sensor (On Option System Board)	



## 4069-0XX

**Printer does not recognize Tray X is installed.**

	FRU	Action
1	Autoconnect Cables Tray X System Board	Check the autoconnect from the printer or option above tray x. Check for signs of cuts, pinched wiring or damage to the contacts in the connector. Check the autoconnect cable(s) for correct installation at the tray x system board. If correct, check the continuity of the autoconnect cable(s). If correct, replace the tray x system board. If incorrect, replace the cable.

**Paper from Tray X does not reach the Pass Thru Sensor.**

Service Tip: Check the media in tray x to make sure it is within specifications. Some types of labels, foil material and slick papers can cause misfeeds and slippage of the rollers.

	FRU	Action
1	Autocompensator Assembly	Check the autocompensator pick arm rollers for any sign of glazing, toner or other buildup. Clean or replace as necessary.

## High Capacity Feeder Input Tray Service Check

**Note:** Voltage measurements in the high capacity feeder input tray service checks must be made with the high capacity feeder attached to the base printer to obtain accurate results.

Service Tip: Be sure the paper size switch is set to the correct paper size setting and the rear paper guides are in the correct locations for the size of paper installed in the high capacity feeder tray.

Service Tip: Check the other paper sources to be sure they are operating correctly.

4069-0XX

The base printer indicates a dead machine condition when the high capacity input tray is installed.

	FRU	Action
1	AC Line Cord AC Jumper (HCIT to Printer) AC input and Output Receptacles AC Wiring Harness	<p>If the base printer works normally using the AC line cord from the AC wall outlet and does not work when using the AC jumper from the HCIT, check the AC jumper cord. If defective, replace the cord. If not defective, check the AC input and output receptacles and wiring harness in the HCIT. Repair or replace the receptacles or AC wiring harness as required.</p> <p><b>NOTE:</b> Make sure the ground wire is installed correctly from the AC wiring harness to the frame of the HCIT and the nut and lockwasher are tightened down.</p>

**4069-0XX**

**The base printer does not recognize that the high capacity input tray is installed.**

	<b>FRU</b>	<b>Action</b>
1	High Capacity Feeder Autoconnect Mechanical Check	Check the high capacity feeder input tray to make sure it is mounted correctly and is not pushed down into the frame assembly or damaged. Be sure the high capacity feeder input tray autoconnect is properly connected to the high capacity feeder tray option board assembly.
2	Base Printer or option mounted above	Check the option or base printer autoconnect for signs of damage. Repair the high capacity option autoconnect as necessary.
3	LVPS Option System Board	Check the voltages at J11-2 and J11-4. The voltage measures +24 V dc, If the voltage is correct, replace the high capacity system board assembly. If the voltage is incorrect, check the continuity of the AC input cable to the LVPS. If correct, replace the LVPS assembly. If incorrect, replace the AC cable to the input of the LVPS.

	<b>FRU</b>	<b>Action</b>
4	High Capacity Feeder Option Control Board	<p>Check the voltage on J8-1 (green). The voltage measures +24 V dc. If incorrect, check the autoconnect system for any problems. +24 V dc must come from the base printer through the autoconnect system to the high capacity input for the high capacity feeder to be recognized. If the voltage is correct, check the voltages at J11-3(red) and J11-4(red). The voltages measure +24 V dc. If correct, replace the high capacity feeder option system board. If incorrect, disconnect J8 from the system board and measure the voltages again. If incorrect, check the LVPS cable and the A.C. internal wiring from the input appliance receptacle. If incorrect, replace as necessary. If correct, replace the LVPS. If the voltages are correct, check the stepper motor for shorts from the motor housing to each pin on the motor connector. If you find a short between any pin and the motor housing, replace the motor assembly. If no shorts are found, replace the high capacity feeder option control board.</p> <p>Check the voltage at J9-1 (light blue). The voltage measures approximately +24 V dc. If incorrect, disconnect the cable at J9 and check the voltage again. If the voltage continues to be incorrect, replace the high capacity feeder option system board. If the voltage measures correctly, check the cable. If the cable is damaged, replace as necessary. If no problem is found with the cable, replace the high capacity feeder option control board.</p>

**4069-0XX**

**24X Paper Jam message displays, Paper jammed over the Pass Thru Sensor. (X=The printer displays the value of X for the paper tray where the error occurs. Example: 242 is a Paper Jam Tray 2)**

	<b>FRU</b>	<b>Action</b>
1	Pass Thru Sensor and Flag Assembly	The tray x option system board did not detect a piece of paper actuating the pass thru sensor. Remove any jammed sheets of paper from the printer and check the pass thru sensor and flag for proper operation by running the appropriate Tray Sensor Test from the diagnostics menu. If the test fails, check the sensor for correct installation and the flag for proper operation. Also check the sensor cable to make sure it is correctly connected to the option system board. If incorrect, replace the tray x option pass thru sensor assembly.
2	Power Takeoff Shaft and Spring, Bevel Gear, Feedroll Gear, Drive Roll Assembly, Wear Plate, Drive Shaft Bearings and Skewed Backup Roller	Check these parts for signs of broken or damaged parts, contamination on the drive rollers or wear plate and wear or damage to the drive shaft bearings. Check the drive roll assembly and skewed backup roller for signs of wear, slick spots, material buildup, and oil or grease on the rollers. Also check for proper operation of the paper aligning assembly. Repair or replace parts as necessary.

## 4069-0XX

**Tray X Paper Low Message displays when Tray X is full or has adequate Paper in the tray.**

	FRU	Action
1	Paper Low Switch Paper Low Switch Cable High Capacity Feeder Input System Board	Run the sensor diagnostics for tray X (X=the number that represents the high capacity input tray). If the test fails, disconnect the paper low switch cable from J3 on the high capacity system board. Short pins 1 and 2 together while observing the sensor test on the display. If the display does not change, replace the high capacity feeder system board. If the display changes check the continuity of the switch. If incorrect, replace the switch. If correct, replace the switch cable.

**Tray X empty message displays when there is paper in the high capacity feeder input tray.**

	FRU	Action
1	Paper Out Sensor Flag	Check the paper out sensor flag for correct operation and installation. If correct, replace the high capacity feeder system board. (The paper out sensor is mounted on the high capacity feeder system board).
2	Paper Out Sensor (On Option System Board)	

## 4069-0XX

**The elevator tray fails to stop at the correct position and continues to drive into the bottom frame.**

	FRU	Action
1	Lower Limit Switch Lower Limit Switch Cable	Check continuity of the lower limit switch. If incorrect, replace the switch. If correct, check the switch cable. If incorrect, replace the cable. If correct, replace the high capacity feeder option control board.
2	High Capacity Feeder Control Board	Disconnect the lower limit switch cable and check the voltage at J2-1 (orange). The voltage measures approximately +5 V dc. If incorrect, replace the high capacity feeder option control board.

**The elevator tray down button does not operate. The tray moves to the upper position.**

Service Tip: Open the high capacity feeder option front door and check the black rubber bumper attached to the door switch spring. Be sure the rubber button is centered and not touching the sides of the hole or the switch will not function properly.

	FRU	Action
1	Lower Limit Switch Lower Limit Switch Cable High Capacity Feeder Control Board	Check the lower limit switch to make sure it is not closed (normally open). If incorrect, replace the switch. Check the lower limit switch cable for a short between pins 1 and 2. If incorrect, replace the cable. If correct, replace the high capacity feeder option control board.

**4069-0XX**

**Paper from the high capacity feeder input tray does not reach the pass thru sensor.**

Service Tip: Check to be sure the paper in tray is within specifications.

	<b>FRU</b>	<b>Action</b>
1	Autocompensator Assembly	Check the autocompensator pick arm rollers for sign of glazing, toner or other buildup. Replace as necessary.
2	Wear Strips	Check the wear strips for glazing or contamination. Replace as required. It is advisable to replace all four wear strips at the same time.



## 4069-0XX

**The elevator tray does not move up or down. The printer recognizes that the option is installed.**

	FRU	Action
1	DC Drive Motor High Capacity Feeder Option System Board	<p>Be sure the motor cable is correctly installed at J1 on the board. Check the cables, damaged or loose wires. Disconnect the motor. Check for a short between each pin and the motor housing. If a problem is found, replace the motor assembly. If no problem is found, measure the resistance between the following pins on the motor cable connector:</p> <p>Pins 1 (brown) and pin 2 (Yellow)</p> <p>The resistance measures between approximately 7.5 and 10.5 ohms. If incorrect, replace the motor assembly. If correct, replace the high capacity feeder option system board.</p>

**4069-0XX**

**The elevator moves in one direction only.**

	<b>FRU</b>	<b>Action</b>
1	DC Drive Motor Assembly High Capacity Feeder System Board	<p>Check the voltages at J1 on the high capacity system board. The voltages measure as follows:</p> <p>Static (Motor Not Running) J1-1 (Brown): approximately 0 V dc J1-2 (yellow): approximately 0V dc</p> <p>Motor Running Forward J1-1 (Brown): Approximately 0 V dc J1-2 (Yellow): Approximately +24V dc</p> <p>Motor Running Reverse J1-1 (Brown): Approximately +24 V dc J1-2 (Yellow): Approximately 0 V dc</p> <p>If any of the voltages are incorrect, disconnect the motor and measure the resistance between J-1 and J-2. The resistance measures between 7.5 and 10.5 ohms. If incorrect replace the motor. If correct, replace the system board.</p>

**4069-0XX****Paper size switch not selecting paper size that is selected.**

	FRU	Action
1	Paper Size Switch High Capacity Feeder Option Control Board	<p>Check for continuity between the common pin (J5-1) and the pin of the paper size selected.</p> <p>J5-1 (Black): Common Lead  J5-2 (Blue) B5  J5-3 (Green) Executive  J5-4 (Yellow) A4  J5-5 (Orange) Letter  J5-6 (Red) Legal  J5-7 (Brown) A5</p> <p>If any position does not measure continuity when selected, replace the paper size switch assembly. If the switch assembly is operating correctly, replace the high capacity feeder option control board.</p>

**24X Paper Jam Check Tray X Message displays when Tray X is empty. No Tray X Message displays.**

	FRU	Action
1	High Capacity Feeder Option Control Board	<p>Check the voltages on the board at J4-1 (red) and J4-3 (blue). The voltages measure approximately +5 V dc. If incorrect, disconnect J4 from the board and measure the voltages again. If incorrect, replace the high capacity feeder option control board.</p>
2	Elevator Top Optical Sensor Cable Elevator Top Optical Sensor	<p>Check the continuity of the sensor cable. If incorrect, replace the cable. If correct, replace the top optical sensor assembly.</p>

## 4069-0XX

**Tray X Empty message displays. Tray does not respond to loading paper. No response from the front door switch.**

	FRU	Action
1	High Capacity Feeder Option Control Board	Check the voltage on the board at J4-2 (green). The voltage measures approximately +5 V dc. If incorrect, disconnect the cable at J4 and check the voltage again. If incorrect, replace the high capacity feeder option control board.
2	Elevator Top Optical Sensor Cable Elevator Top Optical Sensor	Check the continuity of the sensor cable. If incorrect, replace the cable. If correct, replace the top optical sensor assembly.

**Tray X Paper Low Message displays when the high capacity feeder input tray is full or has adequate paper in the tray.**

	FRU	Action
1	Paper Low Switch Paper Low Switch Cable High Capacity Feeder Option Control Board	Run the sensor diagnostics for tray X (X=the number that represents the high capacity input tray). If the test fails, check the voltage at J3-1 (grey). The voltage measures approximately +24 V dc. If incorrect, disconnect the paper low switch cable from J3 and measure the voltage again on J3-1. If incorrect, replace the high capacity feeder option control board. If correct, check the cable for a short between pins 1 and 2 on the cable. If incorrect, replace the cable. If correct, check the switch for a bent or deformed actuator lever or defective switch. If incorrect, replace the switch.

**Excessive Noise or Vibration**

	<b>FRU</b>	<b>Action</b>
1	DC Motor Assembly	Check to make sure all the motor plate mounting screws are tight.
2	Idler Pulley DC Motor Assembly	Check to make sure the idler pulley is not binding on the pulley shaft. Check the pulley for any signs of wear. Check the idler pulley shaft on the motor mounting plate for any signs of damage or contamination.
3	Drive Pulley	Check the drive pulley for any signs of wear, binds or damage to the pulley or pulley shaft. Make sure the pulley turns freely on the pulley shaft.
4	Motor Drive Belt Tray Drive Belt	Check the DC motor drive belt for any signs of damage. Check to make sure the belt is tracking correctly on the drive pulley, idler pulley and motor pulley. Check the tray drive belt for any signs of damage. Check to make sure the belt is tracking correctly on the lower section of the drive pulley and lead screw pulleys.

## Main Drive Service Check

Service Tip: Excessive gear or main drive assembly noise is usually caused by a defective motor assembly or engine board.

Service Tip: If there are equally spaced horizontal lines across the page, go to **“Print Quality - Evenly spaced horizontal lines or marks” on page 2-95.**

**WARNING:** Whenever the gearbox assembly is removed from the machine it must be handled very carefully. Do not allow any of the gears to come in contact with any metal or other hard surface to avoid gear damage. It is also very important not to let any dirt, paper, staples or other material come intact with the grease in the gearbox assembly.

	FRU	Action
1	Main Drive Assembly (Excessive noise or vibration)	Remove the controller board and run a Diagnostic Print Test in the continuous mode. Check the main drive assembly for any excessive noise or vibration. Determine if the noise is in the main drive, toner cartridge, fuser or main drive gearbox. Look for any loose or worn parts in the developer drive assembly, main drive gearbox or fuser. Repair as necessary.
2	Main Drive Motor Assembly (Excessive noise, gears ratcheting and so on)	A service error code 936 - Transport Motor may be displayed. Check the voltage at J12-6 on the engine board. It measures approximately +5 V dc when the motor is not running and goes to 0 V dc when the motor is running. If incorrect, replace the engine board. If this does not fix the problem, replace the main drive motor.
3	Main Drive Motor Cable	Check the continuity of the main drive motor cable. If incorrect, replace the cable.

	FRU	Action
4	Motor does not turn, no gear error code 936 or User message 201 Paper Jam displays.	<p>Check the voltages at J12 on the engine board.</p> <p>Pin number and voltage:</p> <p>J12-1 = +24 V dc</p> <p>J12-4 = +5 V dc (static) 0 V dc (when main drive motor running)</p> <p>J12-5 = + 5 V dc (static) 0 V dc (when main drive motor running)</p> <p>J12-6 = +5 V dc (static) +2.5 V dc (when main drive motor running)</p> <p>J12-7 = +5 V dc (static) 0 V dc (when main drive motor running)</p> <p>J12-8 = +5 V dc (static) +5 V dc (when main drive motor running)</p> <p>J12-11 = + 5 V dc (static) 0 V dc (when main drive motor running)</p> <p>If the voltage is incorrect, replace the FRUs in the following order:</p> <p>main drive motor assembly</p> <p>engine board</p>

## Operator Panel Service Check

### Operator Panel Buttons Service Check

**Note:** Before continuing with this service check do the “**Button Test**” on page 3-9 in the diagnostic aids chapter.

	FRU	Action
1	Operator Panel Assembly	If any button fails the Button Test, replace the operator panel assembly.

	FRU	Action
2	Engine Board (No buttons work)	Check the voltage at J11-5. The voltage measures approximately +5 V dc with the controller board removed. If incorrect, replace the engine board. If correct, check the continuity of the operator panel cable. If incorrect, replace the cable. If correct, replace the operator panel assembly.

### Operator Panel Display Service Check

**SERVICE TIP:** The printer has detected a problem with the engine board, operator panel cable or operator panel assembly if POST does not complete and the printer emits 5 beeps and stops in a continuous pattern until the printer is turned off. The operator panel cable is an individual cable on some printers and a combination cable assembly with the cover switch cable on later models.

**Note:** If the operator panel is operating properly except for a PEL or a few PELS missing or broken, run the **"LCD Test"** on [page 3-9](#) from the hardware tests before continuing with this diagnostic service check.

	FRU	Action
1	Operator Panel Cable	Check for proper installation of the cable at the engine board (J11) and at the operator panel. Check the continuity of the operator panel cable. If incorrect, replace the cable.
2	Operator Panel Display blank, 5 beeps, LED Off	Check the voltage at J11-2 on the engine board. It measures approximately +5 V dc. If incorrect, replace the engine board. If correct, replace the operator panel assembly.
3	Operator Panel Display blank, 5 beeps, LED On	Check for ground between J13-4 and ground. If correct, replace the operator panel assembly. If incorrect, replace the engine board.



	FRU	Action
4	Operator Panel all diamonds, No Beeps	Check to make sure a SIMM is not plugged in backward. This condition causes the printer to fail POST displaying all diamonds on the operator panel with no beeps.
5	Operator Panel all diamonds, 5 Beeps	Check the voltage at Pin J11-1 and J11-3. The voltage measures approximately +5 V dc. If incorrect, replace the FRUs in the following order:  operator panel assembly  engine board

## Options Service Check

Service Tip: When you have a problem with any of the options installed in the options slots on the interconnect board on a 212/414/616 (the 010 has only one slot), switch the non operating option to one of the other option slots to isolate the failure.

### Flash Memory Option(s)

Run a copy of the test page and check to see if the option you are checking is listed. The printer does not recognize the option being installed if the option is not listed. Check to make sure that the Memory DIMM is installed correctly and is not broken or damaged. If the Memory DIMM is correctly installed not broken or damaged then run the **"Flash Test" on page 3-3**. If the test fails, replace the FLASH DIMM. If the problem continues, replace the controller board.

### DRAM Memory Option(s)

This service check is the same as the flash memory option service check with the following exception:

Run the **"SDRAM Memory Test" on page 3-10** from the menu if the SDRAM Memory DIMM is correctly installed and not broken or damaged. If the test fails, replace the SDRAM DIMM. If the problem continues, replace the controller board.

## 4069-0XX

### Hard Disk Option

Service Tip: The Optra T printers support one hard disk option. Check to make sure only one hard disk option is installed.

- 2.1 GB or larger

Check to make sure the fixed disk and the fixed disk board are correctly installed. Run the **“Quick Disk Test”** on page 3-2 from the Device Test on the Diagnostic Menu when a problem is suspected either with the hard disk system board or with the hard disk.

**Note:** The Quick Disk Test is a non-destructive test and indicates Pass or Fail. If the test fails, replace the hard disk. If a problem still exists, replace the hard disk board.

The **“Disk Test/Clean”** on page 3-2 is used to help restore the disk if the disk contains bad data and is unusable. This test is divided into a cleaning and a verifying or testing section.

**WARNING:** This can be a very lengthy test depending on the disk size. This test leaves the hard disk unformatted. The servicer or user must reformat the disk using the Format Disk Menu operation. This is a destructive type of test. All the data on the disk is destroyed and should not be performed on a known good disk.

### Network Card Option

**Note:** The network is installed on the controller board on network model printers.

### Error Code 976 - Network Card X (X=Network card 1, 2, or 3)

A 976 error code indicates an unrecoverable software error in network card x. Verify that network card x is correctly installed in the socket on the interconnect board and is properly grounded. If you find no problem, contact your next level of support before replacing the network card.

### Error Code 977 - Network Card X

A 977 error displays when the RIP software detects that a network card is installed in slot x on the interconnect board but cannot establish communications with the network card.

## Output Bin Sensor Standard Tray Service Check

Service Tip: If the output bin standard tray fills up and the bin full sensor fails to post the message "Remove Paper Standard Bin", enter the Diagnostic Mode, select Output Bin Tests, select Sensor Tests and select Standard Bin. Check the sensor and flag for proper operation. If you find no problem with the sensor and flag, continue with the service check.

Service Tip: Check to make sure the correct flag is installed. The Output Bin Sensor is a normally closed sensor with the sensor flag down. Therefore, unless the flag is in the up position or out of the sensor slot, a Remove Paper Standard Bin message is not displayed.

	FRU	Action
1	Engine Board  Printer fails to display Remove Paper Standard Bin message. Output Bin Sensor Test fails	Check the voltage at J6-3. It measures +5 V dc when the flag is in the sensor and 0 V dc when the flag is out of the sensor. If the voltage does not change, replace the sensor cable assembly. If this does not fix the problem, replace the engine board.
2	Output Bin Sensor Flag	Check to make sure the correct flag is installed. Check the flag for damage or improper operation. If incorrect, replace the flag.  <b>Note:</b> A broken or improper operating sensor flag causes a Remove Paper Standard Bin message to display before POST completes and cannot be cleared.

## Output Expander Service Check

Service Tip: The majority of the mechanical components can be observed during operation by removing the left, right and system board covers. The output expander functions without the covers installed.

**Note:** Make sure the option is correctly installed before attempting to service the unit. No jumpers should be installed at connector J6 on the output expander board.

### Problems with excessive static electricity buildup.

	FRU	Action
1	Output Expander Control Board Cover	Check the output expander control board cover to make sure the ESD brush ground lead is firmly attached to the output expander frame. Also check to make sure the ESD brush is not loose.

### Printer does not recognize one or more output expander options as being installed.

Service Tip: If more than a single output expander option is installed, check each one to see if the printer recognizes any single option as being installed. If the printer recognizes any of the output expander options then the base printer autoconnect system is operating correctly and the problem is in the unrecognized expander option.

	FRU	Action
1	Output Expander Option	Make sure the output expander option is the only option that is not recognized by the base printer. If the output expander is the only option not recognized by the printer, continue with step 2. If not, check the autoconnects of the options not recognized and the interconnect board and cable connections.
2	Output Expander Assembly Mechanical Linkage	Check the autoconnects for damage, especially the connector pins. Remove the left and right side covers. Remove the front control board cover. Check the cables at J1A, J1B, J2A and J2B on the control board to make sure they are attached securely and correctly. Remove the output expander and check the voltages on the output bin autoconnect located on the top left rear of the printer. Go to <b>"Autoconnect - Top" on page 5-19</b> . If the voltages are correct, reinstall the output expander unit and check the voltages at J1A and J1B on the connector. If correct, replace the output expander control board. If incorrect, replace the output expander assembly mechanical linkage.

**4069-0XX**

**202 Paper Jam Open Rear Door Message displays. A sheet of paper is jammed prior to the pass through sensor flag.**

**202 Paper Jam Open Rear Door Message displays. A sheet of paper feeds out to the standard bin even though bin x is selected. Paper exits half way out of the redrive.**

Service Tip: For this type of problem check the sub error codes. They can help isolate the problem. 202 Paper Jam messages can also occur prior to the output expander pass thru sensor.

	FRU	Action
1	Output Expander Drive Belt Drive Pulley Drive Belt Idler Pulley Belt Tension Spring	Check to ensure the output expander drive belt is correctly installed on the drive pulley and belt idler pulley. Check the belt tension spring to make sure it is not loose or broken. Repair as necessary.
2	Mechanical Linkage DC Motor Assembly	If the DC motor is functioning properly check the gears, clutch and other linkage parts for correct operation and any signs of wear, broken gear teeth or damaged parts. If incorrect, replace the mechanical linkage/DC motor assembly.

## 4069-0XX

**Remove Paper - Output Bin X is displayed, POST Incomplete, Unable to clear the message.**

	FRU	Action
1	Dual Output Bin Sensor Flag	Check the flag for correct operation, binding, broken parts or interference from the sensor cable, If incorrect, repair as necessary.

## 271 Paper Jam - Check Bin X. POST Incomplete

	FRU	Action
1	Pass Thru Sensor and Flag Assembly Control Board	Check the sensor flag for proper operation. If correct, check to make sure the pass thru sensor cable is correctly connected to J3 on the control board. Disconnect the pass thru sensor cable from J3 on the control board and check the voltage at J3-3. The voltage measures approximately +5 V dc. If incorrect, replace the control board. If correct, check the voltage at J3-2. The voltage measures approximately 0 V dc. If incorrect, replace the sensor assembly. If this does not fix the problem, replace the control board.

**271 Paper Jam - Check Bin X, POST Complete, First Sheet of paper feeds into Output Bin X.**

**Note:** Before performing the following checks run the Output Bin X Sensor Test and check for the failing sensor.

Sensor Test: NF = Near Full (Upper part of sensor assembly)

F = Full (Lower Part of sensor assembly)

P = Pass Thru Sensor

	FRU	Action
1	D.C. Motor Mechanical Linkage Assembly	<p>Check the DC motor cable connector to be sure it is correctly installed at J4 on the output expander option board. If correct, disconnect J4 from the option board and check the resistance of the motor on the cable connector: J4-1 to J4-2: measures between 115 and 135 ohms. Also check J4-1 and J4-2 to the motor case for shorts. If either the resistance is incorrect or a short is found, replace the motor/mechanical linkage assembly.</p> <p><b>Note:</b> If the DC motor is shorted, it may also be necessary to replace the control board.</p>
2	Output Expander Control Board	<p>Disconnect the motor cable J4 and check the voltages at J4 on the board.</p> <p><b>Note:</b> Use caution not to short to adjacent pins on the connector.</p> <p>J4-1 (Motor Idle) +24 V dc  J4-2 (Motor Idle) +24 V dc  J4-5 (Motor Idle) +5 V dc  J4-6 (Motor Idle) +5 V dc</p> <p>If any of the voltages are incorrect, replace the control board. If the voltages are correct, replace the DC motor/mechanical linkage assembly.</p>



## 4069-0XX

### No indication that Bin X is Full OR No indication that Bin X is Near Full

	FRU	Action
1	Dual Output Bin X Sensor Assembly Control Board	Check for correct installation of the sensor cable at J5 on the control board. If either the Bin Full (F) or Bin Near Full (NF) fail the sensor test then check the voltage at J5-3 and J5-4. The voltage measures approximately +5 V dc. If the voltage is incorrect, replace the control board. If correct, replace the sensor assembly.

## High-Capacity Output Stacker Service Check

Service Tip: The majority of the mechanical components can be observed during operation by removing the left, right and front covers. The high capacity output stacker option functions without the covers installed.

Models 010 and 010n do not support this output option.

Determine which paper path stacker assembly is not functioning properly.

Make sure the option(s) are installed correctly and the machine is configured correctly before attempting to service the high-capacity output stacker option.

Go to **“High-Capacity Output Stacker Board”** on page 5-22 to identify the correct jumper location at J6 for the upper and lower units.

**Problems with excessive static electricity buildup**

	FRU	Action
1	Front Cover Assembly	Check the front cover assembly to make sure the ESD brush ground lead is firmly attached to the high capacity option. Also check to make sure the ESD brush is not loose or damaged.

**The printer does not recognize one or more output options as installed**

Service Tip: If more than a single output option is installed, check each one to see if the printer recognizes any single option as installed. If the printer recognizes any of the output options, the base printer autoconnect system is operating correctly. The problem is in the unrecognized option. Continue with this service check or go to the service check for the failing output option.

	FRU	Action
1	High Capacity Stacker Option	Check the autoconnects, cables and connectors of the option for any signs of loose or damaged parts.
2	High-Capacity Output Stacker/Mechanical Linkage Assembly	Remove the left and right side covers and check all four autoconnects for damage, especially the connector pins. Remove the output option and check the voltages on the standard output bin autoconnect located on the top left rear of the printer. Go to <b>"Autoconnect - Top" on page 5-19</b> . If the voltages are correct, reinstall the output option and note the positions of the torroids on the autoconnect cables on the upper and lower assemblies, and check the voltages on the autoconnects. If all voltages are correct and the lower assembly is failing, replace the lower control board. If the upper assembly is failing, replace the upper control board. If the voltages are incorrect, replace the upper or lower failing mechanical linkage assembly.

## 4069-0XX

**202 Paper Jam Open Rear Door Message displays and a sheet of paper is jammed prior to the pass through sensor flag or 202 Paper Jam Open Rear Door Message displays, a sheet of paper feeds out to the standard bin even though bin X is selected and paper exits half way out of the redrive assembly.**

Service Tip: For this type of problem check the **“Base Printer Sub Error Codes” on page 2-8**. They can help isolate the problem. A 202 paper jam message can also occur prior to the high-capacity output stacker pass through sensors.

	FRU	Action
1	Lower Pass Thru Sensor/ Flag Assembly	Check the flag for correct operation, binding, broken parts or interference from the sensor cable. If incorrect, repair as necessary. If correct, check to make sure the lower pass thru sensor is correctly connected to J3 on the lower control board. Disconnect the pass thru sensor cable and check the voltage at J3-3. The voltage measures approximately +5V dc. If incorrect, check the voltage at J3-2. The voltage measures approximately 0V dc. If incorrect, replace the sensor assembly. If this does not fix the problem, replace the lower control board.
2	High-Capacity Output Stacker Drive belt(s), Drive Pulleys, Belt Idlers, and Belt Tension Springs	Check to ensure the output stacker drive belt or the failing assembly is correctly installed on the drive pulley and belt idler pulley. Check the belt tension spring to make sure it is not loose or broken. Repair as necessary.
3	Mechanical Linkage/Motor Assembly (Upper or Lower)	If the DC motor is functioning properly check the gears, clutch and other linkage parts for correct operation and any signs of wear, broken gear teeth or damaged parts. If incorrect, replace the mechanical linkage assembly/DC Motor Assembly.

## 4069-0XX

**Remove Paper - Output Bin X Full displays. You may not be able to clear the message.**

	FRU	Action
1	Dual Output Bin Sensor Flag (Upper Assembly)	Check the flag for correct operation, binding, broken parts or interference from the sensor cable. If incorrect, repair as necessary.

## 271 Paper Jam - Check Bin X. POST Incomplete

	FRU	Action
1	Upper Pass Thru Sensor Flag Assembly Upper Control Board	Check the flag for correct operation, binding, broken parts or interference from the sensor cable. If incorrect, repair as necessary. If correct, check to make sure the lower pass thru sensor is correctly connected to J3 on the lower control board. Disconnect the pass thru sensor cable and check the voltage at J3-3. The voltage measures approximately +5V dc. If incorrect, check the voltage at J3-2. The voltage measures approximately 0V dc. If incorrect, replace the sensor assembly. If this does not fix the problem, replace the lower control board.

## 5-Bin Mailbox Service Check

Service Tip: The majority of the mechanical components can be observed during operation by removing the left, right side covers.

Models 010 and 010n do not support this output option.

Make sure the option(s) are correctly installed before attempting to service the unit. Be sure the option is correctly installed and the machine is configured correctly before attempting to service the unit.

**Problems with excessive static electricity buildup**

	FRU	Action
1	Front Cover Assembly	Check the front cover assembly to make sure the ESD brush ground lead is firmly attached to the 5-Bin Mailbox frame. Also check to make sure the ESD brush is not loose or damaged.

**The printer does not recognize one or more output options as installed.**

Service Tip: If more than a single output option is installed, check each one to see if the printer recognizes any single option as being installed. If the printer recognizes any of the output options then the base printer autoconnect system is operating correctly and the problem is in the unrecognized option. Continue with this service check or go to the service check for the failing output option.

	FRU	Action
1	5-Bin Mailbox Option	Check the autoconnects, cables and connectors of the option for any signs of loose or damaged parts.
2	Mechanical Linkage Assembly	Remove the left and right side covers and check the two autoconnects for damage especially the connector pins. Remove the output option and check the voltages on the standard output bin autoconnect located on the top left rear of the printer. Go to " <b>Autoconnect - Top</b> " on page 5-19. If the voltages are correct, reinstall the output option noting the position of the torroid on the autoconnect cable of the lower autoconnect. Check the voltages on each of the autoconnects. If the torroid was moved make sure to move it back to its original position on the cable. If the voltages are correct, replace the control board. If the voltages are incorrect, replace the failing autoconnect assembly.

**271 Paper Jam - Check Bin 1 displays**

	<b>FRU</b>	<b>Action</b>
1	Bottom Pass Thru Sensor Flag Assembly Control Board	Check the flag for correct operation, binding, broken parts or interference from the sensor cable. If incorrect, repair as necessary. If correct, check to make sure the bottom pass thru sensor is correctly connected to J5 on the control board. Disconnect the pass thru sensor cable and check the voltage at J5-3. The voltage measures approximately +5V dc. If incorrect, check the voltage at J5-2. The voltage measures approximately 0V dc. If incorrect, replace the sensor assembly. If this does not fix the problem, replace the control board.

**274 Paper Jam - Check Bin 4 Displays**

Service Tip: When a 274 Paper Jam Check Bin 4 message displays, a problem exists with the top pass thru sensor assembly or the control board.

	<b>FRU</b>	<b>Action</b>
1	Top Pass Thru Sensor Flag Assembly Control Board	Check the flag for correct operation, binding, broken parts or interference from the sensor cable. If incorrect, repair as necessary. If correct check to make sure the top pass thru sensor is correctly connected to J11 on the control board. Disconnect the pass thru sensor cable and check the voltage at J11-3 The voltage measures approximately +5V dc. If incorrect, check the voltage at J11-2. The voltage measures approximately 0V dc. If incorrect, replace the sensor assembly. If this does not fix the problem, replace the lower control board.

## 4069-0XX

**Ready Bin X Full message displays - May be able to clear message and will feed paper into Bin selected.**

	FRU	Action
1	Bin X Sensor Bin X Sensor Cable Bin X Sensor Flag Control Board	<p>Check the sensor and sensor cable for the bin that is displaying the message to make sure the sensor is seated correctly in the side of the tray and the cable is connected to the sensor and the control board. Check the flag for binding and proper operation. If correct, replace the Bin X sensor. If this does not fix the problem, replace the control board.</p> <p><b>Note:</b> This sensor is in a normally open position with the flag out of the sensor slot.</p>

**Bin X is full - No message that Bin X is full displays**

	FRU	Action
1	Bin X Sensor Bin X Sensor Cable Bin X Sensor Flag Bin X Sensor Flag Control Board	<p>Check the sensor flag for binds, broken or missing parts. If correct, check the bin sensor for correct installation in the side of the tray. If the bin sensor is installed correctly, check the sensor cable for correct installation to the sensor and control board. If correct, replace the Bin X sensor. If this does not fix the problem, replace the control board.</p>

**Ready - Bin X Full displays and paper feeds into Bin X**

	FRU	Action
1	Bin X Sensor Bin X Sensor Control Board	<p>Check the sensor flag for binds. Make sure the sensor flag is not in an up position. If the sensor flag is operating correctly, replace the bin X sensor. If this does not fix the problem, replace the control board.</p>

**4069-0XX**

**Paper does not feed into the bin selected. 271 Paper Jam - Check Bin 1 displays**

	<b>FRU</b>	<b>Action</b>
1	Deflector Deflector Spring Deflector Cover Deflector Cover Spring Shaft assemblies	Check all the bin parts for signs of missing or loose springs, binds in the deflector or deflector cover, broken or binding shaft assemblies or broken gear teeth. If incorrect, repair as necessary.
2	Bin X Solenoid Assembly Control Board	Check the solenoid for any binds. Make sure the solenoid is contacting the latch correctly. If incorrect, repair as necessary. If the solenoid appears to be operating mechanically, check the resistance of the solenoid. It measures between 30 and 50 ohms. If incorrect, replace the failing solenoid assembly. If correct, replace the control board.
3	Mechanical Linkage Motor Assembly	If the DC motor is functioning properly, check the gears, clutch and other linkage parts for correct operation and any signs of wear, broken gear teeth or damaged parts. If incorrect, replace the mechanical linkage assembly/DC motor assembly.



## 990 Service Error displays

	FRU	Action
1	Mechanical Linkage DC Motor Assembly	<p>Check the DC motor cable connector to be sure it is correctly installed at J2 on the control board. If correct, disconnect J2 from the control board and check the resistance of the motor on the cable connector. J2-1 to J2-2 measures between 115 and 135 ohms. Also check J2-1 and J2-4 to the motor case for shorts. If either the resistance is incorrect or a short is found, replace the mechanical linkage/ DC motor assembly.</p> <p><b>Note:</b> If the DC motor is shorted, it may also be necessary to replace the control board.</p>
2	Control Board	<p>Disconnect the motor cable J2 from the control board and check the voltages at J2 on the board.</p> <p><b>Note:</b> Use caution not to short adjacent pins on the connector as damage to the board could result.</p> <p>J2-1 (motor idle) +24V dc  J2-2 (Motor Idle) +24V dc  J2-5 (motor idle) +5V dc  J2-6 (motor idle) +5V dc</p> <p>If any of the voltages are incorrect, replace the control board. If correct, replace the mechanical linkage/ DC motor assembly.</p>

## Paper Feed Service Check

If you have a 936 Transport Motor Error go to the **“Main Drive Service Check”** on page 2-68.

	FRU	Action
1	Alignment Assembly	Check to ensure the alignment assembly is correctly attached to the left side frame and the mounting screws are tight. Check the alignment assembly for any signs of worn rollers, contaminated rollers or binds. Replace the alignment assembly if any problem is found.
2	Inner Deflector	Check the inner paper deflector for correct installation. If the deflector is bowed or not fitting correctly, replace the deflector.

**Autocompensator fails to feed paper. Failures occur randomly throughout the stack of paper.**

	FRU	Action
1	Pass Through Sensor	Check the pass through sensor for correct installation and operation.
2	Autocompensator Assembly	The autocompensator pick roll shaft assembly is not providing enough torque if the pick rollers are not picking the paper correctly. Replace the autocompensator assembly.
3	Wear Strips in Tray X problem is found.	Check the wear strips for excessive wear, scratches or rough spots. Replace the wear strips if a problem is found.

## 4069-0XX

### Paper feed failures occur only near the top of the stack of paper.

The most common cause of this problem is paper curl. Remove the paper from tray x and check for the natural curvature in the paper. Reinstall the paper in the correct manner. If the problem persists, it may be necessary to reduce the stack height. Replace both pick rolls if the paper appears to be flat in the tray but there is still a problem.

### Failures occur mainly near the bottom of the stack of paper.

The autocompensator pick arm may not be coming down far enough to allow the pick rolls to properly contact the paper. Also the autocompensator motor may be failing. If this problems continues, replace the autocompensator assembly.

### Double Feeding Paper

**Note:** If double feeding paper occurs mostly from the bottom of the stack, check for missing or damaged restraint pads in the tray.

	FRU	Action
1	Paper	Paper is usually the primary cause of a double feeding paper problem. Flex the paper before placing the paper in the tray. Edge-welded paper is the most common cause of double feeding. Loading the paper in the tray in different locations and directions and using rough paper and short grain paper also causes double feeding.
2	Autocompensator	Make sure the counterbalance spring is not missing, loose or broken at the top of the autocompensator arm assembly. If you find a problem, replace the autocompensator assembly.

4069-0XX

Multipurpose Tray

Paper fails to feed from the multipurpose tray.

The pick roll should make one complete revolution and stop with the flat side down. If the pick roll turns but does not pick paper, check the roll for signs of wear, oil or grease on the surface of the pick roll or slick spots. If you find a problem, replace the pick roll assembly. Check to ensure the media that is being fed through the multipurpose tray assembly meets recommended paper specifications.

Parallel Port Service Check

Run the “Parallel Wrap Test” on page 3-11.

**Note:** The Parallel Wrap Test is designed to check the parallel port hardware by using a wrap plug (P/N 1319128) and invoking the Parallel Diagnostic Test. This test helps isolate the printer from the parallel cable and host. The test provides failure information on the display for approximately three seconds. If the test indicates that a problem is detected, replace the controller board.

Printhead Service Check

The printhead assembly does not contain any service replaceable parts or components. If service error code 930 displays, the wrong printhead is installed in the printer.

	Service Error Code	Explanation
1	Error Code 931 No first HYSNC Signal Error Code 932 Lost HYSNC	These errors usually indicate a failure in the HYSNC signal to the printhead. Check the continuity of the cables connected to J3 and J8 on the engine board. If incorrect, replace the defective cable. The voltage at J8-4 measures approximately +5 V dc. If incorrect, replace the engine board. The voltage at J3-7 measures approximately +24 V dc. If incorrect, replace the engine board. If correct, replace the printhead assembly.

	Service Error Code	Explanation
2	Error Code 934 Mirror Motor Lost Lock Error Code 935 Mirror Motor unable to reach operating speed	<p>These error codes indicate a problem with the mirror motor circuit in the printhead assembly or the mirror motor cable to the engine board cable or engine board assembly. Check the continuity of the mirror motor cable connected to J3 on the engine board. If incorrect, replace the cable. The voltage at J3-7 measures approximately +24 V dc. If incorrect, replace the engine board. If correct, replace the FRUs in the following order:</p> <p>engine board</p> <p>printhead assembly</p>

## Print Quality Service Check

Service Tip: Before troubleshooting any print quality problems do the following:

- Install another print cartridge if available before proceeding with the service checks.
- Use Tray 1 to test for print quality of the base printer.
- Replace the charge roll if it is damaged or contaminated.
- Replace the transfer roll if it is damaged or contaminated.
- Make sure the fuser assembly is installed correctly.

Select the following menu settings as indicated. Be sure and note the original settings so you can return the printer to the original customer printer setup.

- Print Resolution: Set to 300 dpi (print quality problems should be checked at different resolution settings).
- Print Darkness: Set to NORMAL.
- Toner Saver: Set to OFF.
- PQET: Set to OFF.
- Fuser Temperature: Set to NORMAL.

## 4069-0XX

An incorrect printer driver for the installed software can cause problems. Incorrect characters could print and the copy may not fit the page correctly.

Measure all voltages from the connector to printer ground. All voltages measured during the print cycle are measured with the controller board removed while running the print test.

### Print Quality - All Black Page

Service Tip: An all black page is generally caused by a problem in the high voltage system or an incorrect high voltage in the printing process resulting in toner development on the entire photoconductor drum.

	FRU	Action
1	High Voltage Contacts	<p>Check the high voltage contacts on the right side frame to ensure they fit securely and are not pitted, contaminated or damaged. If incorrect, replace the contact with one from the HV contact kit.</p> <p>Screws are included to attach the contacts to the right side frame in the HV contact kit.</p>
2	HVPS	Check the voltages on J10-1 thru J10-8. If incorrect, replace the engine board.
3	HVPS Cable (Part of Front Harness Cable)  Engine Board	Check the continuity of the HVPS cable. If incorrect, replace the cable assembly. If correct, replace the engine board.

## Print Quality - Blank Page

	FRU	Action
1	Print Cartridge	Check the print cartridge for any signs of damage, especially the PC drum contact on the cartridge.
2	High Voltage Contact	<p>Check the PC drum contact on the right side frame for damage, PC drum contact wear or contamination. If the contact is bent or damaged, replace the contact.</p> <p><b>Note:</b> Inspect the HVPS PC drum contact on the board for any signs of damage or contamination.</p>
3	HVPS	<p>Check the fuse on the HVPS. If open, replace the HVPS. Check the voltages at J10 on the engine board. Measure the following voltages from connector J10 to printer ground:</p> <p>Printer Idle J10-5 measures +24 V dc</p> <p>Printer Printing J10-5 measures +24 V dc</p> <p>If the voltages at J10-5 are incorrect, replace the engine board.</p>
4	Front Cable Harness HVPS Section	Check the front cable harness at J10 on the engine board and at CN1 on the HVPS to make sure the harness is connected properly. If connected properly, check the continuity of the cable harness. If there is no continuity, replace the front cable harness.

	FRU	Action
5	Printhead Assembly	<p>Generally a 93x service error is posted if the printhead assembly fails and the printer does not give a blank copy symptom.</p> <p>The printhead used in the printer does not have a mechanical shutter as previous laser printers. The printer is interlocked through the front top cover interlock switch.</p>

### Print Quality - Random Marks

Service Tip: The primary cause of random marks is due to loose material moving around inside the printer and attaching to the photoconductor, charge roll or transfer roll.

	Symptom	Action
1	Random Marks	<p>Check the print cartridge for any signs of loose or foreign material that might be on the photoconductor. Check the transfer roll and charge roll for any pieces of material that are stuck to the rolls.</p>

### Print Quality - Blurred or Fuzzy Print

Blurred or fuzzy print is usually caused by a problem in the main drive gearbox assembly, alignment assembly, any feed roller or in the transfer roll bearings or transfer roll. Check the gearbox assembly for correct operation. Check the transfer roll for binds or a contaminated shaft or bearings.

Blurred print can also be caused by incorrect feeding from one of the input paper sources, paper trays, duplex or envelope feeder.

Check the high voltage contacts to ensure they are not bent, corroded or damaged. Replace as necessary.



**Print Quality - Evenly spaced horizontal lines or marks**

	FRU	Action
1	Lines spaced 3.19 mm (.126 inch) apart	This can be caused by the motor pinion gear on the main drive motor. Replace the main drive motor.
2	Lines spaced 22.32 mm (.882 inch) apart  Lines spaced 28.7 mm (1.130 inch) apart  Lines spaced 47.83 mm (1.883 inch) apart  Lines spaced 63.77 mm (2.511 inch) apart	This can be caused by a defective gear in the main drive gearbox assembly. Replace the main drive gearbox assembly.
3	Lines spaced 38.26 mm (1.506 inch) apart	This can be caused by defective gear(s) in the main drive gearbox. Replace the FRUs in the following order:  main drive gearbox  reference edge
4	Lines spaced 44.64 mm (1.757 inch) apart	Replace the FRUs in the following order:  developer drive assembly  main drive gearbox assembly
5	Lines spaced 47.19 mm (1.858 inch) apart	Replace the FRUs in the following order:  toner cartridge  charge roll  developer drive assembly
6	Lines spaced 49.16 mm (1.935 inch) apart	Replace the toner cartridge.

## 4069-0XX

	FRU	Action
7	Lines spaced 49.74 mm (1.958 inch) apart	Replace the FRUs in the following order:  redrive assembly  fuser assembly
8	Lines spaced 51.02 mm (2.009 inch) apart	Replace the transfer roll.
9	Lines spaced 52.23 mm (2.056 inch) apart	Replace the redrive assembly.
10	Lines spaced 76.53 mm (3.013 inch) apart	Replace the FRUs in the following order:  alignment assembly  main drive gearbox assembly
11	Lines spaced 95.66 mm (3.766 inch) apart	Replace the FRUs in the following order:  toner cartridge  main drive gearbox assembly
12	Lines spaced 99.49 mm (3.917 inch) apart	Replace the redrive assembly.
13	Lines spaced 114.79 mm (4.519 inch) apart	Replace the alignment assembly.

### Print Quality - Background

**Service Tip:** Some background problems can be caused by rough papers or non-Lexmark toner cartridges. If the rough paper mode is on, turn it off and run the print test.

Some slick or coated papers may also cause background. Some problems occur with printers that run a large amount of graphics in a humid environment. The customer may try to improve the print quality by increasing the transfer setting.

Check the charge roll to make sure it is not at the end of life.

	FRU	Action
1	Erase Lamp/Lens Assembly	Check the erase lamp lens for any signs of toner, paper dust or other types of contamination. Clean the lens with a soft dry cloth if necessary. If unable to clean the contamination off the lens, replace the lens and lamp assembly. Check the erase lamp assembly. Use the same procedure as outlined in the "Erase Lamp Service Check" on page 2-45.
2	Printhead	The printhead on the Optra T printers cannot be cleaned. Try another printhead if all other attempts fail to correct a background problem.
3	Transfer Roll Assembly	Check the high voltage contact from the HVPS to the transfer roll. Check the transfer arm assembly right side bearing for any signs of contamination, pitting or a loose cable to the bearing. If any problems are found, replace the defective part. Check the transfer roll shaft for any signs of contamination, wear or pitting on the ends of the shaft that go into the bearings. If a problem is found, clean the ends of the shaft or replace the transfer roll assembly.
4	High Voltage Contacts	Check the high voltage contacts on the right side frame to ensure they are clean and not bent, deformed, or pitted. If incorrect, replace the contact.

	FRU	Action
5	Engine Board HVPS Connector	<p>Check the following voltages at J10 on the engine board. Measure the voltages from J10 to printer ground.</p> <p>Printer Idle  J10-1 approximately 0 V dc  J10-2 approximately 4 V dc  J10-4 approximately 0 V dc</p> <p>Printer Printing  J10-1 varies 0 V dc to +5 V dc  J10-2 varies 0 V dc to +4 V dc  J10-4 varies 0 V dc to +1.9 V dc</p> <p>If J10-1 voltage is incorrect, check the continuity of the front harness cable (J10-1 line). If there is no continuity, replace the harness cable. If there is continuity, replace the HVPS. If this does not correct the problem, replace the engine board.</p> <p>If J10-2 voltage is incorrect or if the voltage remains at 0 V dc, check the continuity of the front harness cable (J10-2 line). If there is no continuity, replace the harness cable. If there is continuity, replace the HVPS. If this does not correct the problem, replace the engine board.</p> <p>If J10-4 voltage is incorrect, check the front harness cable (J10-3 line). If there is not continuity, replace the harness cable. If correct, replace the engine board. if this does not correct the problem, replace the HVPS.</p>

Print Quality - Banding

Service Tip: Banding is difficult to detect except on a page with a uniform gray or a large amount of graphics printed on the page. Banding is primarily due to a variation in the speed of the paper as it feeds thru the printer, especially in the development and transfer process. Inspect the alignment assembly, main drive assembly and all other paper feed components for signs of wear, dirt, binds, or damage, especially the drive gears. Banding appears as light or dark horizontal lines on a uniformly gray page.

Banding can also be caused by a defective charge roll brush contact or HVPS. Check the charge roll contact for any signs of damage and for proper connection to the HVPS and print cartridge.

Print Quality - Black bands on outer edges of the page

This print quality problem appears as vertical black bands on one or both sides of the copy and can be wide, narrow, light or dark.

	FRU	Action
1	Charge Roll Counterbalance Springs	If the problem is just on one side of the page, check the charge roll counterbalance spring on that side. You can check to see if enough force is being applied to the charge roll by applying a slight downward pressure with your finger to the charge roll link arm that the spring is attached to while you run a print test sample. See if the problem changes or goes away. If this fixes or changes the problem, then check the springs and charge roll link arm assemblies for binds or defective parts. Replace as necessary.

	FRU	Action
2	Charge Roll Assembly Charge Roll Link Arm	Check the charge roll for any signs of toner buildup or other contamination on the outer edges that correspond to the bands on the page. Check the charge links and arms for proper operation, binds or incorrectly mounted counterbalance springs. Repair or replace as necessary.
3	HVPS	<p>Check the following voltages at J10-8 on the engine board:</p> <p>Printer Idle J10-8 measures 0 V dc</p> <p>Printer Printing Test Page J10-8 voltage changes from 0 V dc to +4 V dc</p> <p>If the voltage does not vary, check the continuity of line J10-8 in the front cable harness. If there is no continuity, replace the cable harness. If there is continuity, replace the HVPS. If this does not correct the problem, replace the engine board.</p> <p>Turn the printer Off and check the resistance between J10-7 and printer ground. The resistance measures approximately 0 ohms. If incorrect, make sure the engine board is mounted correctly and securely grounded. If correct, replace the engine board.</p>

### Print Quality - Residual Image

Service Tip: Install a new print cartridge if available before doing this service check. Residual image can be caused by the photoconductor, cleaning blade and other parts inside the print cartridge.

	FRU	Action
1	Erase Lamp Assembly	Check the erase lamp lens assembly for any signs of paper dust, toner buildup or any other contamination. Clean with a soft cloth or replace the lens and lamp assembly which are provided together in a kit. If the lens is clean then check the erase lamp assembly for failed erase lamps. If defective, replace the erase lamp assembly.
2	Fuser Assembly	Check the fuser assembly for signs of toner contamination. The hot roll especially might cause toner to be retained and deposited on the page.

### Print Quality - Light Print

Service Tip: Check the toner saver and print darkness settings first if the print is light.

	FRU	Action
1	Transfer Roll	Check the right end of the transfer roll shaft for signs of wear or contamination. If incorrect, replace the transfer roll.
2	Right Side Transfer Roll Arm Assembly	Check the right side transfer roll arm assembly bearing for any signs of wear or contamination. Also check to ensure the transfer cable is firmly attached to the bearing. If incorrect, replace the right side transfer arm assembly. Check the connection of the transfer roll assembly cable to the transformer on the HVPS board. Check the continuity of the cable from the bearing to the spade terminal on the cable. If incorrect, replace the right side transfer arm assembly. If correct, replace the HVPS.

## 4069-0XX

### Print Quality - Toner on backside of printed page

**Service Tip:** This is generally caused by loose toner in the machine in the paper path being carried through the printer on the backside of the paper.

	FRU	Action
1	Fuser Assembly	Toner is being carried out on the backside of the media. This problem is generally caused by a toner buildup on the fuser hotroll or backup roll. Check the fuser hotroll and backup roll for any noticeable buildup of toner. Repair as necessary.
2	Transfer Roll Transfer Plate Assembly	Check the transfer roll for any signs of toner buildup or loose toner around the area of the transfer plate assembly. Clean the area and run another copy. If the problem continues, replace the FRUs in the following order:  HVPS  engine board

### Smart Cartridge Service Check

**Note:** If you are unable to clear a “32-Unsupported Cartridge” User Error Message, make sure an Optra T print cartridge is correctly installed in the printer. The cartridge is easily identified by the smart chip located on the top right side of the cartridge. Install another print cartridge before attempting to troubleshoot the printer. Check to make sure the smart cable is properly connected to J21 on the engine board. Check the print cartridge for any signs of damage or improper installation of the smart chip. Also check to make sure there is proper contact between the smart chip and the smart cartridge contacts.



## 4069-0XX

Service Tip: An intermittent “32-Unsupported Cartridge” User Error Message can be caused by poor contact between the smart cartridge contacts in the upper front cover and the smart chip. Also check for proper seating of the smart cartridge cable to the engine board.

	FRU	Action
1	Smart Cartridge Contact Smart Cartridge Ground Contact	Check both contacts to make sure they are properly installed and the two contacts are not touching each other. Check both contacts for any signs of being bent, worn or broken. If incorrect replace both contacts.
2	Smart Cartridge Cover	Check to make sure that the smart cartridge cover is properly snapped into place and is not damaged or broken. Replace as necessary.
3	Smart Cartridge Plunger	Check the plunger for correct installation and any signs of being damaged or broken. Correct any problem found or replace the plunger as necessary.
4	Smart Cartridge Cable Engine Board	Check the voltage on the smart cartridge contact. The voltage measures approximately +5 V dc when not writing data to the engine board. If data is being written, the voltage measures approximately +12 V dc. If incorrect, disconnect the cable from J21 on the engine board and check the voltage on J21-1. The voltage measures approximately +5 V dc. If incorrect, replace the engine board. If correct, replace the smart cartridge cable.

## Serial Port Service Check

Run the “Serial Wrap Test” on page 3-12.

**Note:** The Serial Wrap Test is designed to check the serial port hardware by using a wrap plug (P/N 1329048) and invoking the Serial Post Diagnostic Test. The test helps isolate the printer from the serial cable and host. The test provides failure information on the display for approximately three seconds. If the test indicates a problem, replace the controller board.

## Toner Sensor Service Check

Service Tip: Check the print darkness MENU setting before checking the toner sensor.

This service check is intended to be used when a 929 Service Error displays.

	FRU	Action
1	Developer Drive Assembly	Incorrect operation of the developer drive assembly can cause the printer to display a 929 error code (Toner Sensor). Check the developer drive assembly for correct installation, any sign of worn, loose or broken parts.
2	Front Harness Cable	Check the toner sensor portion of the front harness cable to make sure it is properly seated into the toner sensor. If correct at both the sensor and engine board (J10), check the continuity of the cable. If incorrect, replace the cable.

	FRU	Action
3	Toner Sensor	The toner sensor cable is part of the front harness and part of connector J10 on the engine board. Check the voltage at J1-011. It reads approximately +5 V dc. If incorrect, replace the engine board. If correct, check the voltage at J10-12. It reads approximately +5 V dc with the controller board removed from the printer. If incorrect, replace the engine board. If correct, replace the toner sensor assembly. A bad ground connection between J10-13 on the engine board and pin 3 on the toner sensor results in a 929 service error.

## Transfer Roll Service Check

**Service Tip:** The transfer roll is 15.02 mm (2.009 inch) diameter. Any print quality problems such as lines that are spaced 15.2 mm apart indicate you should check the transfer roll for damage, toner or foreign material buildup.

**Service Tip:** The transfer roll assembly is part of the Maintenance Kit and is replaced when a '80 Scheduled Maintenance" message displays. Ask the customer if they have replaced the transfer roll recently.

**CAUTION:** Make sure the printer is powered Off before making any checks on the transfer roll or associated parts for personal safety and to prevent damage to the printer.

	FRU	Action
1	Transfer Roll Assembly	Check the transfer roll for any signs of toner buildup, surface damage to the roll, oil or other contaminants on the surface of the roll. Replace the transfer roll as necessary.

	FRU	Action
2	Left Transfer Arm Assembly	Check the left transfer roll arm assembly to make sure it is fastened and locked in the down position. If the arm is not locked down, check to ensure the arm is not broken and will lock into the EP frame correctly. Check the left transfer arm assembly spring for proper operation.
3	Right Transfer Arm Assembly	Check the right transfer arm assembly to make sure it is fastened and locked in the down position. If the arm is not locked down, check to make sure the arm is not broken and will lock into the EP frame correctly. Check the right transfer arm assembly spring for proper operation. For any background problems, check to ensure the contact to the HVPS board is correct and that there is approximately 0 ohms resistance between the transfer roll shaft and the HVPS contact. If correct, go to <b>"Print Quality - Background"</b> on page 2-96.
4	HVPS - 917 Error Code	Check the voltage at J10-3. The voltage changes from +24 V dc with the printer idle to 0 V dc when the printer runs the print test. If the voltage is incorrect, check the continuity of line J10-3 in the front cable harness to the HVPS. If there is no continuity, replace the cable harness. If there is continuity, replace the HVPS. If the problem continues, replace the engine board.

---

## 3. Diagnostic Aids

This chapter explains the tests and procedures to identify printer failures and verify repairs have corrected the problem.

To run the printer diagnostic tests described in this chapter, you must put the printer in Diagnostic Mode.

---

### Diagnostic Mode

To enter the Diagnostic Mode:

1. Turn the printer off.
2. Press and hold the Go and Return buttons.
3. Turn the printer on.
4. Release the buttons when "Performing Self Test" displays on the operator panel.

The tests display on the operator panel in the order shown:

- Print Registration
- Print Tests
- Hardware Tests
- Duplex Tests (If installed)
- Input Tray Tests
- Output Bin Tests
- Five Bin Mailbox Test
- Base Sensor Test
- Printer Setup
- Error Log
- EP Factory Defaults

### Exiting the Diagnostics Mode

Select Exit Diagnostics to exit the Diagnostics Mode and return to normal mode.

---

## Device Tests

### Quick Disk Test

This test performs a non-destructive read/write on one block per track on the disk. The test reads one block on each track, saves the data, and proceeds to write and read four test patterns to the bytes in the block. If the block is good, the saved data is written back to the disk.

To run the Quick Disk Test:

1. Select the Quick Disk Test from the Device Tests menu.
  - The power indicator blinks while the test is in progress.
  - “Quick Disk Test/Test Passed” message displays if the test passes and the power indicator turns on solid.
  - “Quick Disk Test/Test Failed” message displays if the test failed and the power indicator turns on solid.
2. Press Go, Return, or Stop to return to the Device Tests menu.

### Disk Test/Clean

**WARNING:** This test destroys all data on the disk and should not be attempted on a good disk. Also note that this test may run approximately 1 1/2 hours depending on the disk size.

To run the Disk Test/Clean Test:

1. Select Disk Test/Clean from the Device Tests menu.
  - “Files will be lost/Go or Stop?” message displays to warn the user that all contents on the disk will be lost.
2. To exit the test immediately and return to the Device Tests menu, press Return/Stop. To continue with the test, press Go.
  - If go is selected, “Disk Test/Clean/BAD:000000 00%” message displays. The screen updates periodically indicating the percentage of test completed and the number of bad blocks found.
3. The power indicator blinks during the test. The test can be canceled anytime during the test by pressing Return/Stop.
  - Once the test is complete, the power indicator turns on solid and a message displays.

## 4069-0XX

- “xxxx Bad Blocks/yyyyy Usable” message displays if fewer than 2000 bad blocks are detected. xxxx indicates the number of bad blocks and yyyyyy indicates the number of usable blocks.
  - “xxxx Bad Blocks/Replace Disk” message displays if more than 2000 bad blocks are detected. The disk cannot be recovered because too many bad blocks exist on the disk.
4. Press Go or Return/Stop to return to the Device Tests menu.

## Flash Test

This test causes the file system to write and read data on the flash to test the flash.

**WARNING:** This test destroys all data on the flash because the flash is reformatted at the end of the test.

To run the Flash Test:

1. Select Flash Test from the Device Tests menu.
  - The power indicator blinks while the test is running.
  - “Flash Test/Test Passed” message displays if the test passes and the power indicator turns on solid.
  - “Flash Test/Test Failed” message displays if the test fails and the power indicator turns on solid.
2. Press Go or Return/Stop to return to the Device Tests menu.

## Disabling Download Emulations

Error Code 964: Download Emulation CRC Failure. Checksum failure detected in the emulation header or emulation file.

Error Code 965: Download Emulation Outdated. Time stamps indicate the download emulation and RIP code are incompatible.

To help resolve Download Emulation problems the following steps are necessary to instruct the printer to POR without activating any download emulations.

To Disable the Download Emulation:

1. Turn the printer off.
2. Press and hold the Go and Menu buttons.

## 4069-0XX

3. Turn the printer On and release the buttons once "Performing Self Test" displays.
  - Once the printer is idle, the emulation can be downloaded again.
4. Program the download emulation into the code overlay SIMM again.
5. If these steps do not resolve the problem, replace the code overlay SIMM and download the emulation again.

---

## Duplex Tests

### Duplex Quick Test

This test is used to verify that the Duplex Option Top Margin is set correctly. This test prints a duplexed version of the Quick Test Page that can be used to adjust the Top Margin for the backside of the duplexed page. You can run one duplexed page (Single) or continue printing duplexed pages (Continues) until Return/Stop is pressed.

The paper you choose to print the page on should be either Letter or A4.

To run the Duplex Quick Test:

1. Select Duplex Quick Test from the menu.
2. Select Single or Continuous.
  - The single Duplex Quick test cannot be canceled.

The printer attempts to print the Quick Test Page from the default paper source. If the default paper source only supports envelopes, then the page is printed from Tray 1.

Check the Quick Test Page for the correct offset between the placement of the first scan line on the front and back side of a duplexed sheet.

If adjustment is necessary the Top Margin Offset must be adjusted first. The range of the adjustment is -25 to +25. The Duplex Top Margin Offset range is -20 to +20.

Adjustment of this setting lets you shift up or down the position of the Top Margin. Changing this parameter by 1 unit moves the margin



## 4069-0XX

1/100 inch. A positive offset moves the text down the page and widens the top margin while a negative offset moves the text up the page and narrows the top margin.

3. Press Return/Stop to exit the test.

Check the Top Margin Offset of the base printer.

## Duplex Sensor Test

This test is used to determine whether or not the Duplex sensors and switches are working correctly.

Select Sensor Test from the Duplex Tests menu.

Manually actuate each of the duplex sensors. When the sensor/switch is closed, CL (closed) displays, when the sensor/switch is open, OP (Open) displays.

Duplex input sensor

Duplex exit sensor

Press Return/Stop to exit the test.

## Duplex Motor Test

This test lets you test the duplex unit's paper feed drive system, and verify that the power and velocity values are acceptable.

To run the Duplex Motor Test:

1. Select Motor Test from the Duplex Tests menu. The duplex motor test continues to run until the printer is powered off.
  - The power indicator blinks while the test is running.
  - The duplexer runs the motor at a high speed and then a low speed and takes an average of the power required for each speed.
  - After all the information is computed, the motor turns off.

## 4069-0XX

The following appears on the printer display:

DUPLEX MOTOR AA  
BB CC DD EE FF

To pass the test the following results must display:

AA = 00

BB = in the range of 20 through 3F inclusively (hex)

CC = in the range of 3A through 5D inclusively (hex)

DD = in the range of 11 through 1F inclusively (hex)

Ignore bytes EE and FF.

If the test fails, remove the drive belt from the duplex D.C. motor and run the motor test again. For the duplex D.C. motor to pass the test the following results must display:

AA = 00

BB = in the range of 29 through 3E inclusively (hex)

CC = in the range of 35 through 51 inclusively (hex)

DD = in the range of 0C through 13 inclusively (hex)

For the duplex drive system to pass the test the following results must display:

AA = 00

BB = in the range of 29 through 3F inclusively (hex)

CC = in the range of 3A through 5D inclusively (hex)

DD = in the range of 11 through 1F inclusively (hex)

2. Press Return/Stop to exit the test.

## Duplex Feed 1 Test

This test feeds a blank sheet of paper to the duplex paper stop position 1.

To run the Duplex Feed 1 Test:

1. Select Duplex Feed 1 from the Duplex Test menu.
  - The power indicator blinks while the paper is feeding.
  - "Duplex Feed 1/Feeding" message displays while the paper is feeding through the printer.
  - "Duplex Feed 1/Clear Paper" message displays when the paper reaches paper stop position 1 and the power indicator turns on solid.

## Duplex Feed 2 Test

This test feeds a blank sheet of paper to the duplex paper stop position 2.

To run the Duplex Feed 2 Test:

1. Select Duplex Feed 2 from the Duplex Test menu.
  - The power indicator blinks while the paper is feeding.
  - "Duplex Feed 2/Feeding" message displays while the paper is feeding through the printer.
  - "Duplex Feed 2/Clear Paper" message displays when the paper reaches the duplex paper stop position 2 and the power indicator turns on solid.

---

## Error Log

### Viewing the Error Log

The error log is helpful to the servicer by providing a history of printer errors. The error log contains the 12 most recent errors that have occurred on the printer. The most recent error displays in position 1 and the oldest error displays in position 12 (if 12 errors have occurred). If an error occurs after the log is full, the oldest error is discarded. Identical errors in consecutive positions in the log are entered. All 2xx and 9xx error messages are stored in the error log.

To view the Error Log:

1. Select Display Log from the Error Log menu.
  - The Error log displays on three screens as only four entries display at a time.
2. To move to the next screen press Menu> to move forward or <Menu to move backward.
3. Press Return/Stop to exit the Error Log.

### Clearing the Error Log

To clear the Error Log:

1. Select Clear Log from the Error Log menu.
2. Select "YES" to clear the Error Log or "NO" to exit the Clear Log menu.
  - If "YES" is selected, the Empty Error Log displays on the screen.
3. Press Return/Stop to exit the Clear Log menu.

---

## Hardware Tests

The following Hardware Tests can be selected from this menu:

- LCD Test
- Button Test
- DRAM Memory Test
- ROM Memory Test
- Parallel Wrap (if available)
- Serial Wrap (if available)
- Serial 1 Wrap (if available)
- Serial 3 Wrap (if available)

### LCD Test

To run the LCD Test:

1. Select LCD Test from the Diagnostic menu.
  - The LCD test continually executes the LCD display test.
2. Press Return/Stop to cancel the test.

### Button Test

To run the Button Test:

1. Select Button Test from the Diagnostic menu.
  - With no buttons pressed, several OP (Open) appear on the display.
2. Press each button one at a time and a CL (Closed) displays in place of an OP. The proper operation of each button can be checked.
3. Press Return/Stop to cancel the test.

## SDRAM Memory Test

The purpose of this test is to check the validity of SDRAM, both standard and optional. The test writes patterns of data to SDRAM to verify that each bit in memory can be set and read correctly.

To run the SDRAM Memory Test:

1. Select SDRAM Memory Test from the menu.
  - The power indicator blinks indicating the test is in progress.
2. Press Return/Stop to exit the test.

P:##### represents the number of times the memory test has passed and finished successfully. Initially 000000 displays with the maximum pass count being 999,999.

F:##### represents the of time the memory test has failed and finished with errors. Initially 00000 displays with the maximum fail count being 99,999.

Once the maximum pass count or fail count is reached, the test is stopped, the power indicator is turned on solid, and the final results display. If the test fails, the message SDRAM Error, displays for approximately three seconds and the failure count increases by 1.

## ROM Memory Test

The ROM Memory Test is used to check the validity of the controller board code and fonts.

To run the ROM Memory Test:

1. Select ROM Memory Test from the menu. P and F represent the same numbers for DRAM.
  - The power indicator blinks indicating the test is in process.  
The test runs continuously.
2. Press Return/Stop to exit the test.

## 4069-0XX

Each time the test finishes, the screen updates with the result. If the test passes, the Pass Count increases by 1, however if the test fails, one of the following messages displays for approximately three seconds:

ROM Checksum Error

ROM Burst Read Error

Once the maximum pass count or fail count is reached, the test stops with the power indicator on solid. The final results display on the screen.

## Parallel Wrap Test

This test is used with a wrap plug to check operation of the parallel port hardware. Each parallel signal is tested.

To run the Parallel Wrap Test:

1. Disconnect the parallel interface cable and install the wrap plug (P/N 1319128).
2. Select the Parallel Wrap Test from the menu.
  - The power indicator blinks indicating the test is in progress. The test runs continuously until canceled.

Each time the test finishes, the screen updates. If the test passes, the Pass Count increases by 1, however if the test fails, one of the following messages displays for approximately three seconds:

Sync Busy Error

Byte Interrupt Request Error

Strobe Interrupt Request Error

Init Fail Error

Init Busy Error

Init Rise Error

Host Busy Error

RAM Data FF Error

RAM Data AA Error

RAM Data 00 Error

RAM Data 55 Error

DMA Count Error

## **4069-0XX**

DMA Address Error  
DMA Interrupt Error  
DMA Memory Error  
DMA Background Error  
Clear Init Rise Error  
False Init Rise Error  
Autofeed Rising Interrupt Error  
Clear Autofeed Rise Error  
False Autofeed Rise Error  
Autofeed Falling Interrupt Error  
Clear Autofeed Fall Error

Once the maximum count is reached the test stops. The power indicator goes on solid and the final results display.

Press Return/Stop to exit the test.

## **Serial Wrap Test**

This test is used to check the operation of the Serial Port Hardware using a wrap plug. Each signal is tested.

To run the Serial Wrap Test:

1. Disconnect the serial interface cable and install the wrap plug.
2. Select the appropriate Serial Wrap Test from the menu: Serial Wrap, Serial 1 Wrap, Serial 2 Wrap or Serial 3 Wrap. P and F represent the same numbers for DRAM.
  - The power indicator blinks indicating the test is running.
3. This test runs continuously unless canceled by pressing Return/Stop.



## 4069-0XX

Each time the test finishes, the screen updates with the result. If the test passes, the Pass Count increases by 1, however if the test fails, one of the following failure messages displays for approximately three seconds and the Fail Count increases by 1:

- Receive Status Interrupt Error
- Status Error
- Receive Data Interrupt Error
- Transmit Data Interrupt Error
- Transmit Empty Error
- Threshold Error
- Receive Data Ready Error
- Break Interrupt Error
- Framing Error
- Parity Error
- Overrun Error
- Data Error
- Data 232 Error
- Data 422 Error
- FIFO Error
- DSR Error
- DSR PIO Error
- DSR Interrupt Error
- CTS Error
- CTS PIO Error
- CTS Interrupt Error

Once the maximum count is reached the test stops. The power indicator goes on solid and the final results display.

Press Return/Stop to exit the test.

## Input Tray Tests

### Input Tray Feed Test

This test lets the servicer observe the paper path as media is feeding through the printer. A blank sheet of paper feeds through the printer as the laser turns off during this test. The only way to observe the paper path is to open the lower front door that is used to access the envelope or multipurpose feeder. The paper is placed in the output bin.

To run the Input Tray Feed Test:

1. Select Input Tray Feed Test from the menu.
2. Select the input source from the sources displayed on the Feed Test menu. All installed sources are listed.
3. Select either Single (feeds one sheet of media from the selected source) or Continuous (continues feeding media from the selected source until Return/Stop is pressed).
4. Press Return/Stop to exit test.

### Input Tray Sensor Test

This test is used to determine if the input tray sensors are working correctly.

To run the Input Tray Sensor Test:

1. Select the Sensor Test from the Input Tray Test menu.
  - "Input Tray/Empty=OP/Pass=OP" message displays.
  - EM = Input Tray Empty Sensor
  - LO = Input Tray Paper Low Sensor
  - P = Input Tray Pass Thru Sensor
2. Once this message displays, the servicer can manually actuate each sensor. The tray empty sensor can be actuated by hand, however a sheet of paper can be used to cover the pass through sensor. When the sensor is closed, CL displays, when the sensor is open, OP displays.
3. Press Return/Stop to exit the test.

## 4069-0XX

The multipurpose tray and the envelope feeder do not have a paper low sensor. The multipurpose tray does not have a pass through sensor.

### Output Bin Test - Standard Bin

This test is used to verify if the standard bin sensor is working correctly.

To run the Standard Bin Sensor Test:

1. Select Output Bin Tests from the Diagnostic Menu.
2. Select Output Bin Tests - Sensor Tests.
3. Select Sensor Tests - Standard Bin.
  - “Standard Bin/Full=CL” message displays.

Manually actuate the bin sensor by moving the flag in and out of the sensor. The display indicates OP (open) when the flag is out of the sensor and CL (closed) when the flag is in the sensor.

4. Press Return/Stop to exit the test.

### Output Bin Feed Test

**Note:** If the “Configure Bins” printer setting is link rather than mailbox, the printer selects its own internal bin linking regardless of which output bin is selected for the feed test

This test is to verify that media can be fed to a specific output bin. No information is printed on the media because the printhead is not turned on during this test.

To run the Output Bin Feed Test:

1. Select Feed Test from the Output Bin Test menu.
2. Select the output bin you want the paper to exit into. All output bins installed on the printer are shown on the feed test menu.
3. Select either Single (one sheet of media feeds to the selected output bin) or Continuous (media continues feeding to the selected output bin) until Return/Stop is pressed.
4. Press Return/Stop to exit the test.

## **Output Bin Sensor Test**

This test is used to verify if the output bin sensors are working correctly.

To run the Output Bin Sensor Test:

1. Select Sensor Test from the Output Bin Test menu.
  - "Output Bin/Full=OP/Input=OP" message displays.
  - Full = Output Bins Full Sensor
  - Pass = Output Bins Pass Thru Sensor
2. Once the message displays, the servicer can manually actuate each of the output bin sensors. The bin full sensor can be actuated by hand, however a sheet of paper can be used to cover the bin's pass thru sensor. When the sensor is closed CL displays, and when the sensor is open OP displays.
3. Press Return/Stop to exit the test.

## **Output Bin X Sensor Test**

### **Output Expander or High Capacity Output Stacker**

To run the Output Bin X Sensor tests:

1. Select Output Bin tests from the menu.
2. Select Output Bin tests - Sensor Tests.
3. Select Sensor Tests - Output Bin X.
4. Press Return/Stop to exit the test.

The following is displayed:

Output Bin X

P=OP F=OP NF=CL

P = Pass Thru Sensor

F = BIN FULL Sensor (lower part of dual sensor)

NF = Near Full Sensor (upper part of dual sensor)

Once the message displays, you can manually actuate each of the output bin sensors. For all the sensors except the output level sensor, when the sensor is closed CL displays and when the sensor is open OP displays.

## 4069-0XX

If the high capacity output stacker is selected then the following is displayed:

HC BIN 1

TP=OP, P=OP, F=OP, NF=OP

IP = high capacity output stacker top position sensor

P = high capacity output stacker passthru sensor

F = high capacity output stacker full sensor

NF = high capacity output stacker near full sensor

If the 5-bin mailbox is selected the following is displayed:

<output bin> (output bin displayed on line 1 = output bin 1, output bin2, output bin3, output bin4 or output bin 5 for the bin selector)

P1 = 5-bin mailbox first passthru sensor

P2 = 5-bin mailbox second passthru sensor

L = EM, indicates 5-bin x empty

L = NL, bin contains media but the bin is not near full on full

L = NF, indicates bin is near full

L = FL, indicates bin is full

## Base Sensor Test

This test is used to determine if the sensors located inside the printer are working correctly.

The following sensors can be checked:

Toner Optical Sensor

Input Sensor

Output Sensor (Fuser Exit)

Narrow Media Sensor

Front Door Sensor (Upper Front Cover)

To run the Base Sensor Test:

1. Select the Base Sensor Test.
  - The operator panel displays OP for open and CL for closed.
2. Manually toggle the sensors by hand to verify that each sensor switches from open to closed.

## 5-Bin Mailbox Diverter Test

**Note:** This test checks the operation of each mailbox output diverter. Also if more than one 5-bin mailbox option is installed, the test checks all of the diverters installed on the printer.

When the test is selected from the diagnostic menu the following is displayed:

Diverter Test Running

This is a single test. The test terminates upon completion.

---

## Print Registration

The print registration range is as follows:

Bottom Margin: -20 to +20 Each increment causes approximately .55 mm shift in the bottom margin.

Top Margin: -25 to +25

Left Margin: -25 to +25

Right Margin: -10 to +10

To set Print Registration:

1. Select Registration from the Diagnostic menu.
2. The Top margin sign/value pair blinks. This indicates it is the margin value being changed.
3. To select the margin value to be changed press Select until the margin value pair you want to change is blinking.
4. To change the margin value press either Menu> or <Menu. When the value you want is displayed, press Select to save the value.
5. To exit the Registration menu, press Return.

To verify the margin values are correct you must print the "Quick Test Page" from the registration screen. Press Go to print the test page. While printing the Quick Test Page the "Quick Test Printing" message displays. Once the Quick Test Page completes printing, the Registration screen displays again.

The "Quick Test Page" should be printed on letter or A4 paper.

---

## Printer Setup

### Setting the Page Count

This lets the servicer change the page count from the diagnostic menu. This is used whenever the engine board is replaced because this board contains the printer's NVRAM Memory where the page count is stored.

To set the Page Count:

1. Select Page Count from the Diagnostic menu.
  - The current page count displays.
  - The leftmost digit blinks, indicating it is the first digit to be changed.
2. Press either Menu> or <Menu until the value you want displays.
3. Press Select to move to the next digit, press Menu> or <Menu until the value you want displays. Continue with each digit until you set the page count. You can skip any digit by pressing Select.
4. Press Select to save the new page count in NVRAM.
5. Press Return/Stop to exit the Diagnostic menu.

### Viewing the Permanent Page Count

The Permanent Page Count can only be viewed and cannot be changed.

To view the Permanent Page Count:

1. Select Permanent Page Count from the menu.
2. Press Return/Stop to exit the Diagnostic menu.



## **Maintenance Page Count**

This counter is reset by the servicer after a “80 Scheduled Maintenance” message displays (250K copies) and a maintenance kit is installed.

To view the Maintenance Page Count:

1. Select Maintenance Count Value from the diagnostic menu.
2. Press Return to go to the previous menu.

To reset the Maintenance Page Count to zero:

1. Select Reset Maintenance Count. Pressing Select causes the maintenance page counter to reset to zero.
  - Reset Maintenance Count Saved displays momentarily. When the reset operation is complete, the menu returns to the Printer Setup Reset Maintenance Count screen.

## **Setting Configuration ID**

The configuration ID is used to communicate information about certain areas of the printer that cannot be determined using hardware sensors. The Configuration ID is originally set at the factory when the printer is manufactured, however it requires resetting whenever you replace the engine board and can be set on the operator panel. However the Configuration ID is the only diagnostic function displayed until a valid ID is entered.

To set the Configuration ID:

1. Enter the Diagnostic Mode.
2. Select Configuration ID from the Printer Setup menu.
  - The current ID displays on the screen. The Configuration ID is on a label located inside the printer. The label is attached to the top front cover hinge assembly and is visible when the top front cover is open.
  - The leftmost digit blinks indicating that it is the first digit to be changed.
3. To change the value, press either Menu> or <Menu until the value you want is reached. Press Select to move to the next digit, or press Select again to skip a digit. Change each digit as required. When the last digit is changed, press Select to

## **4069-0XX**

validate the Configuration ID. If the ID is invalid then "INVALID ID" message displays on Line 2 before the ID redisplay. You have to reenter the Configuration ID until a valid ID is verified. If the ID is valid then the ID is saved in NVRAM and the printer automatically PORs to activate the new setting.

**Note:** When the printer PORs it does so in the normal mode.

## **Restore EP Factory Defaults**

To restore each of the printer settings contained in the EP Setup menu to their factory default value select Restore from the menu. To exit the menu without restoring the settings to the factory default values, select Do Not Restore. Sometimes this is used to help correct print quality problems.

## **Fuser Temperature**

This adjustment can be used to help solve some customer problems with paper curl on low grade papers and or problems with letter heads on some types of media.

The fuser temperature can be adjusted as follows:

- NORMAL
- LOWER
- LOWEST

## **Warm Up Time**

You can change the amount of time the printer warms up before allowing pages to print by changing this setting from 0 to 5. The factory sets the warm up at 0 or no warm up time. This time period allows the backup roll to heat up and helps reduce curl in some environments.

## **Transfer**

The transfer can be adjusted as follows:

- LOW
- MEDIUM
- HIGH

## 4069-0XX

### Print Contrast

The print contrast setting controls the developer voltage offset.

The print contrast can be adjusted as follows:

- LOW
- MEDIUM
- HIGH

### Charge Roll

The charge roll can be adjusted as follows:

- LOW
- MEDIUM
- HIGH

---

## Print Tests

The purpose of the diagnostic Print Tests is to verify that the printer can print on media from each of the installed input options. Each of the installed options is listed in the following order in the menu:

Tray 1  
Tray 2 (if installed)  
Tray 3 (if installed)  
Tray 4 (if installed)  
Tray 5 (if installed)  
Multipurpose Feeder (if installed)  
Envelope Feeder (if installed)

For each input source selected you have the following choice:

- Single (prints the Print Test Page once)
- Continuous (continue printing the Print Test Page until Return or Stop is pressed).

## 4069-0XX

The contents of the Print Test Page varies depending on the media installed in the selected input source.

**Note:** The Print Test Page always prints on one side of the paper, regardless of the duplex setting or the presence of a duplex option.

If a source is selected that contains envelopes, an envelope test pattern is printed. If continuous is selected, the test pattern is printed only on the first envelope.

To run the Print Test Page:

1. Select Print Tests from the Diagnostic menu.
2. Select the media source.
3. Select Single or Continuous.
  - If single is selected no buttons are active during printing.
  - If continuous is selected, Return or Stop can be selected to cancel the test.

Check each Test Page from each source to assist in Print Quality and Paper Feed problems.

## Print Quality Test Pages

The purpose of this diagnostic function is to allow printing of the print quality test pages with the toner cartridge lockout function disabled. The print quality test consists of three pages. Page one contains a mixture of graphics and text. Pages two and three only contain graphics. If duplex is turned On, the pages are duplexed, otherwise the pages are printed on one side. The Print Quality Test pages are printed in English and must always be printed on letter, legal or A4 paper.

**Note:** The print quality test pages can also be printed from the configuration menu, however a cartridge must be installed with a machine class ID matching the machine class ID stored in NVRAM. Some diagnostic information may be printed on the pages when printing from this menu.

## 4069-0XX

To run the Print Quality Test Pages:

1. Turn the printer off.
2. Press and hold Select and Return.
3. Turn on the printer.
4. Release the buttons once Performing the Self Test displays.
5. The printer performs its normal POR cycle then print one copy of the Print Quality Test pages. If you want more than one copy, perform these steps again.

The following is printed on page 1.

- Diagnostic EP Setup:
  - fuser temperature, warm up time, transfer, print contrast and charge roll settings.
- Contents of the Diagnostic Error Log.
- Printer configuration information:
  - printer serial number, controller code level, engine code level, operator panel code level, smart option code levels, font versions, and so on.
- Values for the Quality Menu settings used to print the pages.

## Printing Menu Settings Page

**Note:** This test page must be printed on letter, legal or A4 paper.

To print the Menu Settings Page:

1. Select the TESTS MENU.
2. Select Print Menus from the TESTS MENU.

The page contains the following information:

- A list of all the printer settings contained in the control panel menus and their values.
- A list of the installed options and features such as RAM memory SIMMs, optional input paper trays, envelope feeder, duplexer, output bins, flash or disk.
- Printer information such as serial number, page count, installed RAM, engine code level, RIP code level, envelope feeder code level, tray 1-5 code levels, output bin 1-3 code levels, control panel code levels, font ROM version and SRAM availability.

---

## Autocompensator Operation

The autocompensator is a paper pick device that generates its own normal force. This force generation is inherent in the fundamental design of the pick arm. If light media is used, it picks very gently. If a heavy media is used, it picks very aggressively. No customer adjustments are necessary, therefore no special trays are needed for card stock or labels.

The gearing in the arm is designed so the input torque from the motor produces a movement about the pivot of the arm. This movement produces a downward force at the pick rolls. The friction between the pick roll and the paper produces a frictional locking condition. If the paper is physically held and not allowed to feed, then the motor stalls. Slippage between the roll and the paper is theoretically impossible. When the motor is energized the pick rolls are driven down into the stack increasing the normal force and drive force until the bending strength of the paper is overcome and the paper bends and moves up the dam. Once this critical threshold is achieved the normal force remains at a level just high enough to reliably feed the paper. Rather than having a fixed spring force for feeding all weights of paper like the D-roll, this device has its own mechanical logic for producing only enough pick energy to feed a single sheet of paper regardless of its stiffness.

High normal force is one of the most significant contributors to double feeding paper. The pick arm is counter balanced by an extension spring located on the pick arm to reduce weight in the rest state. This spring is factory set to exert no more than ten to fifteen grams on the stack. This is as light as can be realistically set and always guarantee there is some force to start the autocompensating phenomena. This spring is not to be considered an adjustment for feeding problems unless it is obvious that the pick arm cannot fall all the way down to the bottom of the tray or has come loose.

## **4069-0XX**

Poor gear efficiency can cause the arm to generate higher normal forces. If the pick assembly is noisy, replacement may be required.

The arm must pivot freely through its full range of motion. On 500 sheet trays there are wrap springs located on the pivot arbors of the arm. These springs aid to prevent the arm from bouncing. If the arm appears to be binding or sticky near the bottom of the tray these springs may be the problem. Reducing the tension on the counterbalance spring may be used as a temporary fix to get additional weight at bottom, until the pick assembly can be replaced. However, the counterbalance spring is not to be considered an adjustment for feeding problems.

---

## **Autoconnect System, Paper Tray Options, Envelope Feeder and Output Expander Operations**

### **Electrical**

#### **Autoconnect Cabling and Connectors**

The printer options make electrical connection automatically or autoconnects requiring no external cables when the option is mechanically installed under the printer. Communication between the option and the base printer stops when you remove an option located above or below the printer. The printer no longer recognizes the option and deletes associated messages. Each installed option below the base printer provides an electrical autoconnect to the option attached below it. The output expander option attached above the base printer provides power to the option above it. We do not recommend to attach or "Hot Plug" any options with the base printer power turned On.

## **4069-0XX**

### **Duplex Option**

The duplex option interface is a six pin autoconnector that provides a +24 V dc, +24 V dc return, serial interface transmit signal, serial interface receive signal and two ground pins. The duplex option receives the +24 V dc from the base printer for the duplex motors and also converts the voltage to +5 V dc for duplex electronics.

Duplex chassis grounding is provided from the printer to the duplex option through a ground spring attached to the frame and base of the printer. The ground connection is automatically made when the option is installed below the printer.

The paper input sensor is located in the rear of the duplex unit under the input paper guide. The rear cover open switch is located on the rear cover assembly. The paper exit sensor is located on the left frame assembly. The jam removal tray open switch is located at the end of the left frame assembly. There are no switches in the level 2 duplex option.

### **Option Microcode**

The options are "Smart Options" or options that have a system board. The option system board has a microprocessor that controls the option mechanism. A software architecture is provided that controls the option and communicates information such as paper path status, sensor or switch status, motor status and so on to the base printer.

---

## **Fuser Operation**

The fuser in the Optra T printers is made up of two primary assemblies. The first assembly is the top fuser cover which contains the thermistor/cable, thermal fuse, cable assembly, left and right lamp brackets and cover. This is a complete assembly and the parts cannot be individually replaced as in previous Lexmark laser printers.

The thermal fuse (two fuses in series) protects the fuser assembly and surrounding parts from ignition in the event of a failure in the fuser control circuitry by opening the AC circuit to the lamp. The thermistor assembly is designed to keep the temperature of the fuser hot roll within a predetermined temperature by being in contact



## **4069-0XX**

with the fuser hot roll and changes resistance as the temperature of the hot roll increases. The thermistor resistance changes from approximately 150K ohms to approximately 260K ohms as the temperature of the fuser hot roll increases. The thermistor is connected to the fuser control board connector J2-1 and J2-2 and from J2 to J1-2 and J1-3 on the fuser control board to J2-6 and J2-7 on the engine board. J2-6 (TEMPIN+) and J2-7 (TEMPIN-) are connected to module PLCC U9. U9 monitors the change in thermistor resistance and sends a signal (HEATON) from J20-A25 through the interconnect board to CN3-9 on the LVPS to signal the triac to turn the fuser lamp On or Off to maintain the correct fuser temperature.

The voltage drop across the thermistor is proportional to the fuser temperature and varies from approximately 2.0 V dc (cold) to 2.3 V dc (warm during idle) to approximately 2.7 V dc during continuous printing. These voltages are assuming the fuser temperature is set to normal. The HEATON signal from CN3-9 varies from 0 V dc (lamp On) to +5 V dc (lamp Off) and is connected to the cathode of an Opto triac to control the fuser lamp. The second part of the assembly is the fuser frame which contains the hot roll, backup roll, and associated parts as well as the paper exit guide assembly, narrow media sensor, fuser control board (which has the exit sensor mounted on the board) and the envelope conditioner solenoid.

---

## **Paper Feed Jams**

### **Paper Jams - Base Printer**

#### **Error Message 200 - Paper Jam - Remove Cartridge**

This message indicates that paper is jammed at the printer input sensor. This condition can be caused by the paper jamming prior to activating the input sensor flag, the sensor not detecting paper over the sensor or paper arriving at the sensor too late.

#### **Error Message 201 - Paper Jam - Remove Cartridge**

This message indicates the paper is jammed between the printer's input and exit sensors. This condition can be caused by the paper exiting the input sensor too late or jamming in the fuser assembly prior to activating the exit sensor flag in time or not at all.

## **4069-0XX**

### **Error Message 202 - Paper Jam - Open Rear Door**

This message indicates the paper is jammed at the printer exit sensor. This can be caused by the paper arriving at the sensor too late, the paper is jammed in the fuser assembly or is jammed exiting the fuser assembly in the redrive assembly or the exit sensor flag is not operating correctly.

### **Paper Jams - Options**

#### **Error Message 230 Paper Jam - Check Duplex**

The paper is most likely jammed in the duplex unit, however the paper can also be jammed in the redrive at the input to the duplex option. The redrive assembly may not be correctly installed or locked in position or the duplex link is bent and not aligned properly to allow paper to feed correctly into the duplex option.

#### **Error Message 24x (x=Tray 1 through 5) Paper Jam Check Tray x.**

The paper has not cleared the pass through sensor or reached the pass through sensor of the option above tray x.

#### **Error Message 250 - Paper Jam - Check MP Feeder**

The paper is jammed in the multipurpose feeder and has not reached the base machine input sensor or has not reached the input sensor in time.

#### **Error Message 260 Paper Jam - Check Envelope Feeder**

An envelope is jammed in the envelope feeder or has not reached the base machine input sensor.

#### **Error Message 27x Paper Jam - Check Bin x.**

Paper is jammed in output bin x (X=bin 1 thru 3). Generally this message appears when the paper has not cleared the exit sensor in time, has jammed in the redrive assembly or has not fed into the output bin selected.

---

## 4. Repair Information

**WARNING:** Read the following before handling electronic parts.

---

### Handling ESD-Sensitive Parts

Many electronic products use parts that are known to be sensitive to electrostatic discharge (ESD). To prevent damage to ESD-sensitive parts, follow the instructions below in addition to all the usual precautions, such as turning off power before removing logic boards:

- Keep the ESD-sensitive part in its original shipping container (a special “ESD bag”) until you are ready to install the part into the machine.
- Make the least-possible movements with your body to prevent an increase of static electricity from clothing fibers, carpets, and furniture.
- Put the ESD wrist strap on your wrist. Connect the wrist band to the system ground point. This discharges any static electricity in your body to the machine.
- Hold the ESD-sensitive part by its edge connector shroud (cover); do not touch its pins. If you are removing a pluggable module, use the correct tool.
- Do not place the ESD-sensitive part on the machine cover or on a metal table; if you need to put down the ESD-sensitive part for any reason, first put it into its special bag.
- Machine covers and metal tables are electrical grounds. They increase the risk of damage because they make a discharge path from your body through the ESD-sensitive part. (Large metal objects can be discharge paths without being grounded.)
- Prevent ESD-sensitive parts from being accidentally touched by other personnel. Install machine covers when you are not working on the machine, and do not put unprotected ESD-sensitive parts on a table.
- If possible, keep all ESD-sensitive parts in a grounded metal cabinet (case).
- Be extra careful in working with ESD-sensitive parts when cold-weather heating is used because low humidity increases static electricity.

---

## Adjustment Procedures

### Duplex Motor Drive Belts

Do the duplex motor belt and drive belt adjustment whenever you remove or replace the duplex motor or loosen the motor or drive belt idler pulley.

Service Tip: Excessive belt tension can result in stalling the duplex motor. Too little belt tension can result in belt slippage.

To do the duplex drive belt adjustment:

1. Do the removal procedure “Duplex Front Cover Door” on page 4-19 to access the drive belt idler pulley.
2. Loosen the idler pulley mounting screw and position the idler to provide 3 mm ( $\pm 5$  mm) drive belt deflection.
3. Tighten the idler pulley mounting screw being careful to maintain the adjustment.
4. Reassemble the duplex unit.

To do the duplex motor belt adjustment:

1. Do the removal procedure “Duplex Motor” on page 4-20 to access the motor mounting screws but do not remove the motor.
2. Loosen the screw in the elongated adjustment slot and position the motor to provide 3 mm ( $\pm 5$  mm) motor belt deflection.
3. Tighten both mounting screws being careful to maintain the adjustment.
4. Reassemble the duplex unit.

## Fuser Solenoid Adjustment

Perform the fuser solenoid adjustment whenever you replace the fuser solenoid. Adjust the fuser solenoid while installed in the printer. Adjust the screw on the eccentric mounted on the solenoid housing to provide an air gap between the rear of the solenoid stator and the solenoid armature.

Printer Models	Solenoid Air Gap
610/612	4.0 mm
614/616	4.5 mm

## Gap Adjustment

The gap adjustment allows you to increase the minimum gap between sheets of paper as they are fed through the printer. This adjustment does not reduce the printer's overall performance such as pages per minute but can help in reducing the amount of curl of some printed media thus improving media stacking in the output bin.

1. Enter the Diagnostic Mode
2. Select EP SETUP from the Diagnostic Menu.
3. Select GAP ADJUST
4. The range of the GAP adjustment is 0 to 255. Adjust the gap setting by using the Menu < > button to select the value. If GAP=0 displays, it indicates a factory setting to minimum gap. Select a value and run several copies of the media that displays a curl problem. It may take several tries before improvement is noticed.

**Note:** This setting has no effect when printing in duplex mode.

## **Printhead Assembly Adjustment**

Do the printhead assembly adjustment whenever you remove or replace the printhead assembly or loosen the mounting screws.

Install the new printhead with the three mounting screws centered in the slots in the printhead frame assembly. Leave the screws loose enough to allow the printhead assembly to move from side to side within the slots. It is necessary to perform a registration adjustment before locking down the three printhead mounting screws.

To perform the registration adjustment:

1. Turn the printer off.
2. Press and hold: Return and Go.
3. Turn the printer On and release the buttons when "Performing Self Test" displays.
4. Select Registration from the menu.
5. Select Quick Test Page. The test page should only be printed on letter or A4 paper from Tray 1. The Quick Test Page consists of alignment diamonds, horizontal lines that can be used for skew adjustment, page count setting, printer serial number code levels and print registration settings.
6. Check the Quick Test Page for any sign of skew by checking the diamonds at the top left and top right of the test page for equal distance from the top of the page. If any adjustment is necessary, adjust the left or right printhead mounting screws and check the skew again by running another Quick Test Page. This procedure may take two or three attempts before you get satisfactory results.
7. When you have the correct adjustment, gently tighten the printhead mounting screws being careful not to move the printhead assembly.

## Paper Alignment Assembly Adjustment

Do the alignment assembly adjustment whenever you replace the alignment assembly. Always print a copy of the Quick Test Page before making any adjustments to the alignment assembly reference adjustment screw. When replacing the alignment assembly, it is necessary to back the reference adjustment screw out far enough to remove the old assembly and install the new one.

If you are replacing the alignment assembly go to step a. If you are only adjusting the reference adjustment screw go to step b.

- a. Print a copy of the Quick Test Page and check the margin adjustments printed on the test page. These settings should be within the range specified in **"Print Registration" on page 3-19**.


Do the reference adjustment if you are sure the margins are set correctly.

1. Loosen the locknut on the inside rear of the alignment assembly.
2. Remove the two screws holding the alignment assembly to the left side frame.
3. Back the reference adjustment screw out far enough to allow the alignment assembly to be removed from the printer. It is not necessary to completely remove the screw.
4. Install the new alignment assembly. Turn the reference screw clockwise with a 7 mm nut driver until it touches the back of the reference plate and tighten the nut with a 5.5 mm wrench.

The reference adjustment screw can be adjusted without loosening the nut. Turn the screw clockwise a few turns and print a copy of the Quick Test Page as you check the diamonds on the left margin. Continue adjusting the screw as you check the results of each adjustment on a new test page until you obtain the results you want.

## 4069-0XX


- b. Print a copy of the Quick Test Page and check the margin adjustments printed on the test page. These settings should be within the range specified in **"Print Registration" on page 3-19**. The reference screw can be adjusted without loosening the locknut. Turn the screw a few turns and print a copy of the Quick Test Page as you check the diamonds on the left margin. Continue adjusting the screw as you check the results of each adjustment on a new test page until you obtain the results you want.





## Screw Identification Table



The following table contains screw types, locations, and quantities necessary to service the printer. Each screw callout in the removal procedure graphic displays the screw reference number listed in the table. Pay careful attention to each screw type location when doing removals. You must install the correct screw type in each location during reassembly.

Reference Number	Screw Type	Location	Purpose	Qty
<div>102</div> <div></div>	M3.5x8 mm Thread Cutting	right side frame to center pan	attach	1
		toner level sensor	mounting	1
		charge roll	mounting	1
		main drive gearbox	mounting	3
		EP module to left and right side frame	attach	9
		developer drive assembly	mounting	2
		stacker duct to frame	mounting	2
		cartridge hold down assembly	mounting	2
		MPT deflector	mounting	2
		interconnect board shield ground	attach	2
		engine board shield to frame	attach	1
		laser cover	mounting	4
		deflector	mounting	2




**4069-0XX**





Reference Number	Screw Type	Location	Purpose	Qty
102	M3.5x8 mm Thread Cutting	spring	mounting	1
		controller board	mounting (front)	2
		integrated tray ITC board	mounting	2
		stacker support to right side frame	attach	2
104	M3.5x12 mm Thread Cutting	engine board shield to left frame	attach	1
		paper alignment assembly	mounting	2
		toner cartridge guide track	mounting	2
		left side frame to center pan	attach	3
		right side frame to center pan	attach	2
		deflector	mounting	2
201	M3x5 mm Taptite	INA cover (2 screws per cover)	attach	6
		interconnect board	mounting	5

## 4069-0XX

Reference Number	Screw Type	Location	Purpose	Qty
202 	M3x6 mm Taptite	outer shield	mounting	6
		inner redrive deflector	mounting	2
		interconnect board to center pan	mounting	2
		engine board (bottom holes)	mounting	2
		controller board to interconnect board ground	attach	2
		controller board to inner shield	mounting	2
		controller board (back)	mounting	2
		engine board to interconnect shield ground	attach	1
		lower stacker duct	mounting	1
		ground cables to ground (center pan - front)	attach	1
		cable clip (main drive gearbox, BTM)	mounting	2
		fuser screw	mounting	7
203 	M3x8 mm Taptite	LVPS	mounting	2
		auto compensator hanger bracket	mounting	1

**4069-0XX**

Reference Number	Screw Type	Location	Purpose	Qty
235		HVPS board	mounting	1
237		developer drive ground (bottom hole)	attach	1
232		stacker duct	mounting	1
		engine board	mounting	2
		controller to shield	mounting	2
		controller board	mounting	2
		in pan	mounting	2
		shield ground	attach	1
		LVPS	mounting	2
		fuser cover	mounting	2
		cable clip	mounting	2
		outer shield	mounting	6
		ina cover	mounting	4

Reference Number	Screw Type	Location	Purpose	Qty
323 	M3.5x8 mm Plastite Thread Forming	autocompensator	mounting	3
324 	M3.5x10 mm Plastite Thread Forming	right side cover	mounting	1
		right side frame to pan	attach	3
		left side frame to pan	attach	1
397 	M3x6 mm SEMS Machine Screw with washer	fuser board	mounting	1
425 	M3.5x12 mm Plastite Thread Forming with washer	printhead to EP frame	mounting	3

## Removal Procedures


**CAUTION:** Remove power from the printer before you connect or disconnect any cable or electronic board or assembly for personal safety and to prevent damage to the printer. Use the hand grips on the side of the printer. Make sure your fingers are not under the printer when you lift or set the printer down.

**Note:** Some removal procedures require removing cable ties. You must replace cable ties during reassembly to avoid pinching wires, obstructing the paper path, or restricting mechanical movement.

### Covers

#### Left Door


1. Open the upper and bottom front covers.
1. Press the two left door latch buttons (A) and open the left door.
2. Release the left door from the rear hinges and remove the door.



**4069-0XX**

## **Right Cover**


1. Open the upper and bottom front covers.
2. Release the cover latch (A) and remove the right cover mounting screw (B).



## 4069-0XX

3. Remove the redrive assembly.
4. Remove the right side cover mounting screw (B).
5. Remove the right side cover.

B (324)






**4069-0XX**

### **Upper Front Cover**

1. Raise the upper front cover.
2. Remove the upper front cover mounting screws (A).
3. Rotate the cover upward to allow the rear cover hinges to clear the mounting slots and remove the cover.


A (323)



## 4069-0XX

### Laser Assembly Cover

1. Remove the left door.
2. Remove the right cover.
3. Remove the rear paper deflector.
4. Press the fuser wiper cover latch and remove the cover.
5. Remove the paper full sensor flag assembly from the mounting bracket.
6. Remove the mounting screws (A) and remove the cover.




### Center Pan Assembly

1. Remove the left and right side frames.
2. Remove the pan assembly.

4069-0XX

## Controller Board


1. Remove the inner EMC shield.
2. Remove the controller board mounting screw (A).
3. Remove the controller board parallel port mounting screws (B).
4. Remove the serial port mounting screws if present.
5. Remove the controller board.



## Developer Drive Assembly

1. Remove the inner EMC shield.
2. Remove the developer drive assembly mounting screws (A).
3. Remove the developer drive assembly.

**Note:** Be sure the developer drive assembly wheel aligns with the hub on the main drive assembly when reinstalling the assembly.



## Duplex Board

1. Lift the base printer from the duplex assembly.
2. Remove the four duplex board cover mounting screws.
3. Gently disconnect the cables from the duplex board. Use caution to avoid damage to the cables and connectors.
4. Remove the two duplex board mounting screws and remove the duplex board.

## Duplex Front Cover Assembly

1. Lift the base printer from the duplex assembly.
2. Remove the four duplex board cover mounting screws and disconnect the duplex cover door switch cable at connector J6.
3. Position the duplex assembly on its side.
4. Gently release the three front cover assembly latches from the bottom of the duplex assembly.
5. Remove the duplex front cover assembly.

## Duplex Front Cover Door

1. Remove the duplex front cover assembly.
2. Holding the front of the assembly away from you, open the cover door and gently pry the left side door pivot from the mounting.
3. Move the cover door to the left to clear the right door pivot from the mounting and remove the duplex front cover door.

## Duplex Front Cover Door Switch

1. Remove the duplex front cover assembly.
2. Remove the four duplex board cover screws and disconnect the cover door switch cable at connector J6.
3. Loosen the cover door switch mounting screw and remove the switch.

**Note:** Be sure the cover door switch is properly positioned in the mounting slots when reinstalling to allow the duplex cover door actuator arm to operate the switch.

## Duplex Motor


1. Remove the duplex front cover door.
2. Gently disconnect the cables from the duplex board. Use caution to avoid damage to the cables and connectors.
3. Remove the four mounting screws from the left and right return guides and remove the guides.
4. Remove the four mounting screws on the right side of the duplex frame assembly.
5. Position the duplex assembly on its side.
6. Gently release the center drive deflector assembly latch from the bottom front left side of the duplex assembly.
7. Remove the center drive deflector assembly and the frame assembly from the duplexer.
8. Remove the two duplex motor mounting screws and remove the motor.

**Note:** Pay attention to cable routing to avoid pinching or cutting wires during reassembly. Ensure cables are securely placed into the cable retaining tabs. Do the adjustment “Duplex Motor Drive Belts” on page 4-2 whenever you remove or replace the duplex motor.

## Engine Board

1. Remove the inner EMC shield.
2. Disconnect all cables from the engine board.
3. Remove the engine board mounting screws (A).
4. Remove the engine board cage mounting screw (B) from the main drive motor assembly.
5. Remove the engine board.

**Note:** Anytime the engine board is replaced, the Configuration ID must be reset in NVRAM on the new engine board. Go to **“Setting Configuration ID”** on page 3-21.




## EP Frame Assembly

1. Remove the left and right side frames.
2. Remove the EP frame assembly.

## Fans

### Auxiliary Fan (Models 614/616)

1. Remove the right cover.
2. Remove the inner EMC shield.
3. Remove the fuser wiper cover.
4. Disconnect the auxiliary fan cable from the engine board at connector J7.
5. Note the routing of the auxiliary fan cable (A) and remove the fan (B).






**4069-0XX**

## **Main Fan**

1. Remove the top rear cover.
2. Remove the inner EMC shield.
3. Note the routing of the main fan cable (A) and disconnect the cable from the engine board at connector J1.
4. Release the four latches (B) and remove the fan from the left side frame.




**Caution:** Be sure the fuser assembly has cooled before working on any of the fuser FRUs.

**Note:** You must replace cable ties (B) if removed during the fuser removals. The cable ties prevent the fuser wiring from obstructing the paper path through the fuser assembly.

## Fuser


1. Remove the redrive assembly.
2. Loosen the fuser mounting screws (A) and remove the fuser.



4069-0XX


## Fuser Board

1. Remove the fuser assembly.
2. Disconnect the cables (A) from the fuser board.
3. Remove the fuser board mounting screw (B).
4. Release the fuser board from the standoff tab (C) and lift the fuser board from the fuser assembly.



## Fuser Cover

1. Remove the fuser assembly.
2. Note the thermistor cable routing and disconnect the cable from the fuser board.
3. Disconnect the thermal fuse cable from the left and right lamp brackets (A).
4. Loosen the left and right lamp bracket mounting screws (B) and remove the thermal fuse cable from the bracket.
5. Remove the left and right fuser cover mounting screws (C) and lift the cover from the fuser assembly.




## Fuser Detack Fingers

1. Remove the fuser assembly.
2. Remove the fuser cover assembly.
3. Remove the fuser detack housing assembly.
4. Gently pry the detack finger and spring (A) from the housing assembly.

## Fuser Detack Housing Assembly


1. Remove the fuser assembly.
2. Remove the fuser cover assembly.
3. Remove the fuser lamp.
4. Gently apply outward pressure on the left and right fuser side frames (B) to release the detack housing assembly.



**4069-0XX**

## **Fuser Transfer Plate**


1. Remove the upper paper deflector.
2. Remove the fuser transfer roll.
3. Remove the inner paper deflector.
4. Lift the left side of the fuser transfer plate (A) and move the plate to the left to clear the right side from its mounting.
5. Remove the fuser transfer plate.



## Fuser Envelope Conditioner Solenoid (614/616)

1. Remove the fuser assembly.
2. Remove the solenoid mounting screw (A).
3. Disconnect the solenoid link (B).
4. Remove the solenoid from the fuser assembly.

**Note:** Do the **"Fuser Solenoid Adjustment"** on page 4-3 whenever you replace the fuser solenoid.




## Fuser Exit Flag Assembly

1. Remove the fuser assembly.
2. Remove the fuser exit flag assembly.

## Fuser Exit Roll Assembly

1. Remove the fuser assembly.
2. Press the exit shaft bushing retaining tabs and slide the left and right bushings (A) toward the inside of the fuser assembly.
3. Remove the exit roll assembly from the slots in the side frame.

**Note:** Be sure the fuser idler gear (B) is in place and the bushing alignment tab is rotated to the correct position in the side frame slot as you snap each bushing in place when reinstalling the exit roll assembly.





Fuser Lamp

- 1. Remove the fuser assembly.
- 2. **Warning:** Hold the left lamp bracket and carefully remove the two mounting screws. There is pressure against the other end of the lamp therefore care must be used when removing the lamp from the fuser. Grip the lamp by the ceramic end piece and remove it from the fuser assembly. Be careful not to touch the glass as skin oils and acids can reduce the life of the lamp.
- 3. Remove the fuser lamp.

**Note:** Be sure to position the left lamp mounting bracket around the fuser lower exit guide mounting pin when reinstalling the lamp.

The fuser lamp FRU is color coded. The left and right fuser lamp bracket access holes let you view the end of the lamp. Use the following table to identify and install the correct lamp.

Description	Color Code
Fuser Lamp 115V 550W	Green
Fuser Lamp 115V 875W	Gold
Fuser Lamp 220V 550W	Brown
Fuser Lamp 220V 875W	Silver

Fuser Lower Exit Guide Assembly


- 1. Remove the fuser assembly.
- 2. Remove the fuser cover assembly.
- 3. Remove the fuser detack housing assembly.
- 4. Remove the fuser flag assembly.
- 5. Gently apply outward pressure on the left and right fuser side frames to release the lower exit guide assembly.

## High Voltage Power Supply

1. Remove the inner paper deflector.
2. Remove the toner sensor cable from the retainer (A) on the front of the HVPS.
3. Remove the right side cover.
4. Disconnect the JVPS cable from the HVPS at connector (C).
5. Disconnect the transfer roll cable from the HVPS board.

**Note:** Use caution when disconnecting the cable from the transformer on the HVPS. The cable and connector can be easily damaged.

6. Remove the HVPS mounting screw (B).
7. Slide the HVPS to the left to release the mounting tab and remove the HVPS.



C


A

B(235)

4069-0XX


## Inner EMC Shield

1. Remove the left door.
2. Remove the outer EMC shield.
3. Remove all option boards from the connector board slots.
4. Remove the inner EMC shield mounting screws (A).
5. Remove the inner EMC shield.




## Inner Paper Deflector Assembly

1. Remove the paper tray.
2. Remove the upper deflector assembly.
3. Place the printer on its side.
4. Remove the lower deflector assembly.
5. Gently pry the inner paper deflector from the left and right mounting posts (A) located on the bottom of the printer and remove the deflector.




## Integrated Tray Compensator Assembly

1. Remove the paper tray.
2. Remove the left door.
3. Remove the inner EMC shield.
4. Disconnect the compensator motor cable (A) from the engine board.
5. Place the printer on its side.
6. Locate the integrated tray compensator assembly (B) on the bottom of the printer and disconnect the compensator arm bias spring from the frame.
7. Disconnect the compensator sensor cable (C) from the assembly.
8. Remove the compensator assembly mounting screw (D).
9. Remove the integrated tray compensator assembly.



## Integrated Tray Compensator Pick Roll Assembly


1. Remove the paper tray.
2. Place the printer on its side.
3. Locate the compensator assembly on the bottom of the printer and pull the compensator arm away from the printer.
4. Unsnap the pick roll assembly (D) from its mounting and remove.



4069-0XX


## Interconnect Board Assembly

1. Remove the inner EMC shield.
2. Remove the engine board and shield.
3. Remove the LVPS.
4. Disconnect all cables from the interconnect board.
5. Remove the interconnect board assembly mounting screw (A).



#### 4069-0XX

6. Place the printer on its back and remove the mounting screws (A).
7. Remove the interconnect board assembly.






**4069-0XX**


## **Left Side Frame**

1. Remove the main drive assembly.
2. Remove the left side frame mounting screws (A).



## 4069-0XX


3. Place the printer on its back and remove the left side frame mounting screws (A).
4. Remove the left side frame.



**4069-0XX**

## **Low Voltage Power Supply**

1. Remove the right cover.
2. Remove the LVPS mounting screws (A) from the rear of the bottom pan.
3. Pull the LVPS assembly from the right side of the printer. Initial resistance is felt as the automate plug disconnects.
4. Press the release latch on the fuser lamp cable connector and disconnect from the LVPS.
5. Remove the LVPS.




**A (203)**

## Main Drive Assembly

1. Remove the inner EMC shield.
2. Remove the gear guard.
3. Remove the developer drive assembly.
4. Remove the transfer shaft (A) through the bottom of the printer.
5. Remove all cables from the cable clamps (B) on the main drive assembly.
6. Remove the three main drive assembly mounting screws (C).
7. Remove the link (D) from the rear of the main drive assembly.
8. Disconnect the cable from the main drive motor.
9. Remove the main drive assembly.


**Note:** *Do not remove* the screws (E) on the main drive assembly. Be sure the main drive assembly gear shaft aligns with the hub on the left side frame when reinstalling the main drive assembly.



4069-0XX


## Main Drive Motor

1. Remove the main drive assembly.
2. Remove the main drive motor mounting screws (A).
3. Remove the main drive motor.




## Multipurpose Tray/Lower Deflector Assembly

1. Open the multipurpose tray to a position that allows the left and right tray hinge slots (A) to align with the rectangular mounting posts (B). Pull upward on each tray hinge to remove the tray from the two mounting posts. Be careful not to break the hinges.



#### 4069-0XX

2. Remove the upper deflector.
3. Remove the paper out sensor.
4. Remove the screws (A) mounting the multipurpose tray/lower deflector assembly.
5. Remove the multipurpose tray/lower deflector assembly.




A (102)

A (104)

**4069-0XX**

## **Operator Panel**

1. Remove the upper front cover.
2. Gently press the three operator panel lens cover retaining tabs (A) and remove the lens cover. The button membrane is free to remove from the assembly.
3. Disconnect the operator panel cable and remove the operator panel board.





## Operator Panel Cable/Cover Open Switch Assembly

**Note:** Pay careful attention to the cable routing through the printer before you remove the operator panel cable/cover open switch assembly.

1. Remove the left door, left cover, upper front cover, outer EMC shield and inner EMC shield.
2. Disconnect the operator panel/cover open switch cable from the engine board.
3. Remove the operator panel. Pull the cables through the rectangular hole in the hinge pivot arm.
4. Plug the new operator panel cable into the operator panel and snap the new cover open switch cable into the bracket assembly.
5. Route the cables and torroid through the rectangular window in the cover hinge pivot arm.
6. Snap the operator panel into the upper front cover.
7. Be sure the torroid is on the opposite end of the cables near the engine board connectors.
8. Route the cables through the printer and down the inside of the engine board shield.
9. Plug the cables into the engine board connectors.

## Optional 250/500 Paper Tray Assembly

**Note:** Remove the printer and other paper feed options to access the failing optional paper tray assembly.

### Paper Tray Compensator Assembly

1. Remove the printer and other paper feed options.
2. Disconnect the compensator assembly bias spring from the tray frame.
3. Disconnect the compensator assembly motor cable.
4. Remove the three compensator assembly mounting screws and remove the compensator assembly.

### Paper Tray Frame Assembly

1. Remove the compensator assembly.
2. Release the paper pass through sensor from its retaining tabs.
3. Release the frame assembly from the front and rear retaining tabs and remove the paper tray frame assembly.

### Paper Tray Board

1. Remove the paper tray frame assembly.
2. Disconnect all cables from the paper tray board.
3. Remove the three paper tray board mounting screws and remove the board.

**Note:** Reinstall with the paper out sensor flag positioned in the sensor slot on the paper tray board.

### Paper Tray Paper Out Sensor Flag

1. Remove the paper tray frame assembly.
2. Remove the paper tray board.
3. Remove the paper out sensor flag.


### Paper Size Spring Comb

1. Remove the paper tray board.
2. Remove the paper size spring comb mounting screw and remove the spring comb.

4069-0XX

## Outer EMC Shield


1. Remove the left door.
2. Loosen the outer EMC shield mounting screws (A) and remove the shield.



**4069-0XX**

## **Paper Alignment Assembly**

1. Remove the upper paper deflector assembly.
2. Remove the inner paper deflector assembly.
3. Release the input paper sensor from its mounting and remove.
4. Remove the left door.
5. Remove the paper alignment assembly mounting screws (A) located inside the printer.




A (104)

## 4069-0XX

6. Locate the paper alignment assembly reference adjustment screw (B) through the left frame and remove the screw.
7. Remove the paper alignment assembly.

**Note:** Do the **“Paper Alignment Assembly Adjustment”** on page 4-5 when you reinstall the assembly.

B (99A0492)




## Paper Input Sensor

1. Remove the inner paper deflector assembly.
2. Disconnect the paper input sensor cable from the input sensor.
3. Release the input paper sensor from its mounting and remove.

**4069-0XX**

## **Paper Size Sensing Board**

1. Disconnect the paper size sensing board cable from the board.
2. Remove the two paper size sensing board mounting screws (A).
3. Remove the paper size sensing board.



A (102)


## **Pick Roll**

1. Remove the upper paper deflector.
2. Release the pick roll retaining tab and slide the pick roll off the shaft.

## Printhead


1. Remove the laser assembly cover.
2. Disconnect the printhead cables (A) from the printhead assembly.
3. Remove the printhead mounting screws (B) and remove the printhead.

**Note:** Do the **“Printhead Assembly Adjustment”** on page 4-4 whenever you remove or replace the printhead assembly or loosen the mounting screws.



## Redrive Assembly


1. Open the redrive door assembly, remove the restraint strap mounting screw and remove the door assembly.
2. Remove the redrive exit cover.
3. Remove the redrive assembly mounting screws (A).
4. Release the redrive assembly mounting latches (B) and remove the redrive assembly.





## Right Side Frame


1. Remove the right side cover.
2. Remove the LVPS.
3. Remove the multipurpose tray assembly.
4. Remove the auxiliary fan assembly.
5. Disconnect the auto compensator arm bias spring from the right side frame.
6. Remove the toner sensor mounting screw (A), disconnect the sensor cable and remove the toner sensor.
7. Remove the right side frame mounting screws (B) and remove the right side frame.



**4069-0XX**

## **Smart Cartridge Contacts**


1. Remove the upper front cover.
2. Release tab (A) and remove the contact cover.
3. Remove the contact plunger (B).
4. Remove the screws (C) and remove the contacts (D).



4069-0XX

## Toner Sensor

1. Remove the right side cover.
2. Remove the toner sensor mounting screw (A). Disconnect the toner sensor cable and remove the toner sensor.



A (102)

## **Transfer Roll Assembly**


1. Open the upper front cover and remove the print cartridge.
2. Pivot the transfer roll assembly toward the front of the printer.
3. Unsnap the transfer roll assembly from the left and right pivot arms and remove the transfer roll assembly.

## **Upper Paper Deflector Assembly**

1. Open the multipurpose tray and remove the tray from the two mounting posts. Be careful not to lose the O-ring on the right mounting post.
2. Gently release the upper deflector assembly latch from its mounting on the right side frame and slide to the right.
3. Remove the upper deflector assembly.


## Upper Front Cover Hinge Assembly

1. Remove the upper front cover.
2. Remove the laser assembly cover.
3. Remove the C-clips (A) from the upper front cover hinge assembly left and right hinge pins and remove the pins. Note the pin orientation and the C-clip location on the inside of each hinge.
4. Detach the two springs (B) from the upper front cover hinges.
5. Disconnect the operator panel cable from the operator panel assembly.
6. Raise the upper front cover hinge assembly to a position that lets you lift the left pivot arm from the mounting bracket (C).
7. Lift the left pivot arm from the bracket and move the upper cover hinge assembly toward the left to clear the right upper cover pivot arm from the mounting bracket.
8. Remove the upper front cover hinge assembly.



## **Upper Front Cover Interlock Switch Assembly**


1. Remove the upper front cover.
2. Remove the operator panel.
3. Remove the inner EMC shield.
4. Press the retaining tabs (A) and remove the interlock switch assembly.
5. Note the routing of the interlock switch assembly cable and disconnect the cable on the engine board.



5. Connector Locations

Low Voltage Power Supply


Connector	Pin No.	Signal
CN3 Interconnect Board	1	+5 V dc
	2	+5 V dc
	3	Ground
	4	Ground
	5	Ground
	6	Ground
	7	+24 V dc
	8	+24 V dc
	9	Heat on
	10	+5 V dc
	11	+5 V dc
	12	Ground
	13	Ground
	14	Ground
	15	Ground
	16	+24 V dc
	17	ZC Out*
	18	+42 V dc





## High Voltage Power Supply

Connector	Pin No.	Signal
CN1 Engine Board	1	Developer PWM
	2	+24 V dc Return
	3	Charge PWM
	4	+24 V dc IN
	5	TX PWM
	6	TX Enable
	7	TX CUR PWM
	8	SVRO OUT



## Engine Board

Connector	Pin No.	Signal
J1 Main Fan	1	Fan Stall
	2	Ground
	3	Main Fan
J3 Printhead (Mirror Motor)	1	+24 V dc Return
	2	+24 V dc Return
	3	ReFREQ
	4	LOCKn
	5	Start*
	6	+24 V dc Return
	7	+24 V dc
J4 Cover Closed Switch	1	Cover Closed
	2	Ground
	3	+5 V dc
J5 Printhead	1	LENA*
	2	Ground
	3	LAOJ*
	4	Ground
	5	LASERPWM
	6	+5 V dc
	7	Ground
	8	Video*
	9	Ground
	10	Ground

**4069-0XX**

<b>Connector</b>	<b>Pin No.</b>	<b>Signal</b>
J6 Output Level Sensor	1	Ground
	2	Ground
	3	Opt2
	4	Ground
	5	+5 V dc
J7 Auxiliary Fan 414/616	1	Cartfan
	2	Ground
J8 Printhead HYSNC	1	Ground
	2	HSYNC*
	3	Ground
	4	+5 V dc

**4069-0XX**

Connector	Pin No.	Signal
J10 Erase/Cartridge/ Sensor/Input Sensor/ HVPS	1	AT Servo (HVPS)
	2	Servo OutT (HVPS)
	3	TXENABLE (HVPS)
	4	Transfer (HVPS)
	5	+24 V dc (HVPS)
	6	Charge (HVPS)
	7	Ground (HVPS)
	8	Developer (HVPS)
	9	Ground (In Sens)
	10	In Sns* (In Sens)
	11	+5 V dc (C-Sens)
	12	CTSENSE* (C-Sens)
	13	Ground (C-Sens)
	14	+24 V dc (Erase L)
	15	ERASEPWM* (Erase L)
J11 Operator Panel	1	I2CDATA
	2	+5 V dc
	3	I2CCLK
	4	Ground
	5	FPIRQ

**4069-0XX**


Connector	Pin No.	Signal
J12 Transport Motor	1	+24 V dc
	2	+24 V dc Return
	3	+24 V dc Return
	4	Motor3
	5	Motor4
	6	Dir
	7	Motor1
	8	+5 V dc
	9	Motor2
	10	Ground
	11	Motor0
J13 Autoconnect (Options)	1	RXDIN
	2	Ground
	3	+5 V dc
	4	Ground
	5	Ground
J14 Autoconnect (Options)	1	RXDIN
	2	Ground
	3	+5 V dc
	4	Ground
	5	Ground

**4069-0XX**

Connector	Pin No.	Signal
J15 Integrated Paper Tray - Paper Size Sensor	1	+5 V dc
	2	PSIZE2
	3	Ground
	4	PSIZE1
	5	+24 V dc
	6	Ground
	7	POUT
	8	+5 V dc
	9	Paper Low
	10	+5 V dc
J16 Fuser	1	Exit Sensor
	2	Thumpret
	3	+5 V dc
	4	Thumpleft
	5	Ground
	6	Therm
	7	Thermgnd
	8	Narmedia
J17 MPT Pick	1	MPT Pick
	2	+24 V dc

**4069-0XX**

<b>Connector</b>	<b>Pin No.</b>	<b>Signal</b>
J18 Auto Compensator	1	+24 V dc
	2	N/A
	3	Ground
	4	Ground
	5	N/A
	6	+5 V dc
J19 MPT Paper Out	1	Ground
	2	POSENSE
	3	+5 V dc
J20 Interconnect Board	N/A	N/A
J21 Smart Cartridge	1	Scart
	2	Scart Ground
	3	Ground






4069-0XX

Fuser Board

Connector	Pin No.	Signal
J1 Engine Board	1	NarMedia
	2	ThermGnd
	3	HRTherm
	4	Ground
	5	ThumpA
	6	+5 V dc
	7	ThumpB
	8	ExitSns*
J2 Thermistor	1	ThermGnd
	2	HRTherm
J3 Thumper	1	Ground
	2	+42V dc
J4 Thumper Solenoid	1	ThumpB
	2	ThumpA
J5 Narrow Media Sensor	1	+5 V dc
	2	Nar Media
	3	Ground




## Interconnect Board

Connector	Pin No.	Signal
J1 Fuser Solenoid	1	+42 V dc
	2	Ground
J2 LVPS	1	+42 V dc
	2	Heaton
	3	Xeroxing
	4	+24 V dc
	5	+24 V dc
	6	+24 V dc
	7	Ground
	8	Ground
	9	Ground
	10	Ground
J3 LVPS	1	Ground
	2	Ground
	3	Ground
	4	Ground
	5	+5 V dc
	6	+5 V dc
	7	+5 V dc
	8	+5 V dc
J4 Autoconnect Top	1	+24 V dc
	2	Ground
	3	+5 V dc Fused
	4	Ground

**4069-0XX**


Connector	Pin No.	Signal
J5 Autoconnect BTM/FNT	1	+24 V dc
	2	Ground
J6 Engine Board	1	N/A
J7 Controller Board	1	N/A
J8 ID-1	1	N/A
	2	N/A
J9 ID-2	3	N/A
	4	N/A
J10 ID-3	5	N/A
	6	N/A
J11 INA 1	1	N/A
J12 INA 2	1	N/A

- Models 010 and 01n have a jumper on J10 between the center pin and pin 6.
- Models 212 and 21n have a jumper on J8 between the center pin and pin 2, on J9 between the center pin and pin 3 and on J10 between the center pin and pin 6.
- Models 414 and 41n have a jumper on J8 between the center pin and pin 1 and a jumper on J9 between the center pin and pin 4.
- Models 616 and 61n have a jumper on J8 between the center pin and pin 2 and on J9 between the center pin and pin 4.



## Envelope Option Board

Connector	Pin No.	Signal
J1	1	N/A
	2	Ground
	3	Tx (EOC)
	4	Ground
	5	Rx (EOC)
	6	+24 V dc Return
	7	+24 V dc
J2	1	Ground
	2	Paper Present
	3	+5 V dc
J3	1	Ground
	2	Paper Present
	3	+5 V dc
J4	1	Motor - Phase B-
	2	Motor - Phase A-
	3	Motor - Phase B+
	4	Motor - Phase A+



## Duplex Option Board

**Note:** Duplex connectors J10 and J11 are interchangeable. No problem results if the connectors are switched.

Connector	Pin No.	Signal
J1 Motor	1	Motor -
	2	Motor +
J2 DC Motor Sensor/Encoder Board	1	+5 V dc Sensor
	2	Tach +
	3	Ground
J3 Stepper Motor	1	STPMOTA -
	2	STPMOTA +
	3	STPMOTB -
	4	STPMOTB +
J4 Fan	1	+24 V dc
	2	Fan On -
J5 Paper Input Sensor	1	+5 V dc Sensor
	2	Input +
	3	Ground
J6 Rear Cover Open Switch	1	Top Cover Open +
	2	Ground
J7 Jam Removal Tray Open Switch	1	Front Drawer Open +
	2	Ground
J8 Paper Exit Sensor	1	+5 V dc Sensor
	2	Exit +
	3	Ground


**4069-0XX**

Connector	Pin No.	Signal
J9 Autoconnect, Option Below	1	Ground
	2	PrtxDout
	3	Ground
	4	PrtRxd
J10 Autoconnect, Option Below	1	+24 V dc
	2	Ground
J11 Printer Autoconnect	1	+24 V dc
	2	Ground
J12 Printer Autoconnect	1	N/A
	2	Ground
	3	PrtxDin
	4	Ground
	5	PrtRxD



Autoconnect - Top

Connector	Pin No.	Signal
Top Autoconnect	1	0 V dc
	2	+5 V dc
	3	0 V dc
	4	0 V dc
	5	0 V dc
	6	+5 V dc
	7	0 V dc
	8	+24 V dc




## Output Expander Control Board

Connector	Pin No.	Signal
J1A Autoconnect	1	+24 V dc
	2	Ground
	3	+5 V dc
J1B	1	Prtxdin
	2	Ground
	3	prtrxd
	4	Ground
	5	N/C
J2A Autoconnect	1	+24 V dc
	2	Ground
	3	+5 V dc
J2B	1	prtxdout
	2	Ground
	3	prtrxd
	4	Ground
J3 Pass Thru Sensor	1	Ground
	2	Paper Present
	3	RVsnsr
J4 DC Motor	1	mtrout1
	2	mtrout2
	3	Ground
	4	Ground
	5	tach +
	6	+5 V dc

4069-0XX

Connector	Pin No.	Signal
J5 Bin Full/Near Full Dual Sensor	1	Ground
	2	Ground
	3	binful
	4	binful
	5	RVsnsr
J6 Jumper Connector	1	Not Used
	2	Not Used
	3	Not Used



## High-Capacity Output Stacker Board


Connector	Pin No.	Signal
J1A Autoconnect	1	+24 V dc
	2	Ground
	3	+5 V dc
J1B	1	Prtxdin
	2	Ground
	3	prtrxd
	4	Ground
	5	N/C
J2A Autoconnect	1	+24 V dc
	2	Ground
	3	+5 V dc
J2B	1	prtxdout
	2	Ground
	3	prtrxd
	4	Ground
J3 Pass Thru Sensor	1	Ground
	2	Paper Present
	3	RVsnsr
J4 DC Motor	1	mtrout1
	2	mtrout2
	3	Ground
	4	Ground
	5	tach +
	6	+5 V dc

4069-0XX

Connector	Pin No.	Signal
J5 Bin Full/Near Full Dual Sensor	1	Ground
	2	Ground
	3	binful
	4	binful
	5	RVsnsr
J6 Jumper Connector	1	Upper Unit
	2	Upper/Lower Unit
	3	Lower Unit

J6 Connector Jumper Locations

High-Capacity Stacker Board	Pin 1	Pin 2	Pin 3
Upper Unit Board	X	X	Not Used
Lower Unit Board	Not Used	X	X



**4069-0XX**

---

## 6. Preventive Maintenance

This chapter describes procedures for printer preventive maintenance. Following these recommendations can help prevent problems and maintain optimum performance.

---

### Safety Inspection Guide

The purpose of this inspection guide is to aid you in identifying unsafe conditions.

If any unsafe conditions exist, find out how serious the hazard could be and if you can continue before you correct the hazard.

Check the following items:

- Damaged, missing, or altered parts, especially in the area of the On/Off switch and the power supply
- Damaged, missing, or altered covers, especially in the area of the top cover and the power supply cover
- Possible safety exposure from any non-Lexmark attachments

---

### Lubrication Specifications

Lubricate only when parts are replaced or as needed, not on a scheduled basis. Use of lubricants other than those specified can cause premature failure. Some unauthorized lubricants may chemically attack polycarbonate parts. Use IBM no. 10 oil, P/N 1280443 (Approved equivalents: Mobil DTE27, Shell Tellus 100, Fuchs Renolin MR30), IBM no. 23 grease (Approved equivalent Shell Darina 1), and grease, P/N 99A0394 to lubricate appropriate areas of the machine.

---

## Scheduled Maintenance

The operator panel displays the message “80 Scheduled Maintenance” at each 300K page count interval. It is necessary to replace the fuser assembly, transfer roller and charge roll at this interval to maintain the print quality and reliability of the printer. The parts are available as a maintenance kit with the following part numbers:

99A1762 - 115V 875W Models 010/01n/212/21n

99A1763 - 220V 875W Models 414/41n/616/61n

99A1764 - 115V 550W Models 010/01n/212/21n

99A1765 - 220V 550W Models 414/41n/616/61n

After replacing the kit, the maintenance count must be reset to zero to clear the “80 Scheduled Maintenance” message. Refer to **“Maintenance Page Count” on page 3-21**.



## 7. Parts Catalog

---

### How To Use This Parts Catalog

- **SIMILAR ASSEMBLIES:** If two assemblies contain a majority of identical parts, they are shown on the same list. Common parts are shown by one index number. Parts peculiar to one or the other of the assemblies are listed separately and identified by description.
- **AR:** (As Required) in the Units column indicates that the quantity is not the same for all machines.
- **CC:** (Color Code) in the Description column indicates the part is identified by a color marking on the part.
- **NS:** (Not Shown) in the Asm-Index column indicates that the part is procurable but is not pictured in the illustration.
- **PP:** (Parts Packet) in the Description column indicates the part is contained in a parts packet.
- **INDENTURE:** The indenture is marked by a series of dots located before the parts description. The indenture indicates the relationship of a part to the next higher assembly. For example:

#### INDENTURE RELATIONSHIP OF PARTS

(No dot) MAIN ASSEMBLY

(One dot) o Detail parts of a main assembly

(One dot) o Subassembly of the main assembly

(Two dot) o o Detail part of a one-dot subassembly

(Two dot) o o Subassembly of a one-dot subassembly


The Optra T laser printer is available in eight models. The model designations are as follows:

4069-01N, 4069-21N, 4069-41N, 4069-61N, 4069-010, 4069-212  
4069-414, 4069-616

The parts catalog uses the three digit model number to identify model specific FRUs.

4069-0XX

**Assembly 1: Covers**




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
1-1	99A1587	1	Support, Paper
1-2	99A1508	1	Cover, Fuser Wick Assembly
1-3	99A1506	1	Cover Asm, Laser 250 Assembly 010/212
1-3	99A1507	1	Cover Asm, Laser 500 Output 414/616
NS		6	Screw, Laser Cover PP 99A0263
NS	99A1512	1	Cover Assembly, Redrive Cap
1-4	99A1593	1	Cable, Smart Cartridge
1-5	99A0816	1	Contact, Smart Cartridge Ground
1-6	99A0815	2	Contact, Smart Cartridge
1-7	99A1595	1	Cover, Smart Cartridge Contact
1-8	99A0834	1	Plunger, Overstress Smart Cartridge
1-9		2	Screws, Contact Mounting PP 99A0263
1-10	99A1775	1	Kit, Upper Front Cover with Labels
NS		5	Screw, Upper Front Cvr Mtg PP 99A0263
1-11	99A1503	1	Hinge, Upper Front Cover
1-12	99A1504	1	Cover, Right Side 010/612
1-12	99A1505	1	Cover, Right Side 414/616
NS		3	Screw, Right Side Cvr Mtg PP 99A0263
1-13	99A0007	1	Label, TLI/ID/Serial No. - Blank
1-14	99A1502	1	Latch, Upper Cover
1-15	99A0004	1	Spring, Latch
1-17	99A1511	1	Cover Assembly, Lower Front
1-18	99A1501	1	Operator Panel Assembly
1-19	99A1577	1	Switch, Cover Open w/Operator Panel Cable Assembly
NS		5	Screw, Left Side Cvr Mtg PP 99A0263
1-20	99A1509	1	Cover, Left Door 010
1-20	99A1510	1	Cover, Left Door 212/414/616
NS	99A0577	1	Cable Tie
NS	99A1594	1	Retainer, Cable

4069-0XX

Assembly 2: Frame




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
2-1	99A1515	1	Duct, Left Stacker 010/212
2-1	99A1516	1	Duct, Left Stacker 414/616
2-2	99A0867	1	Duct, Main Body
2-3	99A1662	1	Support, Left Lower Stacker
2-4	99A0113	1	Pan, Drip ITC
2-5	99A0045	2	Latch, Cartridge Assembly
2-6	99A0039	2	Roller, Developer Support
2-7	99A0058	4	Pad, Machine Mounting
2-7B	99A1518	1	Frame Extension, Right 500 Internal 212/414/616
2-8	99A1588	1	Transfer Plate Assembly
2-9	99A1663	1	Support, Right Stacker Plate
2-10	99A1535	1	Right Sideframe
2-10A	99A1519	1	Rear Frame Extension, 500 Input 212/414/616
2-11	99A0049	1	Fan, Auxiliary 414/616
2-12		1	Contact Kit PP 99A0585
		3	o Contact, Doctor Blade/TAR/Developer Roll
		1	o Contact, PC Drum
		1	o Contact, Charge Roll
		4	o Block, Contact Mounting
		5	o Screw, Contact Mounting
2-13	99A0466	1	Sensor, Toner Cartridge Level
2-14	99A0026	1	Tray Bias Arm Assembly
2-15	99A0028	1	Spring, Tray Bias
2-16	99A1522	1	Pan, Center Assembly
NS	99A1538	1	Contact, RSF Ground
NS	99A1539	1	Shield, Fuser Lockout
NS	99A1540	4	Nutplate, Frame 212/414/616
NS	99A1541	1	Spring, Duplex Ground 212/414/616

4069-0XX

Assembly 2: Frame (continued)




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
2-17	99A1525	1	Deflector, Upper PF
2-18	99A0055	1	Deflector, Inner
2-19	99A1833	1	Frame, EP Module
2-20	99A0053	1	Sensor, Input
2-21	99A0063	1	Spring, PA Out Activate
2-22	99A0549	1	Shield, ESD Assembly with label
2-23	99A1514	1	Left Side Frame
2-24	99A0128	1	Board, Input Tray (ITC)
2-25	99A1517	1	Frame Extension, Left 500 Internal 212/414/616
2-26	99A0899	1	Pan, Motor Drip
2-27	99A0567	1	Link, Gear Release
2-29	99A0556	1	Spring, Counterbalance
NS		17	Screw PP 99A0263
2-30	99A0803	1	Fan, Main
2-31	99A1580	1	Flag, Output Paper Level
2-31	99A1613	1	Flag, Output Paper Level 212
2-32	99A0062	1	Bracket, Level Sensor 212/414/616
2-33	99A0138	1	Sensor, Standard Bin Level
NS	99A1524	1	Spring, Cartridge Load
NS	99A1545	1	Guard, Gear
NS	99A1546	1	Shield, Gear
NS	99A1643	1	Shroud, Fan 250 010
NS	99A1592	1	Shroud, Fan 500 212/414/616
NS	99A1596	1	Contact, LSF Ground

**4069-0XX**

**Assembly 3: Printhead**






**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
3-1	99A1526	1	Printhead Assembly, 010
3-1	99A1527	1	Printhead Assembly, 212
3-1	99A1528	1	Printhead Assembly, 414
3-1	99A1529	1	Printhead Assembly, 616
NS		3	Screw, Printhead Mounting PP 99A0263

4069-0XX

Assembly 4: Paper Feed (Autocompensator)




**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
4-1	99A0060	1	Sensor, Paper Out Internal Tray
4-2	99A1056	1	Pick Arm Assembly, Integrated Tray (250) 010
4-2	99A1530	1	Pick Arm Assembly, Integrated Tray (500) 212/414/616
4-3	99A0070	2	Pick Rolls
NS		1	Screw, Hanger PP 99A0263
NS	99A1616	1	Arm, Paper Out 500 Tray 212/414/616
NS	99A1609	1	Arm, Paper Out 250 Internal Tray 010

4069-0XX

Assembly 5: Paper Feed - Multipurpose Unit




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
5-1	99A0075	1	Screw, Socket Set M4X5 mm
5-2	99A0071	1	Arm Assembly, MPT
5-3	99A0076	1	Pick Roll Assembly
5-4	99A0081	1	Spring Assembly, Separator
5-5	99A0083	1	MPT Pad Assembly Kit o Restraint Pad o MPT Pad Assembly
5-6	99A1608	1	Deflector Assembly, MPT
5-7	99A1531	1	Deflector, Lower
5-8		2	Screw, Lower Deflector Mounting 8 mm PP 99A0263
5-8		2	Screw, Lower Deflector Mounting 12mm PP 99A0263
5-10	99A0084	1	Flag, MPT Paper Out
5-11	99A0082	1	Plate Assembly, MPT
5-12	99A0078	1	Sensor, MPT Paper Out
5-13	99A0073	2	Screw, Damper
5-14		1	Screw, Frame Mounting PP 99A0263
NS		2	Clip, Pick Roll Shaft PP 99A0267
5-15	99A0072	1	Solenoid, MPT
5-16	99A0074	2	Bushing, Pick Roll Shaft

4069-0XX

Assembly 6: Paper Feed - Alignment




**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
6-1	99A0089	1	Alignment Assembly Paper Feed
6-2	99A0492	1	Screw, Paper Reference Adjustment
6-3	99A0566	1	Nut, Paper Reference Adjustment
6-4	99A0559	1	Lever, Bellcrank Release
6-5	99A0565	1	Washer, Reference Adjustment
NS	99A0490	1	Clip, Reference Ground
NS		2	Screw, Alignment Asm Mtg PP 99A0263

4069-0XX

Assembly 7: Paper Feed - Output






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
7-1	99A1586	1	Redrive Assembly, Inner 250 010
7-1	99A1604	1	Redrive Assembly, 212
7-1	99A1533	1	Redrive Assembly, Inner 500 414/616
7-2	99A1644	1	Door Assembly, Redrive 250 010/212
7-2	99A1534	1	Door Assembly, Redrive 500 414/616
NS	99A0104	1	Spring, Upper Diverter
NS	99A0107	1	Deflector, Upper
NS		2	Screw, SEMS-Duplex Path PP 99A0263

4069-0XX

Assembly 8: Integrated Paper Tray - 250 Sheet




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
8-1	99A1536	1	Tray, Integrated 250 Sheet
8-2	99A1601	1	Latch, Back Restraint
8-3	99A0120	2	Restraint Pad
8-4	99A0892	1	Restraint, Side 250 Sheet Tray
8-5	99A0119	4	Wear Strips
8-6	99A1537	1	Knob, Paper Size
8-7	99A1829	1	Label, Integrated Tray Number
8-8	99A0121	1	Clip, 250 Tray Wear
8-9	99A0126	4	Finger, Autosize
8-10	99A0124	1	Plate, Snap-In
8-11	99A0127	1	Slider, Autosize 250
8-12	99A0893	1	Restraint, Back 250 Sheet Tray
NS		2	Screw, Deflector Mounting PP 99A0263
NS		1	Screw, Latch Mounting PP 99A0263

4069-0XX

Assembly 9: Integrated Paper Tray - 500 Sheet




**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
9-1	99A1601	1	Latch, Back Restraint
9-2	99A1576	1	Tray Assembly 500 Sheet
9-3	99A0895	1	Restraint, Side
9-4	99A0292	4	Strip, Wear
9-5	99A1537	1	Knob, Paper Size
9-6	99A1829	1	Label, Tray Option Numbers
9-7	99A1750	1	Plate, 500 Tray Wear
9-8	99A0126	3	Finger, Autosize
9-9	99A1582	1	Slider, Autosize 500
9-10	99A0120	2	Pad, Restraint
9-11	99A0124	1	Plate, Snap-in
9-12	99A1602	1	Restraint, Back

4069-0XX

Assembly 10: Main Drive




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
10-1	99A1542	1	Gearbox, w/Motor 010
10-1	99A1543	1	Gearbox, w/Motor 212/414/616
10-2	99A0134	1	Shaft, Power Take Off 010
10-2	99A1569	1	Shaft, Power Take Off 500 212/414/616
10-3	99A0275	1	Spring, Power Takeoff Shaft
10-4	99A0954	1	Gear, Bevel with Grease Packet
NS		4	Screw, Gearbox Mounting PP 99A0263
NS		3	Screw, Motor Mounting PP 99A0263
NS	99A0260	2	Clip, Cable

4069-0XX

Assembly 11: Developer Drive






**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
11-1	99A1544	1	Developer Drive Assembly
11-2	99A0564	1	Coupler, Gear #55
11-3	99A0136	1	Shaft, Developer Drive
11-4		1	Screw, Developer Drive Ground PP 99A0263
11-5		2	Screw, Developer Drive Mtg PP 99A0263


Assembly 12: Fuser



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
12-1	99A1584	1	Fuser Assembly w/115V 875W Lamp 414/616
12-1	99A1585	1	Fuser Assembly w/220V 875W Lamp 414/616
12-1	99A1660	1	Fuser Assembly w115V 550W Lamp 010/212
12-1	99A1661	1	Fuser Assembly w220V 550W Lamp 010/212
12-2	99A0725	1	Wiper Assembly, Wet
12-3	99A1603	1	Cover, Fuser Assembly with Thermistor, Thermal Fuse, and LH & RH Fuser Lamp Contact Assemblies
12-4		4	Screw, Contact Assembly PP 99A0263
12-5	99A1631	1	Exit Roll Assembly
12-5A	99A1520	1	Gear, Upper Redrive
12-6	99A0833	1	Detack Assembly
12-7	99A1521	1	Hot Roll, 010/212
12-7	99A1549	1	Hot Roll, 414/616
12-8	99A0144	2	Retainer, Backup Roll Bearing
12-9	99A0160	1	Backup Roll, 010/212
12-9	99A0158	1	Backup Roll, CBM 28 mm 414/616
12-10	99A0173	1	Solenoid Assembly, Envelope Conditioner
12-11		1	Screw, Solenoid Mounting PP 99A0263
12-12		1	Screw, Board Cover Mounting PP 99A0263
12-13	99A1598	1	Shield, Fuser Board
12-14	99A1554	1	Fuser Cable, AC
12-15	99A1648	1	Fuser Cable, DC
12-16		1	Tie, Wire PP 99A0577
12-17	99A1553	1	Board Assembly, Fuser
12-18	99A1649	2	Screw, Fuser Mounting
12-19		2	Screw, Fuser Cover Assembly PP 99A0263
12-20	99A0142	2	Retainer, Hot Roll Bearing

Assembly 12: Fuser (continued)




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
12-21	99A0143	2	Bearing, Hot Roll
12-22	99A0150	2	Bushing, Hot Roll
12-23	99A1600	2	Bellcrank, Backup Roll 414/616
12-23	99A1659	2	Bellcrank, Backup Roll 010/212
12-24	99A1591	1	Guide, Fuser Entry
12-25	99A0410	2	Spring, Backup Roll Bellcrank
12-26		2	Retainer, Backup Roll Bellcrank PP 99A0267
12-27	99A1597	1	Clamp, Fuser Cable AC/DC
12-28	99A0157	1	Gear, Hot Roll
12-29	99A0148	1	Gear, Idler
12-30	99A0297	1	Link, Solenoid
12-31	99A1651	1	Sensor, Narrow Media
12-32	99A1551	1	Sensor, Exit
12-33	99A0897	2	Spring, Redrive Idler
12-34	99A0167	2	Roller, Redrive Idler
12-35	99A1550	1	Guide Assembly, Lower Exit
12-36	99A1547	1	Lamp, 115V 875W CC Gold
12-36	99A1639	1	Lamp, 115V 550W CC Green
12-36	99A1548	1	Lamp, 220V 875W CC Silver
12-36	99A1642	1	Lamp, 220V 550W CC Brown
NS	99A1658	1	Cover, Fuser Wiper Cavity
NS		7	Screw, Hanger PP 99A0263
NS	99A0919	2	Standoff, Fuser Control Board
NS	99A0159	2	Spacer, BUR 010/212
NS	99A1599	1	Tray, Fuser AC Connector

4069-0XX

Assembly 13: Transfer




**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
13-1	99A1015	1	Transfer Roll Assembly
13-2	99A0349	1	Arm, Transfer Roll Assembly Right
13-3	99A0184	1	Spring, Transfer Roll Right
13-4	99A0186	1	Erase Lamp Assembly Kit o Lamp, Erase Assembly o Lens, Erase Lamp
13-5	99A0185	1	Shaft, Transfer Pivot
13-6	99A0181	1	Spring, Transfer Roll Left
13-7	99A1578	1	Arm, Transfer Roll Left
NS		1	Retainer, Pivot Shaft PP 99A0267

4069-0XX

Assembly 14: Charging






**4069-0XX**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
14-1	99A0512	1	Link Assembly, Charge Left Kit
14-2	99A0513	1	Link Assembly, Charge Right Kit
14-3	99A1017	1	Roll Assembly, Charge
NS		1	Screw, Charge Roll PP 99A0263
NS	99A1555	1	Bushing, Charge Roll


Assembly 15: Electronics



## 4069-0XX

Asm-Index	Part Number	Units	Description
15-1	99A1562	1	Engine Board Assembly 010
15-1	99A1563	1	Engine Board Assembly 212
15-1	99A1564	1	Engine Board Assembly 414
15-1	99A1565	1	Engine Board Assembly 616
15-2	1342514	1	Power Cord Set, 8 ft. - U.S., Canada (LV), Nicaragua, Venezuela, Peru (LV), Bolivia, Colombia, Costa Rica, Ecuador, El Salvador, Guatemala, Honduras, Mexico, Panama
15-2	43H5248	1	Power Cord Set, 8 ft. - U.S., Canada (LV), Nicaragua, Venezuela, Peru (LV), Bolivia, Colombia, Costa Rica, Ecuador, El Salvador, Guatemala, Honduras, Mexico, Panama 414/41n/616/61n
15-2	1339538	1	Europe, 6 ft.
15-2	1342536	1	Power Cord Set, 6 ft. - Argentina (HV), Paraguay (HV), Uruguay (HV), APG (LV)
15-2	1342537	1	Power Cord Set, 8 ft. - U.K., Ireland
15-2	1339539	1	Power Cord Set, 6 ft. - Israel
15-2	1339540	1	Power Cord Set, 6 ft. - Switzerland
15-2	1339541	1	Power Cord Set, 6 ft. - South Africa
15-2	1342534	1	Power Cord Set, 8 ft. - Chile (HV)
15-2	1339543	1	Power Cord Set, 8 ft. - Denmark
15-2	1339542	1	Power Cord Set, 6 ft. - Italy
15-2	1374067	1	Power Cord Set, 8 ft. - Peru (HV)
15-2	1342530	1	Power Cord Set - Brazil
15-3	99A0215	1	Fuse, 110 V ac LVPS
15-3	99A0205	1	Fuse, 220 V ac
15-4	99A1822	1	LVPS, 110 V ac 010/212
15-4	99A0214	1	LVPS, 110 V ac 414/616
15-4	99A1640	1	LVPS, 220 V ac 010/212
15-4	99A0199	1	LVPS, 220 V ac 414/616


Assembly 15: Electronics (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
15-5	99A1823	1	Screw, HVPS Mounting PP 99A0263
15-6		1	Screw, Engine Bd Mounting Top PP 99A0263
15-7		1	High Voltage Power Supply
15-8	99A1617	1	Interconnect Board Assembly 212/414/616 o 2 Slot with shield
15-8	99A1607	1	Interconnect Board Assembly 610 o 1 Slot with shield
15-9		2	Screw, Int Board Mounting PP 99A0263
15-9		1	Screw, Int Board Shield Ground PP 99A0263
15-9		2	Screw, Int Shield Mounting PP 99A0263
15-9		3	Screw, Int Shield Mounting PP 99A0263
15-10		2	Screw, Controller Bd Mounting Front PP 99A0263
15-11	99A0426	2	Screw, Parallel Connector Mounting
15-12		2	Screw, Controller Bd Mounting Back PP 99A0263
15-13	99A1556	1	Controller Board Assembly 010
15-13	99A1557	1	Controller Board Assembly 212
15-13	99A1558	1	Controller Board Assembly 414
15-13	99A1559	1	Controller Board Assembly 616
15-13	99A1560	1	Controller Board Assembly 010n
15-13	99A1561	1	Controller Board Assembly 212n
15-13	99A1641	1	Controller Board Assembly 61n/414n
15-14		2	Screw, Engine Bd Mtg Bottom PP 99A0263
15-14		2	Screw, Engine Bd Mtg Front PP 99A0263
15-14		2	Screw, Engine Bd Mtg Top PP 99A0263
NS	99A1612	1	Cable, Deflector
NS	99A0346	1	Clip, EMC Six Finger


Assembly 15: Electronics (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
15-15	99A0408	1	Cover, INA Flat (Blank)
15-16		6	Screw, INA Cover Mounting PP 99A0263
15-16		4	Screw, INA Cover Mounting PP 99A0263
15-16		2	Screw, INA Cover Mounting PP 99A0263
15-17	99A1566	1	Engine Board Shield Assembly
15-18	99A1570	1	Shield, Inner Assembly, 1 slot
		1	o Cover, INA Blank
15-18	99A1571	1	Shield, Inner Assembly, 2 slot
		2	o Cover, INA Blank
15-19	99A0207	1	Shield, Outer 2 slot
15-19	99A0206	1	Shield, Outer 1 slot
15-20		4	Screw, Outer Shield Mounting PP 99A0263
15-20		6	Screw, Outer Shield Mounting PP 99A0263
15-21		1	Screw, Eng/Controller Mtg Ground PP 99A0263
NS	99A0260	1	Screw, Eng/Int Shield Ground PP 99A0263
NS		2	Screw, Controller/Int Ground PP 99A0263
NS		2	Screw, Int/Pan Mounting PP 99A0263
NS		1	Screw, Eng/Int Ground PP 99A0263
NS		1	Clip, Cable
NS		2	Screw, Cable Clip PP 99A0263
NS		1	Shield, Ethernet Blank
NS		1	Shield, Serial Blank

Assembly 15: Electronics (continued)






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
15-22	99A0138	1	Sensor, Standard Bin Level
15-23	99A0803	1	Fan, Main
15-24	99A0255	1	Cable, Main Drive Motor
15-25	99A1542	1	Gearbox, w/Motor 010/212
15-25	99A1543	1	Gearbox, w/Motor 414/616
15-26	99A0256	1	Cable, Integrated Tray
15-27	99A0128	1	Board, Input Tray (ITC)
15-28	99A1632	1	Cable, Auto Connect Bottom
15-29	99A0257	1	Cable, Auto Connect Top 212/414/616


Assembly 15: Electronics (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
15-30	99A0049	1	Fan, Auxiliary 414/616
15-31	99A0466	1	Sensor, Toner Cartridge Level
15-32	99A1593	1	Cable, Smart Cartridge
15-33	99A1501	1	Operator Panel Assembly
15-34	99A1577	1	Switch, Cover Open w/Operator Panel Cable Assembly
15-35	99A0053	1	Sensor, Input
15-36	99A0186	1	Erase Lamp Assembly
15-37	99A0576	1	Cable, Front Harness
15-38	99A0815	2	Contacts, Smart Cartridge

Assembly 15: Electronics (continued)




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
15-39	99A1526	1	Printhead Assembly 010
15-39	99A1527	1	Printhead Assembly 212
15-39	99A1528	1	Printhead Assembly 414
15-39	99A1529	1	Printhead Assembly 616
15-40	99A0889	1	Cable, Laser
15-41	99A0173	1	Solenoid Assembly, Envelope Conditioner
15-42	99A1553	1	Board Assembly, Fuser
15-43	99A1551	1	Sensor, Exit
15-44	99A1603	1	Cover, Fuser Assembly with Thermistor, Thermal Fuse and RH Fuser Lamp Contact Assembly
15-45	99A1554	1	Cable, DC EP Autoconnect to Fuser Board
15-46	99A1651	1	Sensor, Narrow Media
15-47	99A1648	1	Cable, AC EP Autoconnect to Fuser Cover
15-48	99A0247	1	Cable, Hysnc
15-49	99A0250	1	Cable, Mirror Motor
NS	99A1573	1	Cable, Fuser DC EP Autoconnect to Engine Board
NS	99A1575	1	Cable, Fuser AC EP Autoconnect to LVPS
NS	99A1612	1	Cable, Deflector

4069-0XX


Assembly 16: 250 Sheet Tray



## 4069-0XX

Asm-Index	Part Number	Units	Description
16-1	99A0287	1	Pick Arm Assembly
16-2		3	Screw, Auto Comp Mounting PP 99A0263
16-3	99A0070	2	Roll Assembly, Pick
NS	99A0438	2	Bushing, Drive Roll
16-4	99A0448	1	Arm, Paper Out 250
16-5	99A1638	1	Base, 250 Option
16-6	99A0026	1	Tray Bias Arm Assembly
16-7	99A0419	1	Spring, Tray Bias
16-8	99A0058	4	Pad, Machine Mounting
16-9	99A0288	1	Sensor, Option Pass Thru
16-10	99A0272	1	Shaft, 250 Drive
16-11	99A0275	1	Spring, Power Takeoff
16-12	99A0282	1	Cable, 250 Tray Option
16-13	99A0451	1	Roller, Skewed Backup
16-13B	99A0450	1	Retainer, Roller
16-14	99A0276	1	Roll Assembly, Drive 500 Dual
16-15		2	Screw, Wear Plate Mounting PP 99A0263
16-16	99A0277	1	Wear Plate, Pass Thru 250 Tray
NS	99A0278	1	Bellcrank, Roller Release
16-17	99A0280	1	Bushing, Drive Shaft Low
16-18	99A0274	1	Gear, Feed Roll
16-19	99A0273	1	Gear, Bevel
16-20	99A0279	1	Bearing, Drive Shaft
16-21	99A0445	1	Stud Assembly, 250 Frame
16-22	99A0281	1	Cable, 250 Auto Connect Option
16-23		1	Screw, Switch Activate Spring Mounting PP 99A0263
16-24		3	Screw, Option Board Mounting PP 99A0263
16-25	99A0397	1	Board, Option Tray
16-25A	99A0627	1	Jumper, 2-pin
16-26	99A0063	1	Spring, Switch Activate

Assembly 16: 250 Sheet Tray (continued)






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
16-27	99A1536	1	Tray Assembly, 250 Sheet Option
16-28	99A0119	4	Wear Strips
16-29	99A0120	2	Restraint Pad
16-30	99A1537	1	Knob, Paper Size
16-31	99A1637	1	Label, Tray Option Number
16-32	99A0121	1	Clip, 250 Tray Wear
16-33	99A0126	4	Finger, Autosize
16-34	99A0124	1	Plate, Snap-In
16-35	99A0127	1	Slider, Autosize 250
16-36	99A1601	1	Latch, Back Restraint
16-37	99A0893	1	Restraint, Back 250 Sheet Tray
16-38	99A0892	1	Restraint, Side 250 Sheet Tray
NS	99A1666	1	Label, Options
NS	99A0286	1	Spring, Backup Roller
NS	99A0446	1	Aligner Assembly, Paper
NS	99A0452	4	Washer, Frame Mounting
NS	99A0679	2	Bracket, 250 Frame Retention
NS	99A0678	1	Deflector, Base
NS	99A0350	1	Sensor, Paper Low

4069-0XX

# Assembly 17: 500 Sheet Tray



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
17-1	99A0350	1	Sensor, Paper Low
17-2		3	Screw, Auto Comp Mounting PP 99A0263
17-3	99A0405	1	Pick Arm Assembly
17-4	99A0070	2	Pick Roll Assembly
17-5	99A1636	1	Base, 500
17-6	99A0058	4	Pad, Base 500
17-7	99A0419	1	Spring, Tray Bias
17-8	99A0026	1	Tray Bias Arm Assembly
16-9	99A0288	1	Sensor, Option Pass Thru
17-10	99A0895	1	Restraint, Side 500 Sheet Tray
17-11	99A0292	4	Wear Strips
17-12	99A1537	1	Knob, Paper Size
17-13	99A1637	1	Label, Tray Option Numbers
17-14	99A1750	1	Plate, 500 Tray Wear
17-15	99A0126	4	Finger, Autosize
17-16	99A0124	1	Plate, Snap-In
17-17	99A1582	1	Slider, Autosize 500
17-18	99A0120	2	Restraint Pad
17-19	99A1576	1	Tray Assembly, 500 Sheet
17-20	99A1602	1	Restraint, Back 500 Sheet Tray
17-21	99A1601	1	Latch, Back Restraint
17-22	99A0447	1	Shaft, 500 Drive
17-23	99A0397	1	Board, Tray
17-24	99A0275	1	Spring, Power Takeoff
17-25		3	Screw, Board Mounting PP 99A0263
17-26	99A0280	1	Bearing, Drive Shaft Low
17-27	99A0446	1	Aligner Assembly, Paper
17-28		1	Retainer, Aligner Assembly PP 99A0267
17-29	99A0274	1	Gear, Feed Roll
17-30	99A0063	1	Spring, Switch Activate

## Assembly 17: 500 Sheet Tray (continued)




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
17-31	99A0286	1	Spring, Backup Roller
17-32	99A1664	1	Bellcrank, Roller Release
17-33	99A0273	1	Gear, Bevel
17-34	99A0279	1	Bearing, Drive Shaft
17-35	99A0281	1	Cable, 500 Auto Connect Top
17-36	99A1646	1	Stud Assembly, 500 Frame
17-37	99A0282	1	Cable, 500 Auto Connect Bottom
17-38	99A0438	2	Bearing, Drive Roll
17-39	99A1638	1	Wear Plate, Pass Thru
17-40		2	Screw, Wear Plate Mounting PP 99A0263
17-41	99A0451	1	Roller, Skewed Backup
17-42	99A0450	1	Retainer, Roller
17-43	99A0276	1	Roll Assembly, Drive 500
17-44	99A1645	1	Arm, Paper Out 500
NS	99A1666	1	Label, Options
NS	99A0452	4	Washer, Frame Mounting
NS	99A1665	1	Deflector, Base 500

4069-0XX


# Assembly 18: Duplex



## 4069-0XX

Asm-Index	Part Number	Units	Description
18-1	99A1674	1	Cover, System Board
18-2	99A0322	1	Main Frame Assembly 250 Duplex
18-2	99A1693	1	Main Frame Assembly 500 Duplex
18-3	99A0324	1	Idler Assembly, Belt Tension
18-4	99A0326	3	Spring, Aligner
18-5	99A0323	3	Guide Assembly, Paper
18-6	99A1675	1	Guide Assembly, Paper 500
18-7	99A0314	2	Spring, Chassis Ground
18-8		2	Screw, Motor Mount 3 mm PP 99A0413
18-9	99A0328	1	Belt, Motor 114 Gear
18-10	99A0329	1	Pulley, Main Drive 96/54 Gear
18-11	99A0321	1	Motor Assembly, DC Drive
18-12	99A1673	1	Cable, D.C. Motor Tach 250 Duplex
18-13		1	Cam Follower Assembly Kit PP 99A0299
18-14	99A0312	1	Actuator Assembly, Deflector
18-15		2	Screw, Actuator Assembly Mounting PP 99A0413
18-16	99A0339	1	Guide, Return RH Upper 250 Duplex
18-17		2	Screw, Upper Return Guide Mounting PP 99A0413
18-18	99A0340	1	Guide, Return RH Lower 250 Duplex
18-18	99A1680	1	Guide, Return RH Lower 500 Duplex
18-18A	99A1579	1	Guide, Upper 500 Duplex
18-19	99A1671	1	Tray Assembly, Jam Removal 250 Duplex
18-19	99A1681	1	Tray Assembly, Jam Removal 500 Duplex
NS		2	Retainer 6 mm - Backup Roll PP 99A0404
NS		2	Screw, M3x6L:G Supradrive PP 99A0413

Assembly 18: Duplex (continued)






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
18-20	99A0342	1	Guide, LH Lower Return 250 Duplex
18-20	99A1682	1	Guide, LH Lower Return 500 Duplex
18-21	99A0343	1	Guide, Return LH Upper 250 Duplex
18-22	99A0341	1	Sensor, Exit - Optical
18-23		2	Screw, LH Upper Return Guide Mounting PP 99A0413
18-24	99A1668	1	Base Assembly, w/Tray Bias 250 Duplex
18-24	99A1677	1	Base Assembly, w/Tray Bias 500 Duplex
18-25	99A1666	1	Label, Options
18-26	99A0316	1	Shaft, Duplex Drive
18-27	99A0315	1	Spring, Duplex Shaft
18-28	99A0325	1	Gear, Pass Thru Idler
18-29	99A0280	1	Bearing, Drive Shaft Low
18-30	99A0311	1	Cable, Auto Connect Bottom
18-31	99A0274	1	Gear, Pass Thru Drive Roll
18-32	99A0310	1	Cable, Auto Connect Top
18-33		4	Screw, Main Frame Assembly Mounting PP 99A0413
18-34	99A0317	1	Gear, Duplex Bevel
18-35	99A0434	1	Pan, System Board Drip
18-36	99A0279	1	Bearing, Drive Shaft
18-37	99A0191	1	Fuse, .8A SB
18-38	99A1669	1	Board, System with Jumper 250/500 Duplex
NS	99A0627	1	Jumper, System Board 250 Duplex
18-39		2	Screw, System Board Mounting PP 99A0413
18-40		4	Screw, System Board Cover PP 99A0413

4069-0XX


Assembly 18: Duplex (continued)



## 4069-0XX

Asm-Index	Part Number	Units	Description
18-41	99A1703	1	Top Cover Assembly, Movable 250 Duplex
18-41	99A1678	1	Top Cover Assembly, Movable 500 Duplex
18-42	99A1634	1	Top Cover Assembly, Fixed 250 Duplex
18-42	99A1679	1	Top Cover Assembly, Fixed 500 Duplex
NS		1	Retainer, 6 mm Top Cover PP 99A0404
18-43	99A0435	1	Guide, Lower Entry 250 Duplex
18-43	99A1691	1	Guide, Lower Entry 500 Duplex
18-44	99A1672	1	Guide Assembly, Paper Decurl
18-45	99A0332	1	Guide, Center Drive Upper
18-46	99A0307	1	Air Plenum
18-47	99A0335	2	Spring, Decurl Shaft
18-48	99A0334	2	Bushing, Decurl Shaft
18-49	99A0952	1	Frame Assembly, 250 Duplex
18-50		3	Screw, Outer Frame PP 99A0413
18-51	99A0330	1	Guide Assembly, Center Drive
18-52		1	Fan Mounting Kit PP 99A0269
		2	o Screw, Fan Mounting M4x30
		2	o Washer, Fan - M4
		2	o Nut, Fan - M4
18-53	99A0308	1	Fan, Cooling Duplex
18-54		2	Retainer, 5 mm Main Drive PP 99A0404
18-55	99A0337	1	Main Drive Assembly
18-56	99A0319	1	Sensor, Input Optical 250 Duplex
18-57	99A1676	1	Spring, Decurl Adjust
18-58	99A0433	1	Sensor, Input Optical 500 Duplex
18-59		4	Retainer, 6 mm Drive Roll PP 99A0404
18-60	99A0336	1	Shaft Assembly, Drive 250 Duplex
18-60	99A1692	1	Shaft Assembly, Drive 3 Roll 500 Duplex
NS	99A1695	1	Shaft Assembly, Drive 2 Roll 500 Duplex
18-61	99A0333	1	Shaft Assembly, Decurl
NS		1	Screw, Tensioner PP 99A0413
NS		2	Retainer, 6 mm Clutch Roll PP 99A0404
NS	99A0058	4	Feet, Duplex Base


Assembly 19: Output Expander



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
19-1	99A0107	1	Diverter, Upper Also order 99A0104
19-2	99A0104	1	Spring, Upper Diverter
19-3	99A0369	1	Shaft Assembly, Exit Also order PP 99A0572
19-4	99A0052	1	Shaft Assembly, Lower Exit Also order PP 99A0572
19-5		11	Screw, PP 99A0263
19-6	99A0915	1	Board, Output Expander DC motor
19-7	99A0571	1	Cover, Front Control Board with ESD Brush
19-8	99A1683	1	Tray, Output Expander
19-9	99A1666	1	Label, Options
19-10	99A1689	1	Spring Clutch Assembly
19-11	99A1688	1	Diverter Arm
19-12	99A0482	1	Spring, Output Tray
19-13	99A1684	2	Bracket, Attach
19-14	99A0914	1	Output Expander Assembly, Mechanical Linkage
19-15	99A0372	1	Cover, Left Side
19-16	99A0415	2	Spring, Swing Arm
19-17	99A0481	1	Latch, Output Tray
19-18		2	Shaft Bearing PP 99A0572
19-19	99A0414	1	Sensor, Dual Bin Full
19-20	99A1687	1	Flag, Output Paper Level
19-21	99A0409	1	Level Sensor Bracket

Assembly 19: Output Expander (continued)




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
19-22	99A1685	1	Door Assembly, Rear Access
19-23	99A0368	1	Shaft Assembly, Lower Also order PP 99A0572
19-24	99A0363	3	Pulley, Drive
19-25	99A0371	1	Cover, Right Side
19-26	99A0361	1	Belt, 160 Gear
19-27	99A0362	1	Arm Assembly, Belt Idler
19-28	99A0364	1	Spring, Belt Tensioner
19-29	99A0351	1	Sensor, Output Expander Pass Thru
19-30	99A1686	1	Shaft Assembly, Middle 40T Also order PP 99A0572
19-31	99A0912	1	Frame Assembly

4069-0XX

Assembly 20: Envelope Feeder






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
20-1	99A0389	1	Paper Weight Assembly
20-2	99A1694	1	Guide, Edge
20-3	99A1696	1	Cover, Top
20-4	99A0485	1	Sensor, Envelope Pass Thru
20-5	99A0393	1	Clutch, Restraint/Gear
20-6	99A1697	1	Cover, Right Side
20-7	99A0407	1	Base Assembly
20-8	99A0390	1	Support, Slide Out
20-9	99A0488	7	Roller, Support
20-10	99A0382	1	Motor, Stepper D.C.
20-11	99A1666	1	Label, Options
20-12	99A0388	1	Switch, Envelope Out
20-13	99A1700	1	Board Assembly, Electronic Control
NS		6	Screw, Top/Motor/Board
NS	99A0484	1	Belt, Gear Drive
NS	99A0491	1	Bracket, Stack Limiter
NS	99A0400	1	Spring, Restraint Roll Shaft
NS	99A0489	1	Spring, Latch Return
NS	99A0487	1	Flag, Envelope Out Sensor

Assembly 20: Envelope Feeder (continued)




## 4069-0XX

Asm-Index	Part Number	Units	Description
20-14		1	Gear Kit, PP 99A0271
		1	o Gear, Feed
		1	o Gear, Master Cam
		1	o Gear, Drive Roll Shaft
		3	o Gear, Master/Feed Kick
		2	o Gear, Drive Idler
		1	o Gear, Comp Drive/Clutch
		1	o Gear, Kick Roll Connect
		1	o Gear, Kick CNCT Idler
		1	o Gear, Feed Shaft Right
		1	o Gear, Drive Idler Rear
20-15	99A1698	1	Cover, Left Side
NS		1	Retainer, 4 mm PP 99A0404
NS		3	Retainer, Clip 5 mm Shaft PP 99A0404
NS		2	Retainer, 6 mm PP 99A0404
NS		3	Retainer, 7 mm Shaft PP 99A0404
NS	99A0384	1	Shaft, Drive Pressure Roller
NS	99A0385	1	Cable, Auto Connect Front
NS	99A0494	1	Spring, Cam Clutch
NS	99A0427	1	Label, Envelope Orientation Icon
NS	99A0469	1	Deflector Guide
NS	99A1699	1	Guard, Pass Through Sensor

4069-0XX


Assembly 21: High Capacity Feeder



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
21-1	99A0660	1	Frame, Printer Support Frame 2
21-2		3	Screw, Printer Support 2 Frame Mounting PP 99A0675
NS		6	Washer, Printer Support Frame 2 Star PP 99A0677
NS		6	Nut, Printer Support Frame 2, 8-32 Hex PP 99A0676
21-3	99A0698	2	Clamp, Feed Frame
21-4		4	Screws, Feed Frame Clamp PP 99A0675
21-5	99A0691	2	Bearing, Nyliner Leadscrew Top
21-6	99A0656	1	Cover, Side
21-7	99A1809	1	Deflector Assembly Front
21-8	99A0681	4	Strip, Wear
21-9	99A0662	2	Transfer Lead Screw Assembly
21-10	99A0461	1	Label, Tray Option Numbers
21-11		3	Screw, Deflector Mounting 8-18 x 7/8 inch PP 99A0675
21-12	99A0716	1	Bearing, Leadscrew Bottom
21-13	99A0658	2	Magnet, Door
21-14	99A0650	1	Frame Assembly
21-15	99A0661	1	Tray Assembly, Elevator
21-16	99A0671	1	Card Assembly, 2000 Option Control
21-17		4	Nut, 6-32 Hinge Mounting PP 99A0676
21-18		4	Washer, Hinge Mounting Flat PP 99A0677
NS		1	Cable, Optical Sensor
21-19	99A0690	4	Washer, Hinge Mounting Star PP 99A0677
21-20		1	Door Assembly, Front
21-21		2	Hinge, Door
21-22		4	Washer, Card Assembly Mounting PP 99A0677
21-23	99A0392	4	Screw, Card Assembly Mounting PP 99A0675
21-24		1	Kit, Door Switch Spring and Bumper
21-25		1	Washer, Door Switch Spring Mounting PP 99A0677
21-26		1	Nut, Door Switch Spring Mounting PP 99A0676


Assembly 21: High Capacity Feeder (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
21-27	99A0188	3	Guide, Rear Paper with retainer arm Use with 99A0219
21-28	99A0219	6	Screw, Top Frame Mounting PP 99A0675
21-29		1	Frame Assembly, Top with labels
21-30		2	Screw, Top Frame Clamp Mounting PP 99A0675
21-31		2	Washer, Top Frame Clamp PP 99A0677
21-32	99A0719	1	Clamp, Top Frame Mounting
21-33		2	Nut, Base Mounting PP 99A0676
21-34		2	Washer, Base Mounting PP 99A0677
21-35		2	Screw, Base Mounting PP 99A0675
21-36	99A0663	1	Pulley, Idler
21-37	99A0664	1	Belt, Drive
21-38	99A1807	1	Cable, AC Internal Wiring
21-39	99A0653	2	Nut, 2-56 Lower Limit Switch Mounting PP 99A0676
21-40		1	Switch, Lower Limit Microswitch
21-41		2	Nut, Power Supply Ground PP 99A0676
21-42		4	Washer, Motor Plate Mounting PP 99A0677
21-43	99A1808	1	Cord, AC External Jumper
21-44		2	Nut, Power Supply Cover PP 99A0676
21-45	99A0714	1	Cover, Power Supply
21-46		2	Screw, Power Supply Board Mounting PP 99A0675

Assembly 21: High Capacity Feeder (continued)






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
21-47		2	Washer, Power Supply Board PP 99A0677
21-48	99A0667	1	Power Supply Board
21-49	99A0715	1	Cable, Low Voltage Power Supply
NS	99A0684	1	Cable, HCIT-14Pin Flex
21-50	99A0685	1	Bushing
21-51		2	Nut, 2-56 Paper Low Switch Mounting PP 99A0676
21-52	99A0654	1	Switch, Paper Low
21-53	99A0651	1	Sensor Assembly, Paper Out/Upper Limit
21-54		3	Screw, Printer Support 1 Frame Mounting PP 99A0675
NS		6	Washer, Printer Support Frame 1 Star PP 99A0677
NS		6	Nut, Printer Support Frame 1 8-32 Hex PP 99A0676
NS		10	Screw, Door to Door Frame Mounting PP 99A0675
21-55	99A0659	1	Frame, Printer Support 1
21-56	99A0695	1	Parts Kit, Paper Size Switch Assembly including cable, switch, lock washer, nut and knob
21-57		2	Washer, Sensor Bracket Mounting PP 99A0677
21-58		2	Screw, Sensor Bracket Mounting PP 99A0675


Assembly 21: High Capacity Feeder (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
21-59	99A1795	3	Screw w/washer, Motor Mounting PP 99A1793
21-60		3	Nut w/lockwasher, Drive Pulley Plate PP 99A1794
21-61		1	Motor Assembly, DC
21-62		4	Mounting Feet PP 99A0687
21-63	99A1796	4	Foot, Stabilizer PP 99A0672
21-64		1	Belt, DC Motor Drive
21-65		1	Idler Pulley, Belt Tension
21-66		1	Plate, Drive Pulley
21-67	99A1799	1	AC Receptacle, Lower AC
21-68	99A1800	1	Pulley, Drive
21-69	99A1801	1	Retainer, C-Clip
21-70	99A1802	1	AC Receptacle, Upper AC
21-71	99A1803	1	Cover, Top LVPS
21-72	99A1804	3	Nut w/Lockwasher, Top LVPS Cover Mounting
21-73	99A1804	1	Nut w/Lockwasher, Top LVPS Cover Mounting
21-74	99A1805	1	Grommet, Top LVPS Cover


Assembly 21: High Capacity Feeder (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
21-75	99A0281	1	Cable, 250 Auto Connect
21-76	99A0279	1	Bearing, Drive Shaft
21-77	99A0273	1	Gear, Bevel
21-78		2	Screw, Frame Mounting PP 99A0263
21-79	99A0276	1	Roll Assembly, Drive 250 Option
21-80	99A0451	1	Roll, Skew Backup
21-81		1	Retainer, Roller PP 99A0267
21-82		2	Screw, Wear Plate Mounting PP 99A0675
21-83	99A0277	1	Plate Wear, Pass Thru
NS	99A0286	1	Spring, Backup Roller
21-84	99A0445	1	Stud Assembly, 250 Frame
21-85	99A0280	1	Bearing, Drive Shaft Low
21-86	99A0275	1	Spring, Power Takeoff
21-87	99A0272	1	Shaft, 250 Drive
21-88	99A0446	1	Aligner Assembly, Paper
21-89		1	Retainer, Aligner Assembly PP 99A0267
21-90	99A0274	1	Gear, Feed Roll
21-91	99A0278	1	Bellcrank, Roller Release
21-92	99A0688	1	Card Assembly, 2000 Tray Option
21-92	99A0401	1	Card Assembly, 2000 Tray Option
21-93		3	Screw, 2000 Tray Option Card Mounting PP 99A0263


Assembly 21: High Capacity Feeder (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
21-94		3	Screw, Auto Comp Assembly Mounting PP 99A0263
21-95	99A0674	1	Arm Assembly, Pick 2000
21-96	99A0070	2	Roll Assembly, Pick
21-97	99A0692	1	Base, 2000 Option
21-98		1	Screw, Deflector Mounting PP 99A0263
21-99	99A0678	1	Deflector, Base
21-100	99A0288	1	Sensor, Pass Thru
21-101	99A0461	1	Label, Tray Option Numbers
21-102	99A1666	1	Label, Options
21-103		4	Washer, Bracket 250 Frame Retention Mounting PP 99A0677
21-104		4	Screw, Bracket 250 Frame Retention Mounting PP 99A0263
21-105	99A0679	2	Bracket, 250 Frame Retention
NS	99A0448	1	Arm, Paper Out 250 Sheet

Assembly 22: Kiosk - Vertical Paper Adapter






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
22-1	99A0231	1	Bail, Support
22-2	99A0112	1	Mounting, Frame Assembly
22-3	99A1635	1	Shaft, Drive Rear
22-4		12	Retainer PP 99A0240
22-5	99A1647	1	Arm Assembly, Pivot
22-6		16	Screws PP 99A0234
22-7		7	Parts, Pulley PP 99A0208
22-7B		3	Gear, Idler PP 99A0237
22-8	99A0079	1	Tray Assembly, Backup Roller
22-9	99A0087	6	Spring, Backup Roller
22-10	99A0086	6	Roller, Backup
22-11	99A0116	1	Tray Assembly, Drive Roller
22-12	99A0125	1	Frame Assembly, Right Side
22-13	99A0232	1	Cover, Right
22-14	99A1649	2	Belt, 185G
22-15	99A0226	1	Guide, Paper Exit
22-16	99A0122	2	Shaft Assembly, Drive Roller
22-17	99A0137	1	Frame Assembly, Left Side
22-18	99A0088	1	Cover, Backup Tray
22-19	99A0085	1	Tray, Backup Roller

**4069-0XX**

## Assembly 23: Kiosk - Horizontal Paper Adapter




**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
23-1	99A0231	1	Bail, Support
23-2	99A0112	1	Mounting, Frame Assembly
23-3	99A1650	1	Shaft, Drive Rear
23-4		12	Retainer PP 99A0240
23-5	99A1652	1	Arm Assembly, Pivot
23-6		15	Screws PP 99A0234
23-7		7	Parts, Pulley PP 99A0208
23-7B		3	Gear, Idler PP 99A0237
23-8	99A0079	1	Tray Assembly, Backup Roller
23-9	99A0087	6	Spring, Backup Roller
23-10	99A0086	6	Roller, Backup
23-11	99A1654	1	Tray Assembly, Drive Roller
23-12	99A0907	1	Frame Assembly, Right Side
23-13	99A0232	1	Cover, Right
23-14	99A1655	2	Belt, 160G
23-15	99A0122	2	Shaft Assembly, Drive Roller
23-16	99A0906	1	Frame Assembly, Left Side
23-17	99A0088	1	Cover, Backup Tray
23-18	99A0085	1	Tray, Backup Roller

4069-0XX


# Assembly 24: High-Capacity Output Stacker



**4069-0XX**


<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
24-1	99A1748	2	Door Asm, Rear Access
24-2	99A1785	4	Latch, Rear Door
24-3	99A1783	1	Frame, Right
24-4	99A1778	2	Pulley, Output Tray
24-5	99A1782	2	Shaft, Pulley
24-6	99A1790	2	Guide, Output Tray
24-7	99A1779	2	Spring, Output Tray
24-8	99A1746	1	Cover, Right
24-9	99A1747	1	Cover, Front
24-10	99A1701	1	Tray Asm, Output
24-11	99A1781	1	Frame, Left
24-12	99A1666	1	Label, Options
24-13	99A1745	1	Cover, Left
24-NS	99A1751	1	Switch Asm, Tray Sensing
24-NS	99A1777	1	Flag, Tray Sensing Switch
24-NS	99A1780	2	Gear, Damping
24-NS	99A1744	2	Kit, High-Capacity Output Stacker

Assembly 24: High-Capacity Output Stacker (cont'd)



Asm-Index	Part Number	Units	Description
24-14	99A0107	2	Deflector, Upper Also order 99A0104
24-15	99A0104	2	Spring, Upper Diverter
24-16	99A0369	1	Shaft Asm, Exit Upper Stacker Asm
24-17	99A0052	1	Shaft Asm, Stacker Lower Exit Upper Stacker Asm
24-18		12	Bearings, Shaft PP 99A0572
24-19	99A1749	2	Board Asm, High-Capacity Output Stacker
24-20		31	Screws, PP 99A0263
24-21	99A1688	1	Arm, Diverter
24-22	99A1689	1	Clutch Asm, Output Stacker
24-23	99A1784	2	Bracket, Attach
24-24	99A0415	2	Spring, Swing Arm
24-25	99A0914	2	Drive Asm, Output Stacker DC Motor
24-26	99A0409	1	Bracket, Dual Sensor Mounting Upper Stacker Asm
24-27	99A1613	1	Flag, Bin Full Dual Sensor Upper Stacker Asm
24-28	99A0414	1	Sensor Asm, Bin Full Dual Upper Stacker Asm
24-NS	99A1690	1	Belt, 95G Lower Stacker Asm

Assembly 24: High-Capacity Output Stacker (cont'd)






**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
24-29	99A0913	2	Shaft, 40T Middle Output Stacker
24-30	99A0368	2	Shaft Asm Lower
24-31	99A0363	6	Pulley, Drive
24-32	99A0361	1	Belt, 160G Upper Stacker Asm
24-33	99A0362	1	Arm Asm, Belt Idler
24-34	99A0364	2	Spring, Belt Tensioner
24-35	99A1791	1	Stacker Asm, Paper Path Lower
24-35	99A1792	1	Stacker, Asm Paper Path Upper
24-36	99A0351	2	Sensor, Stacker Passthru
24-NS	99A1751	1	Switch Asm
24-NS	99A0462	1	Packet Grease, IBM #23
24-NS	99A0627	1	Jumper, 2 pin (Use with 99A1749)


Assembly 25: 5-Bin Mailbox



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
25-1	99A1512	1	Cover, Redrive Cap
25-2	99A1710	1	Cover, Wire
25-3	99A1711	1	Cover, Top Bin
25-4	99A1784	2	Latch, Rear Access Door
25-5	99A0104	1	Spring, Upper Diverter
25-6	99A1714	1	Door, Rear Access
25-7	99A1723	4	Shaft Asm, Drive
25-8	99A1724	1	Shaft Asm, Drive W/Gear
25-9	99A1708	1	Cover, Right Side
25-10	99A1725	1	Packet, Drive Shaft Bushing
25-11	99A1742	2	Sensor, 5-Bin Mailbox Passthru
25-12	99A1712	5	Tray, Paper Cap
25-13	99A1739	1	Bracket Asm, Bail Attach w/Brush
25-14	99A1743	1	Kit, 5-Bin Mailbox Asm
25-15	99A1666	1	Label, Options
25-16		1	Bail, order 99A1743, 5-Bin Mailbox Asm Kit
25-17	99A1713	5	Support, Paper Tray
25-18	99A1687	5	Stop Asm, Paper Tray
25-19	99A1735	5	Flag, Bin Full
25-20	99A1737	5	Sensor, Dual Paper Height
25-21	99A1736	5	Cable, Dual Sensor
25-22	99A1718	1	Cable Asm, Lower Auto Connect
25-23	99A1716	1	Drive Asm, Main DC Drive
25-24	99A1740	1	Board Asm, 5-Bin Mailbox System
25-25	99A1726	1	Frame Asm, Left w/Clutch Asm
25-26	99A1786	1	Gear, Drive
25-27	99A1719	1	Cable Asm, Upper Auto Connect
25-28		12	Screw, Board Mounting PP 99A0263
25-29	99A1709	1	Cover, Left Side

Assembly 25: 5-Bin Mailbox (continued)



**4069-0XX**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
25-30	99A1741	4	Spring, Diverter
25-31	99A1727	1	Frame Asm, Right Side
25-32	99A1728	4	Cam, Diverter Actuator
25-33	99A1731	4	Spring, Diverter Actuator
25-34	99A1729	4	Latch, Diverter Actuator
25-35	99A1730	4	Arbor, Diverter Actuator
25-36	99A1789	4	C-Clip
25-37	99A1720	1	Bracket, Attach
25-38	99A1732	4	Solenoid, Diverter
25-39	99A1738	5	Deflector, Paper Exit w/Brush
25-40	99A1722	4	Deflector, Paper
25-41	99A1787	4	Deflector
25-42	99A1721	1	Deflector, Paper Top Bin
25-NS	99A1734	1	Spring, Static Ground
25-NS	99A0462	1	Grease Packet, IBM #23
25-NS	99A1715	1	Roller Asm, Rear Access Door
25-NS	99A1717	1	Gear, Drive
25-NS	99A1788	1	Retainer, R-Ring

## Assembly 26: Options

Asm-Index	Part Number	Units	Description
26	99A1752	1	4MB SDRAM DIMM
26	99A1753	1	8MB SDRAM DIMM
26	99A1754	1	16MB SDRAM DIMM
26	99A1755	1	32MB SDRAM DIMM
26	99A1756	1	64MB SDRAM DIMM
26	99A1773	1	128MB SDRAM DIMM
26	99A1757	1	2MB Flash DIMM
26	99A1758	1	4MB Flash DIMM
26	99A1759	1	8MB Flash DIMM
26	99A1774	1	16MB Flash DIMM
26	99A1025	1	SIMM, Bar Code
26	99A1046	1	SIMM, Prescribe 5/4/2 Flash
26	99A0420	1	Token-Ring Card
26	99A0421	1	10/100 Ethernet Card
26	99A0422	1	10Base2/10BaseT Card with T-connector
26	99A0459	1	Hard Disk, w/o Control Board 2.1GB
26	99A0516	1	Board, Hard Disk Control
26	99A1030	1	SIMM, IPDS 5/4/2 Flash
26	99A0629	1	Adapter Card, SES for SCS
26	13A0296	1	Cable, Twinax
26	13A0297	1	Cable, Coax
26	99A0545	1	Adapter, Serial
26	13A0298	1	Cable, Serial
26	99A0467	1	Board, Parallel Port Adapter
26	99A0923	1	Board, USB/Parallel Port
26	99A1044	1	SIMM, Image Quick Tiff
26	99A1031	1	SIMM, Image Quick Web

**Assembly 26: Options (continued)**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
26	99A0911	1	Tray Assembly, 250 Special Media
26	99A1654	1	Tray, Universal Adjustable
26	99A1652	1	Wear Strip, 250 Special Media Tray
26	99A1650	1	Wear Strip, 500 Special Media Tray
26	99A0910	1	Cartridge, Empty Shipping (2)
26	99A0909	1	Cartridge, Empty Shipping (1)
26	99A0863	1	Stacking Device, Integrated Label/Letter
26	99A0864	1	Stacking Device, Integrated Label/Letter
26	99A0865	1	Stacking Device, Legal Label
26	99A0799	1	Drive, Forms HD 2.1GB or larger
26	99A1605	1	Kit, Cap/Stack Bails 500
26	99A0945	1	Kit, Paper Stacking Arm
26	12G1695	1	Marknet N2000e 10/100base Tx Card Asm
26	12G1696	1	Marknet N2000e 10base T/2 Card Asm
26	12G1697	1	Marknet N2000e 4/16 Token Ring Card Asm
26	99A0560	1	Adapter, Omnibus INA Car

**Assembly 27: Miscellaneous**

<b>Asm-Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
27	99A1633	1	Parts Packet, Screws
27	99A0585	1	Parts Packet, Contact Kit
27	99A0267	1	Parts Packet, Retainers
27	99A0268	1	Parts Packet, Springs Paper Feed
27	99A0269	1	Parts Packet, Duplex Option Fan Mounting
27	99A0299	1	Parts Packet, Duplex Option Cam Follower Assembly
27	99A0271	1	Parts Packet, Envelope Option Gears
27	99A0404	1	Parts Packet, Retainers Envelope Option
27	99A0413	1	Parts Packet, Screws Duplex
27	99A0572	1	Parts Packet, 500 Sheet Feeder Option Shaft Bearings
27	99A0577	1	Parts Packet, Cable Ties (10 each)
27	99A0675	1	Parts Packet, Screws High Capacity Feeder
27	99A0676	1	Parts Packet, Nuts High Capacity Feeder
27	99A0677	1	Parts Packet, Washers High Capacity Feeder
27	99A0083	1	Parts Kit, Multipurpose Tray
27	99A0512	1	Parts Kit, Charge Roll Link Asm, Left Side
27	99A0513	1	Parts Kit, Charge Roll Link Asm, Right Side
27	99A0186	1	Parts Kit, Erase Lamp/Lens
27	99A0702	2	Printer Stand Caster, Non Locking
27	99A0703	2	Printer Stand Caster, Locking
27	99A0704	1	Printer Stand Grommet, Wire
27	99A0705	2	Printer Stand Lock, Cam
27	99A0706	1	Printer Stand Storage Shelf
27	99A0707	1	Printer Stand Door Assembly, Cabinet
27	99A0710	1	Printer Stand Filler, Rear Top Piece
27	99A0711	1	Printer Stand Table Assembly, Large
27	99A0712	1	Printer Stand Table Assembly, Small



4069-0XX

**Assembly 27:Miscellaneous (continued)**

<b>Asm- Index</b>	<b>Part Number</b>	<b>Units</b>	<b>Description</b>
27	99A0208	1	Parts Packet, Pulley - Kiosk
27	99A0234	1	Parts Packet, Screws - Kiosk
27	99A0265	1	Packaging, Short
27	99A0295	1	Packaging, Tall with 500/500 Option Tray
27	99A0248	1	Packaging, 500/500 Dual Option Tray Assembly
27	99A0301	1	Packaging, w/o 500/500 Option Tray
27	99A0394	1	Grease Packet, Nyogel 744
27	99A0462	1	Grease Packet, IBM 23

**4069-0XX**

# Index

## A

- Acronyms 1-4
- Adjustment Procedures 4-2
  - Duplex Motor Drive Belts 4-2
  - Fuser Solenoid (HBR) 4-3
  - Gap Adjustment 4-3
  - Paper Alignment Assembly 4-5
  - Printhead Assembly 4-4
- Autoconnect 5-19

## B

- Base Sensor Test 3-17
- Button Test 3-9

## C

- Connector Locations
  - Autoconnect 5-19
  - Duplex Option Board 5-17
  - Engine Board 5-4
  - Envelope Option Board 5-15
  - Fuser Board 5-11
  - High Voltage Power Supply 5-3
  - High-Capacity Output Stacker Board 5-22
  - Interconnect Board 5-12
  - LVPS 5-1
  - Output Expander Control Board 5-20

## D

- Diagnostic Aids 3-1
  - Device Tests 3-2
    - Disk Test/Clean 3-2
    - Flash Test 3-3
    - Quick Disk Test 3-2
- Diagnostic Mode 3-1
- Duplex Tests 3-4
  - Duplex Feed 1 Test 3-7
  - Duplex Feed 2 Test 3-7
  - Duplex Motor Test 3-5
  - Duplex Quick Test 3-4
  - Duplex Sensor Test 3-5

- Error Log 3-8
  - Clearing the Error Log 3-8
  - Viewing the Error Log 3-8
- Hardware Tests 3-9
  - Button Test 3-9
  - LCD Test 3-9
  - Parallel Wrap Test 3-11
  - ROM Memory Test 3-10
  - SDRAM Memory Test 3-10
  - Serial Wrap Test 3-12
- Input Tray Tests 3-14
  - Input Tray Feed Test 3-14
- Paper Feed Tests
  - Base Sensor Test 3-17
  - Input Tray Sensor Test 3-14
  - Output Bin Feed Test 3-15
  - Output Bin Sensor Test 3-16
  - Output Bin Test - Standard Bin 3-15
  - Output Bin X Sensor Test 3-16
  - 5-Bin Mailbox Diverter Test 3-18
- Print Registration 3-19
- Print Tests 3-23
- Printer Setup 3-20
  - Maintenance Page Count 3-21
  - Restore EP Factory Defaults 3-22
  - Setting Configuration ID 3-21
  - Setting the Page Count 3-20
  - Viewing the Permanent Page Count 3-20

- Diagnostic Mode 3-1
- Disabling Download Emulations 3-3
- Disk Test/Clean 3-2
- Duplex Option Board Connectors 5-17
- Duplex Tests 3-4

## E

- Engine Board Connectors 5-4
- Envelope Option Board Connectors 5-15
- Error Codes

## 4069-0XX

Service Error Codes 2-2  
User Error Messages 2-16  
Error Log 3-8  
ESD-Sensitive Parts 4-1

## F

Flash Test 3-3  
Fuser Board 5-11

## G

Gap Adjustment 4-3

## H

Hardware Tests 3-9  
High-Capacity Output Stacker Board  
5-22  
HVPS Connectors 5-3

## I

Input Tray Feed Test 3-14  
Input Tray Sensor Test 3-14  
Interconnect Board Connectors 5-12

## L

Laser Notices ix  
LCD Test 3-9  
Lubrication Specifications 6-1  
LVPS Connectors 5-1

## M

Maintenance Approach 1-3  
Maintenance Page Count 3-21  
Maintenance, Preventive 6-1  
Maintenance, Scheduled 6-2  
Messages  
    Check Device Connection Messages  
        2-22  
    Service Error Codes 2-2  
    User Error Messages 2-16  
    User Line 2 Link Messages 2-21  
    User Line 2 Messages 2-20  
    User Status Messages 2-12

## O

Output Bin Feed Test 3-15

Output Bin Sensor Test 3-16  
Output Bin Test - Standard Bin 3-15  
Output Bin X Sensor Test 3-16  
Output Expander Control Board 5-20

## P

Parallel Wrap Test 3-11  
Parts Catalog 7-1  
    Charging 7-32  
    Covers 7-2  
    Developer Drive 7-24  
    Duplex 7-54  
    Electronics 7-34  
    Envelope Feeder 7-64  
    Frame 7-4  
    Fuser 7-26  
    High Capacity Feeder 7-68  
    High-Capacity Output Stacker 7-84  
    Integrated Paper Tray - 250 Sheet  
        7-18  
    Integrated Paper Tray - 500 Sheet  
        7-20  
    Kiosk - Horizontal Paper Adapter  
        7-82  
    Kiosk - Vertical Paper Adapter 7-80  
    Main Drive 7-22  
    Miscellaneous 7-96  
    Options 7-94  
    Output Expander 7-60  
    Paper Feed  
        Alignment 7-14  
        Autocompensator 7-10  
        Multipurpose Unit 7-12  
        Output 7-16  
    Printhead 7-8  
    Transfer 7-30  
    250 Sheet Tray 7-46  
    5-Bin Mailbox 7-90  
    500 Sheet Tray 7-50  
Power-On Self Test (POST) 2-24  
Preventive Maintenance 6-1

## Q

Quick Disk Test 3-2

## 4069-0XX

### R

Removal Procedures 4-12

#### Removals

Center Pan Assembly 4-16

Controller Board 4-17

Covers 4-12

Developer Drive Assembly 4-18

Duplex Board 4-19

Duplex Front Cover Assembly 4-19

Duplex Front Cover Door 4-19

Duplex Front Cover Door Switch  
4-19

Duplex Motor 4-20

Engine Board 4-21

EP Frame Assembly 4-21

Fans 4-22

Fuser 4-24

Fuser Board (HBR) 4-25

Fuser Cover (HBR) 4-26

Fuser Detack Fingers (HBR) 4-27

Fuser Detack Housing Assembly  
(HBR) 4-27

Fuser Envelope Solenoid 4-29

Fuser Exit Flag Assembly (HBR)  
4-29

Fuser Exit Roll Assembly (HBR)  
4-30

Fuser Lamp (HBR) 4-31

Fuser Lower Exit Guide Assembly  
(HBR) 4-31

Fuser Transfer Plate 4-28

HVPS 4-32

Inner EMC Shield 4-33

Inner Paper Deflector Assembly  
4-34

Integrated Tray Compensator  
Assembly 4-35

Integrated Tray Compensator Pick  
Roll Assembly 4-36

Interconnect Board Assembly 4-37

Left Side Frame 4-39

LVPS 4-41

Main Drive Assembly 4-42

Main Drive Motor 4-43

Multipurpose Tray/Lower Deflector  
Assembly 4-44

Operator Panel 4-46

Operator Panel Cable/Cover Open  
Switch Assembly 4-47

Optional Paper Tray Assembly 4-48

Outer EMC Shield 4-49

Paper Alignment Assembly 4-50

Paper Input Sensor 4-51

Paper Size Sensing Board 4-52

Pick Roll 4-52

Printhead 4-53

Redrive Assembly 4-54

Right Side Frame 4-55

Smart Cartridge Contacts 4-56

Toner Sensor 4-57

Transfer Roll Assembly 4-58

Upper Front Cover Hinge Assembly  
4-59

Upper Front Cover Interlock Switch  
Assembly 4-60

Upper Paper Deflector Assembly  
4-58

Restore EP Factory Defaults 3-22

ROM Memory Test 3-10

### S

Safety Information xvii

Safety Inspection Guide 6-1

Scheduled Maintenance 6-2

Screw Identification Table 4-7

SDRAM Memory Test 3-10

Serial Wrap Test 3-12

#### Service Checks

Charge Roll 2-29

Cover Open Switch/Cable 2-31

Dead Machine 2-32

Duplex Option 2-35

Envelope Feeder Option 2-38

Erase Lamp 2-45

Fan 2-46

Fuser (HBR) 2-47

Fuser Solenoid (HBR) 2-50

High Capacity Feeder Input Tray  
2-55

High-Capacity Output Stacker 2-79

Input Sensor 2-51

Input Tray(s) Option 2-52

## 4069-0XX

Main Drive	2-68	1339542	7-35
Operator Panel	2-69	1339543	7-35
Options	2-71	1342514	7-35
Output Bin Sensor	2-73	1342530	7-35
Output Expander	2-74	1342534	7-35
Paper Feed	2-88	1342536	7-35
Parallel Port	2-90	1342537	7-35
Print Quality	2-91	1374067	7-35
Printhead	2-90	43H5248	7-35
Serial Port	2-104	99A0004	7-3
Smart Cartridge	2-102	99A0007	7-3
Toner Sensor	2-104	99A0026	7-5, 7-47, 7-51
Transfer Roll	2-105	99A0028	7-5
5-Bin Mailbox	2-82	99A0039	7-5
Setting Configuration ID	3-21	99A0045	7-5
Setting the Page Count	3-20	99A0049	7-5, 7-43
Status Messages	2-12	99A0052	7-61, 7-87
Symptom Tables	2-25	99A0053	7-7, 7-43
Base Printer	2-25	99A0055	7-7
Duplex	2-27	99A0058	7-5, 7-47, 7-51, 7-59
Envelope Feeder Option	2-27	99A0060	7-11
High Capacity Feeder Option	2-26	99A0062	7-7
Output Expander Option	2-28	99A0063	7-7, 7-47, 7-51
Paper Tray Options	2-27	99A0070	7-11, 7-47, 7-51, 7-79

## U

Unique Tools	1-3
User Line 2 Link Messages	2-21
User Line 2 Messages	2-20
User Status Messages	2-12

## V

Viewing the Permanent Page Count	3-20
----------------------------------	------

## Part Numbers

12G1695	7-95	1339542	7-35
12G1696	7-95	1339543	7-35
12G1697	7-95	1342514	7-35
13A0296	7-94	1342530	7-35
13A0297	7-94	1342534	7-35
13A0298	7-94	1342536	7-35
1339538	7-35	1342537	7-35
1339539	7-35	1374067	7-35
1339540	7-35	43H5248	7-35
1339541	7-35	99A0004	7-3
		99A0007	7-3
		99A0026	7-5, 7-47, 7-51
		99A0028	7-5
		99A0039	7-5
		99A0045	7-5
		99A0049	7-5, 7-43
		99A0052	7-61, 7-87
		99A0053	7-7, 7-43
		99A0055	7-7
		99A0058	7-5, 7-47, 7-51, 7-59
		99A0060	7-11
		99A0062	7-7
		99A0063	7-7, 7-47, 7-51
		99A0070	7-11, 7-47, 7-51, 7-79
		99A0071	7-13
		99A0072	7-13
		99A0073	7-13
		99A0074	7-13
		99A0075	7-13
		99A0076	7-13
		99A0078	7-13
		99A0079	7-81, 7-83
		99A0081	7-13
		99A0082	7-13
		99A0083	7-13, 7-96
		99A0084	7-13
		99A0085	7-81, 7-83
		99A0086	7-81, 7-83
		99A0087	7-81, 7-83
		99A0088	7-81, 7-83
		99A0089	7-15
		99A0104	7-17, 7-61, 7-87, 7-91
		99A0107	7-17, 7-61, 7-87
		99A0112	7-81, 7-83
		99A0113	7-5
		99A0116	7-81
		99A0119	7-19, 7-49

## 4069-0XX

99A0120	7-19, 7-21, 7-49, 7-51	99A0265	7-97
99A0121	7-19, 7-49	99A0267	7-96
99A0122	7-81, 7-83	99A0268	7-96
99A0124	7-19, 7-21, 7-49, 7-51	99A0269	7-96
99A0125	7-81	99A0271	7-96
99A0126	7-19, 7-21, 7-49, 7-51	99A0272	7-47, 7-77
99A0127	7-19, 7-49	99A0273	7-47, 7-53, 7-77
99A0128	7-7, 7-41	99A0274	7-47, 7-51, 7-57, 7-77
99A0134	7-23	99A0275	7-23, 7-47, 7-51, 7-77
99A0136	7-25	99A0276	7-47, 7-53, 7-77
99A0137	7-81	99A0277	7-47, 7-77
99A0138	7-7, 7-41	99A0278	7-47, 7-77
99A0142	7-27	99A0279	7-47, 7-53, 7-57, 7-77
99A0143	7-29	99A0280	7-47, 7-51, 7-57, 7-77
99A0144	7-27	99A0281	7-47, 7-53, 7-77
99A0148	7-29	99A0282	7-47, 7-53
99A0150	7-29	99A0286	7-49, 7-53, 7-77
99A0157	7-29	99A0287	7-47
99A0158	7-27	99A0288	7-47, 7-51, 7-79
99A0160	7-27	99A0292	7-21, 7-51
99A0167	7-29	99A0295	7-97
99A0173	7-27, 7-45	99A0297	7-29
99A0181	7-31	99A0299	7-96
99A0184	7-31	99A0301	7-97
99A0185	7-31	99A0307	7-59
99A0186	7-31, 7-43, 7-96	99A0308	7-59
99A0188	7-71	99A0310	7-57
99A0191	7-57	99A0311	7-57
99A0199	7-35	99A0312	7-55
99A0205	7-35	99A0314	7-55
99A0206	7-39	99A0315	7-57
99A0207	7-39	99A0316	7-57
99A0208	7-97	99A0317	7-57
99A0214	7-35	99A0319	7-59
99A0215	7-35	99A0321	7-55
99A0219	7-71	99A0322	7-55
99A0226	7-81	99A0323	7-55
99A0231	7-81, 7-83	99A0324	7-55
99A0232	7-81, 7-83	99A0325	7-57
99A0234	7-97	99A0326	7-55
99A0247	7-45	99A0328	7-55
99A0248	7-97	99A0329	7-55
99A0250	7-45	99A0330	7-59
99A0255	7-41	99A0332	7-59
99A0256	7-41	99A0333	7-59
99A0257	7-41	99A0334	7-59
99A0260	7-23, 7-39	99A0335	7-59

## 4069-0XX

99A0336	7-59	99A0434	7-57
99A0337	7-59	99A0435	7-59
99A0339	7-55	99A0438	7-47, 7-53
99A0340	7-55	99A0445	7-47, 7-77
99A0341	7-57	99A0446	7-49, 7-51, 7-77
99A0342	7-57	99A0447	7-51
99A0343	7-57	99A0448	7-47, 7-79
99A0346	7-37	99A0450	7-47, 7-53
99A0349	7-31	99A0451	7-47, 7-53, 7-77
99A0350	7-49, 7-51	99A0452	7-49, 7-53
99A0351	7-63, 7-89	99A0459	7-94
99A0361	7-63, 7-89	99A0461	7-69, 7-79
99A0362	7-63, 7-89	99A0462	7-89, 7-93, 7-97
99A0363	7-63, 7-89	99A0466	7-5, 7-43
99A0364	7-63, 7-89	99A0467	7-94
99A0368	7-63, 7-89	99A0469	7-67
99A0369	7-61, 7-87	99A0481	7-61
99A0371	7-63	99A0482	7-61
99A0372	7-61	99A0484	7-65
99A0382	7-65	99A0485	7-65
99A0384	7-67	99A0487	7-65
99A0385	7-67	99A0488	7-65
99A0388	7-65	99A0489	7-65
99A0389	7-65	99A0490	7-15
99A0390	7-65	99A0491	7-65
99A0392	7-69	99A0492	7-15
99A0393	7-65	99A0494	7-67
99A0394	7-97	99A0512	7-33, 7-96
99A0397	7-47, 7-51	99A0513	7-33, 7-96
99A0400	7-65	99A0516	7-94
99A0401	7-77	99A0545	7-94
99A0404	7-96	99A0549	7-7
99A0405	7-51	99A0556	7-7
99A0407	7-65	99A0559	7-15
99A0408	7-39	99A0560	7-95
99A0409	7-61	99A0564	7-25
99A0410	7-29	99A0565	7-15
99A0413	7-96	99A0566	7-15
99A0414	7-61, 7-87	99A0567	7-7
99A0415	7-61, 7-87	99A0571	7-61
99A0419	7-47, 7-51	99A0572	7-96
99A0420	7-94	99A0575	7-37
99A0421	7-94	99A0576	7-43
99A0422	7-94	99A0577	7-3, 7-96
99A0426	7-37	99A0585	7-96
99A0427	7-67	99A0627	7-47, 7-57, 7-89
99A0433	7-59	99A0629	7-94



## 4069-0XX

99A0650	7-69	99A0815	7-3, 7-43
99A0651	7-73	99A0816	7-3
99A0653	7-71	99A0817	7-3
99A0654	7-73	99A0833	7-27
99A0655	7-69	99A0834	7-3
99A0656	7-69	99A0863	7-95
99A0657	7-69	99A0864	7-95
99A0658	7-69	99A0865	7-95
99A0659	7-73	99A0867	7-5
99A0660	7-69	99A0889	7-45
99A0661	7-69	99A0892	7-19, 7-49
99A0662	7-69	99A0893	7-19, 7-49
99A0663	7-71	99A0895	7-21, 7-51
99A0664	7-71	99A0897	7-29
99A0667	7-73	99A0899	7-7
99A0671	7-69	99A0904	7-5
99A0674	7-79	99A0906	7-83
99A0675	7-96	99A0907	7-83
99A0676	7-96	99A0909	7-95
99A0677	7-96	99A0910	7-95
99A0678	7-49, 7-79	99A0911	7-95
99A0679	7-49, 7-79	99A0912	7-63
99A0681	7-69	99A0913	7-89
99A0684	7-73	99A0914	7-61, 7-87
99A0685	7-73	99A0915	7-61
99A0688	7-77	99A0919	7-29
99A0690	7-69	99A0923	7-94
99A0691	7-69	99A0945	7-95
99A0692	7-79	99A0952	7-59
99A0695	7-73	99A0954	7-23
99A0698	7-69	99A1015	7-31
99A0702	7-96	99A1017	7-33
99A0703	7-96	99A1025	7-94
99A0704	7-96	99A1030	7-94
99A0705	7-96	99A1031	7-94
99A0706	7-96	99A1044	7-94
99A0707	7-96	99A1046	7-94
99A0710	7-96	99A1056	7-11
99A0711	7-96	99A1501	7-3, 7-43
99A0712	7-96	99A1502	7-3
99A0714	7-71	99A1503	7-3
99A0715	7-73	99A1504	7-3
99A0716	7-69	99A1505	7-3
99A0719	7-71	99A1506	7-3
99A0725	7-27	99A1507	7-3
99A0799	7-95	99A1508	7-3
99A0803	7-7, 7-41	99A1509	7-3

## 4069-0XX

99A1510	7-3	99A1561	7-37
99A1511	7-3	99A1562	7-35
99A1512	7-3, 7-91	99A1563	7-35
99A1514	7-7	99A1564	7-35
99A1515	7-5	99A1565	7-35
99A1516	7-5	99A1566	7-39
99A1517	7-7	99A1569	7-23
99A1518	7-5	99A1570	7-39
99A1519	7-5	99A1571	7-39
99A1520	7-27	99A1573	7-45
99A1521	7-27	99A1575	7-45
99A1522	7-5	99A1576	7-21, 7-51
99A1524	7-7	99A1577	7-3, 7-43
99A1525	7-7	99A1578	7-31
99A1526	7-9, 7-45	99A1579	7-55
99A1527	7-9, 7-45	99A1580	7-7
99A1528	7-9, 7-45	99A1582	7-21, 7-51
99A1529	7-9, 7-45	99A1583	7-51
99A1530	7-11	99A1584	7-27
99A1531	7-13	99A1585	7-27
99A1533	7-17	99A1586	7-17
99A1534	7-17	99A1587	7-3
99A1535	7-5	99A1588	7-5
99A1536	7-19, 7-49	99A1591	7-29
99A1537	7-19, 7-21, 7-49, 7-51	99A1592	7-7
99A1538	7-5	99A1593	7-3, 7-43
99A1539	7-5	99A1594	7-3
99A1540	7-5	99A1596	7-7
99A1541	7-5	99A1597	7-29
99A1542	7-23, 7-41	99A1598	7-27
99A1543	7-23, 7-41	99A1599	7-29
99A1544	7-25	99A1600	7-29
99A1545	7-7	99A1601	7-19, 7-21, 7-49, 7-51
99A1546	7-7	99A1602	7-21, 7-51
99A1547	7-29	99A1603	7-27, 7-45
99A1548	7-29	99A1604	7-17
99A1549	7-27	99A1605	7-95
99A1550	7-29	99A1607	7-37
99A1551	7-29, 7-45	99A1608	7-13
99A1553	7-27, 7-45	99A1609	7-11
99A1554	7-27, 7-45	99A1610	7-39
99A1555	7-33	99A1611	7-39
99A1556	7-37	99A1612	7-45
99A1557	7-37	99A1613	7-7, 7-87
99A1558	7-37	99A1616	7-11
99A1559	7-37	99A1617	7-37
99A1560	7-37	99A1631	7-27

## 4069-0XX

99A1632	7-41	99A1684	7-61
99A1633	7-96	99A1685	7-63
99A1634	7-59	99A1686	7-63
99A1635	7-81	99A1687	7-61, 7-91
99A1636	7-51	99A1688	7-61, 7-87
99A1637	7-49, 7-51	99A1689	7-61, 7-87
99A1638	7-47, 7-53	99A1690	7-87
99A1639	7-29	99A1691	7-59
99A1640	7-35	99A1692	7-59
99A1641	7-37	99A1693	7-55
99A1642	7-29	99A1694	7-65
99A1643	7-7	99A1695	7-59
99A1644	7-17	99A1696	7-65
99A1645	7-53	99A1697	7-65
99A1646	7-53	99A1698	7-67
99A1647	7-81	99A1699	7-67
99A1648	7-27	99A1700	7-65
99A1649	7-27, 7-81	99A1701	7-85
99A1650	7-83, 7-95	99A1703	7-59
99A1651	7-29, 7-45	99A1708	7-91
99A1652	7-83, 7-95	99A1709	7-91
99A1654	7-83, 7-95	99A1710	7-91
99A1655	7-83	99A1711	7-91
99A1658	7-29	99A1712	7-91
99A1659	7-29	99A1713	7-91
99A1660	7-27	99A1714	7-91
99A1661	7-27	99A1715	7-93
99A1662	7-5	99A1716	7-91
99A1664	7-53	99A1717	7-93
99A1665	7-53	99A1718	7-91
99A1666	7-49, 7-53, 7-57, 7-61, 7-65, 7-79, 7-85, 7-91	99A1719	7-91
99A1668	7-57	99A1720	7-93
99A1669	7-57	99A1721	7-93
99A1671	7-55	99A1722	7-93
99A1672	7-59	99A1723	7-91
99A1673	7-55	99A1724	7-91
99A1674	7-55	99A1725	7-91
99A1675	7-55	99A1726	7-91
99A1676	7-59	99A1727	7-93
99A1677	7-57	99A1728	7-93
99A1678	7-59	99A1729	7-93
99A1679	7-59	99A1730	7-93
99A1680	7-55	99A1731	7-93
99A1681	7-55	99A1732	7-93
99A1682	7-57	99A1734	7-93
99A1683	7-61	99A1735	7-91
		99A1736	7-91

## 4069-0XX

99A1737	7-91	99A1801	7-75
99A1738	7-93	99A1802	7-75
99A1739	7-91	99A1803	7-75
99A1740	7-91	99A1804	7-75
99A1741	7-93	99A1805	7-75
99A1742	7-91	99A1807	7-71
99A1743	7-91	99A1808	7-71
99A1744	7-85	99A1809	7-69
99A1745	7-85	99A1822	7-35
99A1746	7-85	99A1823	7-37
99A1747	7-85	99A1829	7-21
99A1748	7-85	99A1833	7-7
99A1749	7-87		
99A1750	7-21		
99A1751	7-85, 7-89		
99A1752	7-94		
99A1753	7-94		
99A1754	7-94		
99A1755	7-94		
99A1756	7-94		
99A1757	7-94		
99A1758	7-94		
99A1759	7-94		
99A1773	7-94		
99A1774	7-94		
99A1775	7-3		
99A1777	7-85		
99A1778	7-85		
99A1779	7-85		
99A1780	7-85		
99A1781	7-85		
99A1782	7-85		
99A1783	7-85		
99A1784	7-85		
99A1785	7-85, 7-91		
99A1786	7-91		
99A1787	7-93		
99A1788	7-93		
99A1789	7-93		
99A1791	7-89		
99A1792	7-89		
99A1795	7-75		
99A1796	7-75		
99A1797	7-75		
99A1798	7-75		
99A1799	7-75		
99A1800	7-75		

Lexmark Optra™ T  
(4069-0XX)  
Service Manual  
P/N 99A1487  
September 1999

## Readers Comment Form

You may use this form to communicate your comments about this publication, with the understanding that Lexmark may use or distribute whatever information you supply in any way it believes appropriate without incurring any obligation to you.

1. Did you find the book well organized?  
Yes ☐ No ☐
2. Was the content of the book accurate and complete?  
Yes ☐ No ☐
3. Was the book easy to use?  
Yes ☐ No ☐
4. What can we do to improve the book?

---


---

5. What is your job title?

---

Questions or comments about supplies, service, applications, and so on will slow response time considerably. Please refer those questions or comments to your authorized dealer or point of purchase.


*Note: Please direct all requests for copies of publications to your point of purchase. Publications are not stocked at the location to which this form is addressed.*



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS MAIL PERMIT NO. 2659 LEXINGTON, KY



POSTAGE WILL BE PAID BY ADDRESSEE

LEXMARK INTERNATIONAL INC  
D22A BUILDING 035 3  
740 WEST NEW CIRCLE ROAD  
LEXINGTON KY 40511 9954



Fold Here

Cut Along Line

Tape

Please Do Not Staple

Tape