

Electronics/Power Supply

El	ectronics/Power Su	apply		
	Cable			
1	C4557-60022	Cable assembly - An 11 pin (F) connector to two 3 pin (F) connectors and a 7 pin (F) connector - 36.8cm (14.5 inches) long		
2	C4557-80075	Carriage assembly flex cable - 40.3cm (15.9 inches) long		
3	C5870-60140	Cable assembly - 12 pin (F) connector, 5 pin (F) connector, and 7 pin (F) connector - 43.9cm (17.3 inches) long		
	Keypad			
4	C4557-60009	Keypad assembly		
	PC Board			
5	C4557-60062	Banner PCA and cable assembly		
6	C5870-60209	Ink cartridge carriage PCA NO LONGER SUPPLIED		
7	C5870-69121	Main logic PCA NO LONGER SUPPLIED		
8	C6409-60200	Paper encoder PCA - Controls operation of paper motor		
	Power Cord			
9	8120-8336	Power cord (Quartz Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 100V in Japan)		
10	8120-8337	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in Australia and New Zealand)		
11	8120-8341	Power cord (Quartz Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in the UK)		
12	8120-8345	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in South Africa and India)		
13	8120-8900	Power cord (Flint Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 120V in the USA, Canada, Brazil, Latin America and Saudi Arabia)		
14	8121-0023	Power cord (Flint Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 220V in Europe, Asia Pacific, Germany, Spain, France, Netherlands, Switzerland, Italy, and Portugal)		
	Power Module			
15	C6409-60014	Power Supply Module - 100V-240V, 50/60Hz - Requires separate AC power cord - For worldwide use		
Ex	ternal Case Parts			
	Cover			
16	C4557-40053	Main logic PCA cover - Has cut outs for the parallel interface socket and the power module socket		
17	C4557-60020	Left side case		
18	C6409-60162	Right side case		
	Door			
19	C5870-40045	Top/front access door - Print cartridge access door - Solid door without a window opening		
20	C6458-60001	Top/front access door assembly - Print cartridge access door with strawberry colored window - Includes installation instructions		
21	C6458-60002	Top/front access door assembly - Print cartridge access door with strawberry colored window - Includes installation instructions		
22	C6459-60001	Top/front access door assembly - Print cartridge access door with lime window - With installation instructions		
23	C6459-60002	Top/front access door assembly - Print cartridge access door with lime colored window - Without installation instructions		
24	C6460-60001	Top/front access door assembly - Print cartridge access door with tangerine colored window - With installation instructions		
25	C6460-60002	Top/front access door assembly - Print cartridge access door with tangerine window - Without installation instructions		
26	C6461-60001	Top/front access door assembly - Print cartridge access door with grape colored window - With installation instructions		
27	C6461-60002	Top/front access door assembly - Print cartridge access door with grape colored window - Without installation instructions		
28	C6462-60001	Top/front access door assembly - Print cartridge access door with blueberry colored window - With installation		

instructions



Ex	ternal Case Parts		
	Door		
29	C6462-60002	Top/front access door assembly - Print cartridge access door with blueberry colored window - Without installation instructions NO LONGER SUPPLIED	
30	C6409-40014	I/O and power input cable covering door	
31	C4557-60076	Rear cleanout door assembly - Paper jam cleanout door	
	Foot		
32	C4557-40118	Rubber foot	
	Knob		
33	C4557-40090	Rear cleanout door knob	
	Label		
34	C4557-80057	Front panel label - Includes kodak image enhancements	
	Nameplate/Logo		
35	C5894-40001	Nameplate - DeskJet 710C printer NO LONGER SUPPLIED	
36	C5894-40002	Nameplate - DeskJet 712C printer NO LONGER SUPPLIED	
	Plate		
37	C4557-40014	Back Plate - Holds Latch Spring, Knob and Latch Components of Rear Cleanout Assembly	
Int	erface Cables		
	Cable (Interface)		
	5063-1256	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 2.0m (6.6ft) long	
	5063-1257	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 3.0m (9.8ft) long	
	C2950A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 2.0m (6.6ft) long	
	5063-1256	New Part for C2950A	
	C2951A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 3.0m (9.8ft) long	
	C2990A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) (type A) to 36 pin (M) Centronics (type B) - 1.8m (6ft) long NO LONGER SUPPLIED	
	C2991A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) (type A) to 36 pin (M) Centronics (type B) - 3.0m (10ft) long NO LONGER SUPPLIED	
Ot	her Accessories		
	CD-ROM (Support)		
	C6450-60020	DeskJet and DeskWriter service manual on CD-ROM - Version 4.1	
	C6450-60021	DeskJet and DeskWriter service manual on CD-ROM - Version 4.1	
	Cartridge		
44	51645A	Black print cartridge (High capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for USA)	
45	51645AA	Black print cartridge (High capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Asia/Pacific)	
46	51645AC	Black print cartridge (high capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Canada)	
47	51645AE	Black print cartridge (high capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Europe)	
4			

Black print cartridge (high capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print

area (for Latin America)

51645AL



Other Accessories

Otti	ici Accessories	
(Cartridge	
49	51645G	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for USA)
50	51645GA	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Asia/Pacific)
51	51645GC	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Canada)
52	51645GE	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Europe)
53	51645GL	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Latin America)
54	C1823A	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for USA)
	C1823D	New Part for C1823A
55	C1823AA	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Asia/Pacific)
56	C1823AC	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Canada)
57	C1823AE	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Europe)
58	C1823AL	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Latin America)
59	C1823D	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
60	C1823DA	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
61	C1823DC	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Canada)
62	C1823DE	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
63	C1823DL	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
64	C1823G	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
65	C1823GA	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
66	C1823GE	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
67	C1823GL	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
68	C1823T	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
69	C1823TA	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
70	C1823TE	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
71	C1823TL	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
72	C6613AN	Black print cartridges (High capacity) - (2 pack of 51645A) each prints approximately 840 pages based on 5% density on a 8 inch (20.3cm) by 10 inch (25.4cm) print area (for USA) NO LONGER SUPPLIED
73	C6618AN	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch (20.3cm) by 10 inch (25.4cm) print area (for USA) NO LONGER SUPPLIED



76

77

79 80

HP Parts Reference Guide™ www.hp.com/go/hpparts

Other Accessories Door (Product)

C6458A	Top/front access door assembly - Print cartridge access door with Strawberry colored window - Replaces the existing door
C6459A	Top/front access door assembly - Print cartridge access door with Lime colored window - Replaces the existing door
C6460A	Top/front access door assembly - Print cartridge access door with Tangerine colored window - Replaces the existing door
C6461A	Top/front access door assembly - Print cartridge access door with grape colored window - Replaces the existing door
C6462A	Top/front access door assembly - Print cartridge access door with blueberry colored window - Replaces the existing door
Manual	
C5894-60112	DeskJet 710C/712C user's guide (English) NO LONGER SUPPLIED
C5894-60113	DeskJet 710C/712C user's guide (French) NO LONGER SUPPLIED
C5894-60114	DeskJet 710C/712C user's guide (Japanese) NO LONGER SUPPLIED
C5894-60115	DeskJet 710C/712C user's guide (Portuguese) NO LONGER SUPPLIED
C5894-60116	DeskJet 710C/712C user's guide (Spanish) NO LONGER SUPPLIED
C5894-60117	DeskJet 710C/712C user's guide (Arabic) NO LONGER SUPPLIED
C5894-60118	DeskJet 710C/712C user's guide (Czechoslovakian) NO LONGER SUPPLIED
C5894-60119	DeskJet 710C/712C user's guide (Danish) NO LONGER SUPPLIED
C5894-60120	DeskJet 710C/712C user's guide (Dutch) NO LONGER SUPPLIED
C5894-60121	DeskJet 710C/712C user's guide (Finnish) NO LONGER SUPPLIED
C5894-60122	DeskJet 710C/712C user's guide (German) NO LONGER SUPPLIED
C5894-60123	DeskJet 710C/712C user's guide (Greek) NO LONGER SUPPLIED
C5894-60124	DeskJet 710C/712C user's guide (Hebrew) NO LONGER SUPPLIED
C5894-60125	DeskJet 710C/712C user's guide (Hungarian) NO LONGER SUPPLIED
C5894-60126	DeskJet 710C/712C user's guide (Italian) NO LONGER SUPPLIED
C5894-60127	DeskJet 710C/712C user's guide (Korean) NO LONGER SUPPLIED
C5894-60128	DeskJet 710C/712C user's guide (Norwegian) NO LONGER SUPPLIED
C5894-60129	DeskJet 710C/712C user's guide (Polish) NO LONGER SUPPLIED
C5894-60130	DeskJet 710C/712C user's guide (Russian) NO LONGER SUPPLIED
C5894-60131	DeskJet 710C/712C user's guide (Simplified Chinese) NO LONGER SUPPLIED
C5894-60132	DeskJet 710C/712C user's guide (Swedish) NO LONGER SUPPLIED



www.hp.com/go/hpparts

Other Accessories

Manual

C5894-60133 DeskJet 710C/712C user's guide (Traditional Chinese)

NO LONGER SUPPLIED

C5894-60134 DeskJet 710C/712C user's guide (Thai)

NO LONGER SUPPLIED

C5894-60135 DeskJet 710C/712C user's guide (Turkish)

NO LONGER SUPPLIED

Restraint

C6409-80031 Right carriage restraint - Used to protect the carriage assembly from damage during shipment

Retainer

C6409-80030 Left carriage retainer - Protects the carriage assembly from damage during shipment

Return Kit

5183-5268 Return kit with box and instructions - For returning defective Thermal InkJet (TIJ) 2.5 InkJet cartridges covered under the

CREW program - For USA

5184-2833 Return kit with box and instructions - For returning defective Thermal InkJet (TIJ) 2.5 InkJet cartridges covered under the

CREW program - For use outside of the USA

Training Kit

5183-3032 ASP training kit - Service manual CD-ROM and NTSC training videos for 400, 540, 600, and 700 family DeskJet printers

NO LONGER SUPPLIED

Other Internal Parts

Brace

111

113

115

110 C4557-40128 Left bacKBone brace - Provides support for bacKBone

C4557-40130 Left wall brace - Provides support for left wall

112 C5870-40020 Right backbone brace - Installed on right side of printer base to provide support for backbone

Ferrite Assembly

9170-1655 Ferrite core

Frame

114 C5870-40039 Wing frame - Chassis for in/out tray components

Shield

C4557-00038 Paper motor ESD shield

C4557-00040 Main logic board EMI shield

Spring

117 C4557-00042 EMI spring - Provides grounding point between upper paper guide hanger and EMI shield

NO LÖNGER SUPPLIED

Paper Tray Parts

Cam

C4557-40034 Drawer cam - Short, spring loaded lever attached to the base of the wing frame - Used to draw input tray into position

Channel

C5870-00006 Width adjust channel

Door

162

165

166

163 C4557-40026 Output door - Separates output media from input media

Guide

164 C5870-40037 Length adjuster - Media input length adjuster

NO LONGER SUPPLIED

C6409-40034 Left wall pusher - Pushes against left side of media to maintain correct edge alignment

C6411-40004 Width adjust (Gray) - Holds media against right wall of input tray

NO LONGER SUPPLIED



www.hp.com/go/hpparts

Paper Tray Parts

L	e	٧	е	Ì
---	---	---	---	---

C6411-40006 Banner lever - Used to choose either single sheet paper or continuous feed (Banner) paper 167

NO LONGER SUPPLIED

Pad

168 C4557-80027 Length adjust pad (Poron) - Mounted under the fine length adjuster

Panel

169

170

171

176

179

184

185

186

C4557-40098 Paper tray left inner panel (Left cheek cap) Paper tray right inner panel (Right cheek cap) C4557-40099 NO LONGER SUPPLIED

C4557-40116 Paper tray left outer panel (Left cheek) 172 C5870-40019 Paper tray right outer panel (Right cheek)

Spring

173 C4557-00012 Right wing spring - Applies pressure to right wing during paper output

NO LONGER SUPPLIED

C6409-00017 New Part for C4557-00012

174 C4557-00029 Left wall spring (Front) - Holds left wall assembly in position 175 C4557-00030 Left wall spring (Rear) - Provides pressure against media

C4557-00031 Paper length adjuster spring - Provides tension for paper input length adjuster

C6455-00011 New Part for C4557-00031

177 C4557-00035 Paper pusher spring - Maintains alignment in paper tray 178 C4557-20020 Envelope spring - Holds envelopes in position for picking

C6409-00017 Wing torsion spring - Provides pressure on the wing during paper output

NO LONGER SUPPLIED

Stop

180 C6411-40005 Fine paper length adjuster (Gray) - Holds paper firmly against the back of the paper input tray

Tray

181 Paper input tray pressure plate C4557-60049

182 Paper input tray base - Does not include the pressure plate assembly C5870-40028

Tray Assembly

C6411-60004

183 C5870-60081 Paper input tray assembly (partial) - Includes only base of tray and pressure plate assembly

Paper tray left side assembly (Left cheek assembly) - Includes left cheek, banner PCA and cable assembly, banner

switch lever

NO LONGER SUPPLIED

Wing

C4557-40024 Left wing - Holds printed paper after being ejected C4557-40025 Right wing - Holds printed paper after being ejected

Paper and Other Media

Film (Transparency)

C3832A	Premium InkJet transparency film - A4 size (21.0cm x 29.7cm) - 20 sheets per package
C3835A	Premium InkJet transparency film - A4 size (21.0cm x 29.7cm) - 50 sheets per package
C6053A	Premium InkJet rapid-dry tranparencies - A4 size (21.0cm x 29.7cm) - 50 sheets per package NO LONGER SUPPLIED
C3828A	Premium InkJet transparency film - A size (8.5 x 11-inches) - 20 sheets per package

C3834A Premium InkJet transparency film - A size (8.5 x 11-inches) - 50 sheets per package

C6051A Premium InkJet rapid-dry tranparencies - A size (8.5 x 11-inches) - 50 sheets per package

NO LONGER SUPPLIED



www.hp.com/go/hpparts

Paper and Other Media

Greeting Card Kit

C6587AN Printable Expressions all occasions card kit - Includes 20 greeting cards and envelopes, and a CD-ROM with 24 original

pieces of art

NO LONGER SUPPLIED

Iron-On Transfers

C6065A Iron-on T-shirt transfers - A4 size (21.0cm x 29.7cm) - 10 sheets per package (Asia)

C6050A Iron-on T-shirt transfers - A4 size (21.0cm x 29.7cm) - 10 sheets per package
C6049A Iron-on T-shirt transfers - A size (8.5 x 11-inches) - 10 sheets per package

Paper

C6828A Greeting card paper pack (White) - A size (8.5 x 11-inches) - Felt textured - Includes 20 sheets and 20 envelopes

C6042A Greeting card paper pack (White) - A4 size (21.0cm x 29.7cm) - Includes 20 sheets and 20 envelopes
C1812A Greeting card paper pack (White) - A size (8.5 x 11-inches) - Includes 20 sheets and 20 envelopes

Paper (Banner)

C1821A Banner paper - A4 size (21.0cm x 29.7cm) - Perforated for easy separation - 100 sheets per pack
C1820A Banner paper - A size (8.5 x 11-inches) - 24 lb - Perforated for easy separation - 100 sheets per pack

Paper (Glossy)

C3837A Premium glossy InkJet paper - A4 size (21.0cm x 29.7cm) - 50 sheets per package

C6045A Glossy greeting cards - A4 size (21.0cm x 29.7cm) - 10 scored glossy cards and envelopes
C6044A Glossy greeting cards - A size (8.5 x 11-inches) - 10 scored glossy cards and envelopes

C6817A Professional glossy InkJet brochure and flyer paper - Glossy on both sides - A size (8.5 x 11-inches) - 50 sheets per box

Paper (InkJet Photo)

C6983A Photo quality InkJet paper - With two sided semi-gloss finish - A size (8.5 x 11-inches) - 25 sheets per package

C7007A Photo quality InkJet paper - With two sided matte finish - A size (8.5 x 11-inches) - 100 sheets per package

Paper (InkJet)

51634Z InkJet non-glossy LX paper - A4 size (21.0cm x 29.7cm) - 200 sheets per package C1825A Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 500 sheets per package

C1853A Premium InkJet heavyweight paper - A4 size (21.0cm x 29.7cm) - Coated on both sides - 100 sheets per package

C5977A Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 200 sheets per package
C5977B Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 250 sheets per package
InkJet non-glossy LX paper - A size (8.5 x 11-inches) - 200 sheets per package
C1824A Bright white InkJet paper - A size (8.5 x 11-inches) - 500 sheets per package
C5976A Bright white InkJet paper - A size (8.5 x 11-inches) - 200 sheets per package
C5976B Bright white InkJet paper - A size (8.5 x 11-inches) - 250 sheets per package

Paper (Matte)

C7018A Matte greeting cards (White) - Half fold - A size (8.5 x 11-inches)

C6955A Professional and flyer paper (Matte) - A size (8.5 x 11-inches) - 50 sheets

Paper (Photo)

C6979A Premium glossy photo paper (fast dry time) - A size (8.5 x 11-inches) - 50 sheets per package

C1847A Photo paper - A4 size (21.0cm x 29.7cm) - 20 sheets per package

C6040A Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 15 sheets per package (Europe, Brazil, and Argentina)

C6043A Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 15 sheets per package (Japan)

C6057A Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 20 sheets per package

NO LONGER SUPPLIED

C1846A Photo paper - A size (8.5 x 11-inches) - 20 sheets per package

C6039A Premium glossy photo paper (Fast dry time) - A size (8.5 x 11-inches) - 15 sheets per package



www.hp.com/go/hpparts

Paper and Other Media

Paper (Photo)

C6055A Deluxe glossy photo paper - A size (8.5 x 11-inches) - 20 sheets per pack - For use with DeskJet KIE-logo printers

C6039A New Part for C6055A

Paper (Textured)

C7019A Textured greeting card - White half fold - A size (8.5 inches x 11 inches)

Stickers

C6822A Round re-stickable InkJet stickers - HP bright white 6.35cm (2.5in) round stickers with 3M 'Post-it' adhesive - A size (8.5

x 11-inches) - 10 sheets per package with nine stickers per sheet

C6823A Square re-stickable InkJet stickers - HP bright white 6.35cm (2.5in) square stickers with 3M 'Post-it' adhesive - A size

(8.5 x 11-inches) - 10 sheets per package with nine stickers per sheet

Print Mechanism Parts

Adjuster

C6409-40021 Carriage rod adjuster - Used to support and align the carriage rod (2 used) - This item should be replaced only by

trained, experienced service personnel

NO LONGER SUPPLIED

Backbone

C6409-00013 BacKBone - Large metal item where the main logic PCA and the carriage drive motor are mounted - This item should be

replaced only by trained, experienced service personnel

Belt

188

189

190

191

193

194

199

203

204

C4557-40049 Carriage drive belt - Moves printhead side to side

NO LONGER SUPPLIED

Blade

C2145-00037 ESD blade - Installed between cartridge and carriage PCA ESD blade - Installed between cartridge and carriage PCA

Bracket

C5870-00010 Paper motor mounting bracket

Cam

192 C6409-40040 Pick cam - Controls pressure plate and lever

NO LONGER SUPPLIED

Carriage

C6409-60003

C6409-40031 Ink cartridge carriage

Ink cartridge carriage assembly - This item should be replaced only by trained, experienced service personnel

Encoder

195 C4557-80019 Paper motor encoder disk

Flag

196 C5870-40024 OOPS flag - Media sensor - Mounts on the top right edge of the upper paper guide

Gear

197 C4557-40007 Pick gear

198 C4557-40021 Feed roller idler gear

C4557-40095 Encoder gear

200 C4557-40102 Feed roller cluster gear

Guide

C4557-40013 Rear paper guide - Guides media through rear of printer
 C4557-40020 Lower guide - Platform for seperator peg, spring and pad

C4557-40121 Paper encoder disk guide

C6409-40022 Upper paper guide - Guides media through paper path

NO LONGER SUPPLIED



Pr	int Mechanism Pa	rts
	Latch	
205	C4557-40042	Plastic latch (Y-shaped) - Used in conjuction with the knob to hold the rear paper cleanout door assy in place
206	C4557-60045	Cartridge latch (Black) - Holds black ink cartridge in place NO LONGER SUPPLIED
207	C4557-60046	Cartridge latch (Color) - Holds color ink cartridge in place
	Lever	
208	C4557-00037	Pressure plate lever - Transfers upward pressure from the separator lifter to the kicker
209	C5870-40022	Paper pusher - Small, spring loaded lever attached to pivot - Pushes against left side of paper to maintain right edge alignment
	Lifter	
210	C4557-40063	Separator lifter - Used to lift the separator peg
	Link	
211	C6429-60025	Kicker bar cam link (Spring loaded)
	Motor	
212	C4557-60003	Carriage motor assembly (Includes pulley)
213	C6409-60004	Paper advance motor
	Paper Stacker	
214	C4557-40016	Kicker - Restacks paper in stack after top sheet is picked
	Pin	
215	C4557-40085	Link pin - Small plastic piece
	C6429-60025	New Part for C4557-40085
216	C5870-40029	Separator peg
	Plate	
217	C6409-40028	Belt Attachment Plate - Mounted to back of Ink Cartridge Carriage Assembly - Used to attach the Carriage Drive Belt
	Print Mechanism	
218	C5870-69080	Print mechanism assembly - Complete mechanism with carriage movement, paper picking and service station operations NO LONGER SUPPLIED
	Retainer	
219	C4557-00024	Ferrite retainer - Holds head drive flex cable ferrite
220	C4557-20026	Felt retainer - Holds the lubricating felt to the side of the carriage
	Rod	
221	C6409-20004	Carriage rod - Shaft that the carriage assembly rides on - This item should be replaced only by trained, experienced service personnel
	Roller	
222	C4557-20002	Pinch roller - Provides downward pressure on media as it passes by upper paper guide
223	C4557-40015	Rear roller (Black) - Between paper and rear paper guide NO LONGER SUPPLIED
224	C4557-60025	Pivot feed roller - Shaft with 4 hard rollers - Does not include other items such as gear or encoder
225	C5870-40030	Postscan roller - Shaft with 2 rollers - Mounts on underside of the lower ADF chassis
226	C5870-60092	Pickup roller assembly - Shaft with large rollers, gear, and 2 bearings - Picks paper from paper input tray - Available for trade sales in Europe and Asia/Pacific - Available for authorized service centers only in USA
227	C6409-60037	Pivot feed roller assembly - Shaft with small rollers and paper encoder - This item should be replaced only by trained, experienced service personnel
228	C6426-60049	Pickup roller - Shaft with large rollers - Does not include other items such as gear or bearings



www.hp.com/go/hpparts

Print Mechanism Parts

Separat	or
---------	----

229 C4557-60011 Separator pad

Shaft

230 C4557-20027 Cartridge latch shaft near top of carriage - Used to hold cartridge latches in place

Shift Plate

231 C6455-60057 Shift plate assembly - Five plastic gears held in a two piece plastic frame - Attaches to feedroller assembly

Slide

232 C5870-40036 Integrated slider for carriage assembly

Snap

233 C4557-40150 Pivot snap - Used to hold pivot to pick feed roller shaft

Spring

234 C2145-00033 ESD spring between ESD blade and carriage PCA

235 C4557-00009 Separator spring - Provides pressure between separator assembly and the center drive roller

236 C4557-00011 Drawer spring - Holds input drawer in place

C4557-00017 Belt tension spring - Provides tension for carriage belt
 C4557-00018 Encoder spring - Provides tension for encoder strip

239 C4557-00033 Link spring - Provides tension to shaft of pick cam gear

C4557-20003 Rear roller spring - Flexible axle for rear roller

C4557-20007 Pinch spring - Provides tension on upper paper guide
 C4557-20009 Latch spring - Provides friction for rear access door knob

243 C4557-20024 Shifter spring - Provides tension on the pivot

C4557-20028 EOR tension spring - Maintains tension on wear strip

C5870-20002 Paper stacker (kicker) spring

Strip

240

244

245

247

249

252

246 C4557-80001 Encoder strip - Clear strip with position marks - Used by the sensor in the carriage assembly to determine position

Wear strip - Long, spring loaded strip mounted in top of backbone - Used to ensure smooth ink cartridge carriage motion

Support

248 C6409-00008 Upper paper guide support - Base for upper paper guide

NO LONGER SUPPLIED

Turnaround Assembly

C5870-00004

C4557-60109 Turnaround assembly - Provides carriage belt tension - Does not include spring

Washer

250 C4557-80002 Felt washer - Used to lubricate the carriage rod

Service Station Parts

Absorber

251 C5870-80007 Spittoon sponge - Absorbs excess ink from cartridges

Bonnet

C5870-40016 Service station bonnet - Top cover of the spittoon - Has cutout for pallet/link assembly

Clip

253 C5870-00002 Service station ESD grounding clip

Gear

C4557-40079 Transfer gear (Double gear)
 C5870-40017 Cluster gear (Large gear)



www.hp.com/go/hpparts

Service Station Parts

256

257

259

C5870-60004 Service station motor assembly - Includes PC board and gear

Pallet

Pallet/link assembly - Installed between spittoon and sled cap assembly - Mounting platform for the wiper and capping C6426-60054

systems parts

Shaft

258 C4557-40066 Drive shaft with molded gears on each end - Inside the service station spittoon assembly

Sled

C4557-60013 Sled cap assembly - Top cover of the service station assembly - Includes print cartridge caps (gaskets which keep the

cartridges from drying out when not printing)

Snap

260 C4557-40069 Cap snap - Installed between pallet/link assembly and sled cap assembly - Used to hold the cap spring

Spittoon

261 C5870-40014 Spittoon base - The bottom of the service station assembly

Spring

262 C4557-00026 Cap spring - Provides pressure to cap parked print cartridges

Vent


263 C4557-40068 Cap vent - For equalizing the print cartridge capping pressure

Wiper

264 C4557-60014 Wiper assembly - Metal base with plastic wipers




Main Assembly Locator






Carriage Assembly






Paper Drive Motor Assembly






Paper Tray Assembly (1 of 2)






Paper Tray Assembly (2 of 2)






Printer Mechanism (1 of 2)






Printer Mechanism (2 of 2)






Rear Access Cleanout Assembly

Rear Access Cleanout Assembly-31






Service Station





Upper Paper Guide Assembly





HP Parts Reference Guide

http://www.hp.com/go/parts

HP PartSurfer

http://partsurfer.hp.com

HP Parts Ordering Information

http://www.hp.com/go/hpparts

HP Parts Questions/Comments

http://partsurfer.hp.com/contactus.htm