



OPERATING AND SERVICE MANUAL

12597A-005

TAPE PUNCH INTERFACE KIT

(FOR 2100 SERIES COMPUTERS)

Card Assembly
12597-6001, Rev 832



HP Computer Museum
www.hpmuseum.net

For research and education purposes only.

TABLE OF CONTENTS

Section	Page	Section	Page
I GENERAL INFORMATION		IV THEORY OF OPERATION	
1-1. Introduction	1-1	4-1. Introduction	4-1
1-3. Description	1-1	4-3. Functional Theory of Operation	4-1
1-4. General	1-1	4-11. Detailed Theory of Operation	4-1
1-6. Interface Kit Contents	1-1	4-12. General	4-1
1-8. Specifications	1-1	4-17. Power-On Logic	4-1
1-10. Identification	1-2	4-20. Input Register Logic	4-3
II INSTALLATION		4-23. Flag Logic	4-3
2-1. Introduction	2-1	4-29. Skip-On-Flag Signal	4-3
2-3. Unpacking and Inspection	2-1	4-30. Interrupt Signals	4-4
2-5. Reshipment	2-1	4-34. Service Request Signal	4-4
2-9. Preparation for Installation	2-1	4-36. Output Register Logic	4-7
2-10. Current Requirements	2-1	4-38. Command Logic	4-7
2-12. Interface Card Jumpers	2-1	V MAINTENANCE	
2-14. Installation	2-1	5-1. Introduction	5-1
III PROGRAMMING		5-3. Preventive Maintenance	5-1
3-1. Introduction	3-1	5-6. Troubleshooting	5-1
3-3. General Information	3-1	VI REPLACEABLE PARTS	
3-5. I/O Addressing	3-1	6-1. Introduction	6-1
3-7. Sample Program	3-1	6-5. Ordering Information	6-1

LIST OF ILLUSTRATIONS

Figure	Title	Page	Figure	Title	Page
1-1.	HP 12597A-005 Tape Punch Interface Kit . .	1-1	4-4.	Overall Timing Diagram Showing Operation with 2114, 2115, and 2116 Computers . .	4-5
2-1.	Power Lamp Wiring Diagram	2-2	4-5.	Overall Timing Diagram Showing Operation with 2100 and 21MX Computers	4-6
4-1.	Tape Punch Interface Card Functional Operation Flow Chart	4-2	5-1.	Integrated Circuit Pin Connections and Characteristics	5-2
4-2.	Skip-On-Flag Signal Generation Flow Chart . .	4-3	5-2.	Tape Punch Interface Card Parts Location Diagram and Logic Diagram	5-3
4-3.	Interrupt Operation Flow Chart	4-4			

LIST OF TABLES

Table	Title	Page	Table	Title	Page
1-1.	Tape Punch Interface Kit Specifications . . .	1-1	5-2.	Interface Cable Signal Index	5-2
2-1.	Interface Card Jumper Positions	2-1	6-1.	Numerical Listing of Replaceable Parts	6-2
3-1.	Sample Program	3-2	6-2.	Reference Designations and Abbreviations . .	6-3
5-1.	Tape Punch Interface Card Replaceable Parts List	5-1	6-3.	Code List of Manufacturers	6-4

SECTION I

GENERAL INFORMATION

1-1. INTRODUCTION.

1-2. This manual provides general information, installation instructions, programming instructions, theory of operation, maintenance information, and replaceable parts information for the Hewlett-Packard (HP) 12597A-005 Tape Punch Interface Kit (see figure 1-1).

1-3. DESCRIPTION.

1-4. GENERAL.

1-5. The HP 12597A-005 Tape Punch Interface Kit is an option to the standard HP 12597A 8-Bit Duplex Register Interface Kit. This kit supplies the interfacing requirements for the addition of an HP 2895A or HP 2895B Tape Punch to the user's computer system.

1-6. INTERFACE KIT CONTENTS.

1-7. The HP 12597A-005 Tape Punch Interface Kit consists of the following:


- a. Tape Punch Interface card (part no. 12597-6001).
- b. Interface cable (part no. 12597-60061).
- c. Test connector, 24-pin (part no. 1251-0332).
- d. Operating and service manual (part no. 12597-90025).

1-8. SPECIFICATIONS.

1-9. Table 1-1 lists the specifications for the HP 12597A-005 Tape Punch Interface Kit.

Table 1-1. Tape Punch Interface Kit Specifications

CHARACTERISTICS	SPECIFICATIONS
Output Levels: "1" state "0" state	0 to +0.5V, 12 mA sink maximum +12V, 10K source
Input Levels: "1" state "0" state	0 to +0.5V, 12 mA sink maximum +8V
Computer Power Supply Current Requirements: +12V -12V -2V +4.5V	0.05A 0.02A 0.05A 0.75A
Interface Card Dimensions: Width Height	7-3/4 inches (196,8 mm) 8-11/16 inches (220,7 mm)
Interface Kit Weight: Net Weight Shipping Weight	18 oz (675 gm) 4 lb (1,8 kg)



2158-1

Figure 1-1. HP 12597A-005 Tape Punch Interface Kit .

1-10. IDENTIFICATION.

1-11. This operating and service manual is identified on the title page by interface kit designation and nomenclature, card assembly part number and revision code, manual part number, and publication date. Refer to the information presented in the following paragraphs and ensure that this manual applies to the equipment being serviced.

1-12. Hewlett-Packard uses five digits and a letter (00000A) for standard interface kit designations and a 3-digit suffix (-000) for options to standard interface kits. If the designation of your kit does not agree with that on the title page of this manual, there are differences between your kit and the kit described in this manual. The appropriate manual or manual supplement is available at the

nearest HP Sales and Service Office listed at the back of this manual.

1-13. Printed-circuit cards used as plug-in card assemblies or fixed wired assemblies are identified by a letter, a revision code, and a division code stamped on the card (e.g., A-832-6). The letter identifies the version of the etched trace pattern on the unloaded card. The revision code (three middle digits) refers to the electrical characteristics of the loaded card. The division code (last digit) identifies the Hewlett-Packard division which manufactured the card. If the revision code on the printed-circuit card does not agree with the revision code shown on the title page of this manual, there are differences between your card and the card described in this manual. These differences are described in manual supplements available at the nearest HP Sales and Service Office.

SECTION II

INSTALLATION

2-1. INTRODUCTION.

2-2. This section provides information on unpacking and inspection, reshipment, preparation for installation, and installation of the tape punch interface kit.

2-3. UNPACKING AND INSPECTION.

2-4. If the shipping carton is damaged upon receipt, request that the carrier's agent be present when the kit contents are unpacked. Inspect the card for damage (cracks, broken parts, etc.). If the card is damaged and fails to meet specifications, notify the carrier and the nearest HP Sales and Service Office immediately. (Sales and Service Offices are listed at the back of this manual.) Retain the shipping container and packing material for the carrier's inspection. The HP Sales and Service Office will arrange for repair or replacement of the damaged card without waiting for any claims against the carrier to be settled.

2-5. RESHIPMENT.

2-6. If an item of the kit is to be shipped to Hewlett-Packard for service or repair, attach a tag to the item identifying the owner and indicating the service or repair to be accomplished. Include the model number of the kit.

2-7. Pack the item in the original factory packing material if available. If the original material is not available, standard factory packing material can be obtained from the nearest Hewlett-Packard Sales and Service Office.

2-8. If standard factory packing material is not used, wrap the item in Air Cap TH-240 cushioning (manufactured by Sealed Air Corporation, Hawthorne, New Jersey), or equivalent, and place in a corrugated carton (200 pound test material). Seal the shipping carton securely and mark it "FRAGILE" to ensure careful handling.

2-9. PREPARATION FOR INSTALLATION.

2-10. CURRENT REQUIREMENTS.

2-11. The interface card in this kit obtains its operating current from the computer power supply. Before installing this interface card, determine the current requirements of this card in combination with all other interface or accessory cards already installed in the computer. The computer system documentation describes the procedure for calculating the total current requirements and lists the currents

available from the computer. If the total current requirements exceed the limitations of the computer power supply, a Hewlett-Packard power supply extender unit or I/O extender unit must be used. See table 1-1 for the current requirements of the tape punch interface card.

2-12. INTERFACE CARD JUMPERS.

2-13. There are several jumper wires on the tape punch interface card. These jumpers are used to adapt the card for use with I/O devices other than the tape punch. Before installing the interface card, ensure that the jumpers are positioned as described in table 2-1 (see figure 5-2 for physical location of the jumpers).

Table 2-1. Interface Card Jumper Positions

JUMPER	POSITION
W1	A
W2	A
W3	Connected
W4	Connected
W5	Connected
W6	Connected
W7	Connected
W8	Disconnected
W9	Disconnected

2-14. INSTALLATION.



2-15. To install the tape punch interface kit, proceed as follows:

a. Turn off power at the computer and the tape punch.

b. Insert the interface card in the computer I/O card slot corresponding to the desired select code (address).

c. Connect the interconnecting cable between the interface card and the tape punch. Then connect the POWER lamp wiring portion of interconnecting cable to the POWER lamp on the front panel of the tape punch drawer. (See figure 2-1.)

d. Perform the diagnostic test described in the *High Speed Tape Reader/Punch Diagnostic Reference Manual*, part no. 12597-90031, to verify proper operation of the interface card and tape punch.



2158-2A

Figure 2-1. Power Lamp Wiring Diagram

SECTION III

PROGRAMMING

3-1. INTRODUCTION.

3-2. This section provides programming information for the HP 12597A-005 Tape Punch Interface Kit.

3-3. GENERAL INFORMATION.

3-4. The tape punch interface card provides command logic to start the tape punch and flag logic to signal the computer when the tape punch has completed a punch operation. An output storage register provides buffer storage for transfer of eight bits of data from the computer to the tape punch, and an input storage register provides buffer storage for transfer of status information from the tape punch to the computer. The following paragraphs provide information required to program the operation of the command, flag, input register, and output register logic on the tape punch interface card.

3-5. I/O ADDRESSING.

3-6. Through the use of the I/O extender options, some HP computers are capable of operating up to 56 I/O devices. To provide orderly I/O operations, each I/O card slot is assigned a 2-digit octal address called a select code.

All program instructions calling for action by the tape punch interface card must include the select code of the interface card.

3-7. SAMPLE PROGRAM.

3-8. Table 3-1 provides a sample program showing the use of the tape punch interface card to operate an HP 2895A/B Tape Punch. The sample is an actual program listing prepared on an HP computer system using the HP Assembler software package.

3-9. Under control of the sample program, the tape punch will punch 100 8-bit data words as read from 100 consecutive memory locations. Prior to each data word transfer, the tape punch status will be checked for a possible low-tape condition. Low-tape is indicated by a logic 1 in bit 5 of the tape punch status word. To supply the I/O addressing requirements, the tape punch has been arbitrarily assigned a select code of 16 octal.

3-10. The sample program does not use the computer interrupt system. If the interrupt system has been previously enabled, a CLF 00 instruction must be included at the start of the program to turn off the interrupt system.



Table 3-1. Sample Program

```

0001          ASMB,A,B,L,T
0002*
0003*  THIS IS A SAMPLE PROGRAM DEMONSTRATING THE OPERATION OF THE
0004*  HP 12597A-005 TAPE PUNCH INTERFACE. UNDER CONTROL OF THIS
0005*  PROGRAM, THE TAPE PUNCH WILL PUNCH 100, 8-BIT CHARACTERS AS READ
0006*  FROM 100 CONSECUTIVE MEMORY LOCATIONS. THE TAPE PUNCH STATUS
0007*  WILL BE CHECKED PRIOR TO EACH OUTPUT OPERATION AND AN HLT 66B
0008*  DISPLAYED IF THE STATUS WORD INDICATES TAPE SUPPLY IS LOW.
0009*
0010  00400          ORG 400B  ASSIGN PROGRAM STARTING LOCATION
0011*                OF 400 OCTAL.
0012  00400 060432  START LDA CNT  INITIALIZE COUNT-TO-100 COUNTER
0013  00401 070430          STA CNTR  AND STORE IN LOCATION CNTR.
0014  00402 060433          LDA ITBL  GET STARTING ADDRESS OF DATA TO BE
0015  00403 070431          STA PNTR  PUNCHED AND STORE IN PNTR.
0016*
0017  00404 014417  CHECK JSB STAT  JUMP TO SUBROUTINE THAT WILL GET
0018*                STATUS WORD.
0019  00405 010434          AND MASK  REMOVE INSIGNIFICANT STATUS BITS.
0020  00406 050435          CPA LOW   IS TAPE SUPPLY LOW?
0021  00407 102066          HLT 66B   YES. HALT COMPUTER.
0022  00410 160431          LDA PNTR,I NO. GET CHARACTER TO BE PUNCHED.
0023*
0024  00411 014422          JSB PUNCH JUMP TO SUBROUTINE THAT WILL PUNCH
0025*                A CHARACTER.
0026  00412 034431          ISZ PNTR  MOVE POINTER TO NEXT CHARACTER.
0027  00413 034430          ISZ CNTR  INCREMENT COUNTER. 100 OPERATIONS?
0028  00414 024404          JMP CHECK NO. CHECK STATUS AND PUNCH AGAIN.
0029  00415 102077          HLT 77B   YES. NORMAL END OF PROGRAM.
0030  00416 024400          JMP START TO RERUN PROGRAM PUSH "RUN".
0031*
0032* ** SUBROUTINE ** THIS ROUTINE GETS STATUS WORD FROM PUNCH.
0033*
0034  00417 000000  STAT NOP
0035  00420 102516          LIA TPIF  PUT STATUS WORD IN A-REGISTER.
0036  00421 124417          JMP STAT,I RETURN TO PROGRAM WITH STATUS WORD.
0037*
0038* ** SUBROUTINE ** THIS ROUTINE PUNCHES CHARACTER.
0039*
0040  00422 000000  PUNCH NOP
0041  00423 102316          SFS TPIF  IS TAPE PUNCH READY?
0042  00424 024423          JMP *-1   NO. WAIT.
0043  00425 102616          OTA TPIF  YES. PUT CHARACTER IN INTERFACE
0044*                REGISTER.
0045  00426 103716          STC TPIF,C START TAPE PUNCH.
0046  00427 124422          JMP PUNCH,I RETURN TO PROGRAM.
0047*
0048*  CONSTANT AND STORAGE INFORMATION.
0049*
0050  00430 000000  CNTR BSS 1  RESERVE ONE LOCATION FOR COUNTER.
0051  00431 000000  PNTR BSS 1  RESERVE ONE LOCATION FOR POINTER.
0052  00432 177634  CNT DEC -100 INITIAL COUNT FOR COUNTER.
0053  00433 000122  ITBL OCT 122 STARTING LOCATION OF DATA BLOCK.
0054  00016          TPIF EQU 16B TAPE PUNCH INTERFACE HAS S.C. 16B.
0055  00434 000040  MASK OCT 40
0056  00435 000040  LOW OCT 40  SAMPLE "LOW TAPE" STATUS WORD.
0057*
0058          END START
** NO ERRORS*

```

SECTION IV

THEORY OF OPERATION

4-1. INTRODUCTION.

4-2. This section provides the theory of operation for the 12597-6001 Tape Punch Interface Card.

4-3. FUNCTIONAL THEORY OF OPERATION.

4-4. Figure 4-1 is a flow chart showing the functional theory of operation for the tape punch interface card. The programmed instructions shown in the shaded area of the flow chart are the same as those used in the subroutine portions of the sample program (table 3-1) in Section III of this manual.

4-5. The first programmed instruction (LIA) transfers the tape punch status word from the input storage register to the computer A-register. The status word consists of a single bit (bit 5) that becomes a logic 1 when the tape punch paper tape supply is low. The status word is then checked by software. The computer will normally be programmed to halt if a low-tape condition exists.

4-6. Assuming that the status word does not indicate low tape (bit 5 is logic 0), the next step is to test the state (set or clear) of the Flag FF. If the Flag FF is in the clear state, the punch is busy from some previously programmed punch operation. If the Flag FF is set, the punch is ready to accept data for a new punch operation. An SFS instruction tests the Flag FF. If the Flag FF is clear, the next instruction (JMP *-1) causes the computer to again execute the SFS instruction. This loop continues until the Flag FF is set. An SFS instruction when the Flag FF is set causes the computer to skip the JMP *-1 instruction and continue with the program.

4-7. The computer can also be signaled when the Flag FF is set via interrupt signals (FLG and IRQ) or a Service Request (SRQ) signal. These signals are discussed in detail in paragraphs 4-30 through 4-35.

4-8. The next programmed instruction (OTA) transfers the data word that is to be punched from the computer A-register to the output storage register on the interface card. The tape punch now has data available and requires only that it be commanded to punch the data on paper tape.

4-9. A combined Set Control and Clear Flag (STC xx,C) instruction sets the Control and Command FFs, and clears the Flag Buffer and Flag FFs. The Command FF provides a Punch signal which starts the operation of the tape punch. This completes the programmed instructions required for a punch operation. The computer is now free to perform other operations while the tape punch is completing its operation.

4-10. The tape punch provides a Flag signal when it completes the punch operation. As shown by figure 4-1, the Flag signal sets the Flag Buffer FF and clears the Command FF. At the next computer time T2, an ENF signal sets the Flag FF to indicate that the tape punch is again ready for a new punch operation.

4-11. DETAILED THEORY OF OPERATION.

4-12. GENERAL.

4-13. Diagrams that support the detailed theory of operation for the tape punch interface card include the timing diagram in this section (figure 4-4 or 4-5) and the interface card logic diagram (figure 5-2) in Section V of this manual.

4-14. For an index of signals at the 86-pin edge of the interface card, see Volume Three of the computer system documentation. For an index of signals at the 48-pin edge of the interface card, see table 5-2 in Section V of this manual.

4-15. Logic levels between the computer and the interface card, and logic levels internal to the card are positive-true. The term "true" refers to a signal level of about +3.5 volts and "false" refers to a level of about ground. These signal levels vary somewhat depending on the integrated circuit package involved. Detailed signal level information for the various integrated circuit packages is provided in figure 5-1 in Section V of this manual.

4-16. Signal levels to and from the tape punch are ground-true and are detailed in table 1-1 in Section I of this manual.

4-17. POWER-ON LOGIC.

4-18. When power is initially applied to the computer or the computer PRESET switch is pressed, the computer supplies a POPIO and a CRS signal to the interface card. The POPIO signal sets the Flag Buffer FF and the CRS signal clears the Control and Command FFs. The Control FF, in the clear state, disables the interrupt circuitry on the interface card. A cleared Command FF ensures that the tape punch will be receiving a false Punch signal. At time T2, the computer generates an ENF signal which is gated with the set-side of the Flag Buffer FF to set the Flag FF. The ENF signal also ensures that the IRQ FF is in the clear state.

4-19. The initial operating conditions of the tape punch interface card after power-on are: Flag Buffer and Flag FFs set; Control, Command, and IRQ FFs cleared.




Figure 4-1. Tape Punch Interface Card Functional Operation Flow Chart

4-20. INPUT REGISTER LOGIC.

4-21. The input storage register on the tape punch interface card stores the tape punch status word. Although a full eight bits are transferred to the computer, the status word consists of a single significant bit (bit 5) and, as a logic 1, indicates that the paper tape supply is low. When the interface cable is connected, a ground is applied to pin 21 of the 48-pin edge of the card. This provides a continuous enable to the input storage register so that any change in the status bit is immediately loaded into the bit 5 flip-flop of the register.

4-22. A programmed LIA or LIB instruction addressed to the tape punch interface card provides true SCM, SCL, IOG, and IOI signals. The IOI signal strobes the status word onto the IOBI lines to the computer A- or B-register.

4-23. FLAG LOGIC.

4-24. Before transferring a data word from the computer to the tape punch, the computer must be assured that the punch is not busy operating from some previous data transfer. The state of the Flag FF (set or clear) provides this information to the computer. If the tape punch has not been previously operated, and the state of the Flag FF has not been altered by some programmed instruction, the Flag FF will be in the set state due to the action described in paragraph 4-18. If the tape punch is busy, the Flag FF will be in the clear state due to a programmed Clear Flag instruction described in paragraph 4-39.

4-25. At this point, the discussion of the flag logic assumes that the tape punch is busy and the Flag FF is in the clear state.

4-26. When the tape punch completes an operation, it provides a Flag signal to the interface card. The interface card converts the Flag signal to a 300 nanosecond pulse which clears the Command FF and sets the Flag Buffer FF.

4-27. The timing of the Flag logic at this point is dependent upon the timing of the tape punch and is not related to computer timing. An ENF signal, supplied by the computer every machine cycle at time T2, is gated with the output of the Flag Buffer FF (now in the set state) to set the Flag FF. This action synchronizes the effect of the Flag signal with the computer timing by allowing the Flag FF to be set only at computer time T2.

4-28. When the Flag FF is in the set state, the interface card flag logic responds by generating SKF, FLG and IRQ, or SRQ signals to indicate to the computer that the tape punch is ready to accept a data transfer. The following paragraphs describe how these signals are generated and how they affect computer operation.

4-29. SKIP-ON-FLAG SIGNAL. If the computer is programmed to wait for the Flag FF to be set (for example, an SFS instruction followed by a JMP *-1 instruction as shown in Figure 4-1), the resulting SFS signal gated with a true signal from the set side of the Flag FF generates an SKF signal. This causes the computer to skip the next instruction (in this case JMP *-1) and proceed with the program. Figure 4-2 illustrates the generation of an SKF signal by the interface card. Notice that an SKF signal can also be generated when the Flag FF is in the clear state by programming an SFC instruction. Either way, the state of the Flag FF is being tested and the computer must be programmed to respond accordingly.




Figure 4-2. Skip-On-Flag Signal Generation Flow Chart

4-30. **INTERRUPT SIGNALS.** If the computer interrupt system has been enabled by an STF 00 instruction, the computer can be doing work in the main program rather than waiting for the Flag FF to be set. Figure 4-3 illustrates the functions involved in an interrupt operation. To interrupt the main program when the tape punch is ready, the following conditions must be met:

- Control FF set (paragraph 4-39).
- Flag Buffer FF set (paragraph 4-26).
- Flag FF set (paragraph 4-27).
- IEN signal true (interrupt system enabled).
- PRH signal true (no higher priority interrupts).

4-31. When all of these conditions are established, an SIR signal from the computer at time T5 sets the IRQ FF which generates true FLG and IRQ signals. These signals are used by the computer I/O control and addressing circuits to generate an interrupt request signal.

4-32. At time T2 after interrupt is initiated, an ENF signal clears the IRQ FF. An SIR signal again sets the IRQ FF at time T5 if the PRH signal is still true. The FLG and IRQ signals this time are used by the computer I/O control and addressing circuits to encode the interrupt address.

4-33. The next machine cycle is controlled by the instruction located at the interrupt address in memory. During this machine cycle, an IAK signal clears the Flag Buffer FF and an ENF signal at time T2 clears the IRQ FF. The Flag FF remains set to inhibit lower priority interrupts by providing a false PRL signal. A CLF instruction must be programmed to clear the Flag FF and enable lower priority interrupts just before returning to the main program.

4-34. **SERVICE REQUEST SIGNAL.** If the computer is equipped with the Direct Memory Access (DMA) option, and if the DMA circuits have been initialized, an 8-bit word can be transferred directly from memory to the tape punch




Figure 4-3. Interrupt Operation Flow Chart





Figure 44. Overall Timing Diagram Showing Operation with 2114, 2115, and 2116 Computers



2118-US1

Figure 4-5. Overall Timing Diagram Showing Operation with 2100 and 21MX Computers

in one machine cycle. When the Flag FF on the interface card is set, the interface card supplies a true SRQ signal which enables the DMA circuits. The DMA circuits suspend the computer program for one machine cycle and provide the necessary signals to transfer the 8-bit word and start the tape punch.

4-35. Refer to the applicable DMA option operating and service manual for detailed information on DMA controlled I/O operations.

4-36. OUTPUT REGISTER LOGIC.

4-37. After the computer has been signaled that the tape punch is not busy, the output data word can be transferred to the interface card output storage register. This is accomplished with an OTA or OTB instruction (addressed to the tape punch interface card) in the main program or in an interrupt subroutine. Signals to the interface card resulting from an OTA or OTB instruction are SCM, SCL,

IOG, and IOO. The IOO signal latches the 8-bit data word into the output storage register.

4-38. COMMAND LOGIC.

4-39. With data in the interface card output storage register, the tape punch need only be commanded to punch the data on tape. An STC xx,C (combined Set Control and Clear Flag) instruction with the select code (xx) of the tape punch interface sets the Control and Command FFs and clears the Flag and Flag Buffer FFs. The set side of the Command FF is level-amplified and sent to the tape punch as a Punch signal.

4-40. The set side of the Control FF provides one of the enabling signals for the interrupt logic (see paragraph 4-30). Flag and Flag Buffer FFs in the clear state enable the interface card flag logic. The tape punch will now punch the 8-bit data word and return a Flag signal when it is ready for another punch operation.

SECTION V

MAINTENANCE

5-1. INTRODUCTION.

5-2. This section provides maintenance information for the tape punch interface kit. Included are preventive maintenance instructions, troubleshooting instructions, and maintenance data consisting of a signal index for the interface cable (table 5-2), information pertaining to the integrated circuit characteristics and pin connections (figure 5-1), replaceable parts list for the interface card (table 5-1), and an interface card parts location and logic diagram (figure 5-2).

5-3. PREVENTIVE MAINTENANCE.

5-4. Preventive maintenance for the tape punch interface kit should be performed along with the preventive maintenance routines for the computer system.

5-5. Preventive maintenance consists of running the diagnostic test described in the *High Speed Tape Reader/Punch Diagnostic Reference Manual*, part no. 12597-90031. Also, visually inspect the interface card, cable, and connectors for burned or broken components, connections, and insulation.

5-6. TROUBLESHOOTING.

5-7. Troubleshooting the interface card is accomplished by running the diagnostic test described in the *High Speed Tape Reader/Punch Diagnostic Reference Manual*, part no. 12597-90031 and analyzing error halts as they occur.

5-8. Use the maintenance data contained in this section to further isolate faulty components.

Table 5-1. Tape Punch Interface Card Replaceable Parts List

REFERENCE DESIGNATION	HP PART NO.	DESCRIPTION	MFR CODE	MFR PART NO.
C1 thru C8,18	0140-0198	Capacitor, Fxd, Mica, 200 pF, 5%	28480	0140-0198
C9 thru C16	0140-0191	Capacitor, Fxd, Mica, 56 pF, 5%	28480	0140-0191
C17	0140-0192	Capacitor, Fxd, Mica, 68 pF, 5%	28480	0140-0192
C19,22	0160-0153	Capacitor, Fxd, My, 1000 pF, 10%, 200 VDCW	28480	0160-0153
C20,21	0160-0154	Capacitor, Fxd, My, 2200 pF, 10%	28480	0160-0154
C23 thru C32	0180-0197	Capacitor, Fxd, Elect, 2.2 uF, 10%, 20 VDCW	56289	150D225X9020A2
CR9 thru CR17	1901-0040	Diode, Si, 30 mA, 30 WV	07263	FDG 1088
MC15,36	1820-0068	Integrated Circuit, TTL	56289	USN7410A
MC16,26,47	1820-0956	Integrated Circuit, CTL	07263	SL3459
MC17,25,27,37,46,57,86,94	1820-0054	Integrated Circuit, TTL	56289	USN7400A
MC34,44,64,74	1820-0301	Integrated Circuit, TTL	01295	SN7475N
MC35	1820-0069	Integrated Circuit, TTL	56289	USN7420A
MC45,55,65,75	1820-0974	Integrated Circuit, CTL	07263	SL4817
MC56,66	1820-0071	Integrated Circuit, TTL	56289	USN7440A
Q1 thru Q18	1854-0215	Transistor, Si, NPN	04713	SPS3611
R1 thru R8,18	0757-0417	Resistor, Fxd, Flm, 562 ohms, 1%, 1/8W	28480	0757-0417
R9 thru R17	0757-0442	Resistor, Fxd, Flm, 10.0k, 1%, 1/8W	28480	0757-0442
R19,22,23	0698-3445	Resistor, fxd, Flm, 348 ohms, 1%, 1/8W	28480	0698-3445
R20,30,31	0698-3440	Resistor, Fxd, Flm, 196 ohms, 1%, 1/8W	28480	0698-3440
R21	0698-0082	Resistor, Fxd, Flm, 464 ohms, 1%, 1/8W	28480	0698-0082
R24,25,28,32	0757-0280	Resistor, Fxd, Flm, 1k, 1%, 1/8W	28480	0757-0280
R26,27	0757-0401	Resistor, Fxd, Flm, 100 ohms, 1%, 1/8W	28480	0757-0401
R29	0757-1094	Resistor, Fxd, Flm, 1.47k, 1%, 1/8W	28480	0757-1094
R101,103,105,107,109,111,113, 115,117,118	1810-0008	Resistor Network (6 fxd flm resistors)	28480	1810-0008
R119 thru R122	1810-0020	Resistor Network (7 fxd flm resistors)	28480	1810-0020
W1 thru W7	8159-0005	Jumper Wire	28480	8159-0005




Figure 5-1. Integrated Circuit Pin Connections and Characteristics

Table 5-2. Interface Cable Signal Index

48-PIN CONNECTOR, PIN NO.	TAPE PUNCH CONNECTOR, PIN NO.	SIGNAL
A	1	Bit 1 (CH 1)
B	2	Bit 2 (CH 2)
C	3	Bit 3 (CH 3)
D	4	Bit 4 (CH 4)
E	5	Bit 5 (CH 5)
F	6	Bit 6 (CH 6)
H	7	Bit 7 (CH 7)
J	8	Bit 8 (CH 8)
AA	11	Punch (PI)
6	18	Low Tape (TL)
23	12	Flag (PR)
24,BB	25	Ground (OV)

NOTE: Pins 9 and 24, and pins 7 and 21 are jumpered in the tape punch connector of the interconnecting cable. (See figure 2-1.)








Figure 5-2. Tape Punch Interface Card Parts Location Diagram and Logic Diagram









SECTION VI

REPLACEABLE PARTS

6-1. INTRODUCTION.

6-2. This section provides information for ordering replacement parts for the 12597A-005 Tape Punch Interface Kit. Table 6-1 is a numerical listing of all replaceable parts in the interface kit.

6-3. An interface card replaceable parts list (table 5-1) and parts location diagram (figure 5-2) are provided in Section V of this manual.

6-4. Tables 5-2 and 6-1 list the following information for each replaceable part:

a. Reference designation of the part (table 5-1 only). (Refer to table 6-2 for an explanation of the abbreviations used in the REFERENCE DESIGNATION column.)

b. Hewlett-Packard part number.

c. Description of the part. (Refer to table 6-2 for an explanation of the abbreviations used in the DESCRIPTION column.)

d. A five digit code that corresponds to the manufacturer of the part. (Refer to table 6-3 for a code list of manufacturers.)

e. Manufacturers part number.

f. Total quantity (TQ) of each part used in the kit or assembly (table 6-1 only).

6-5. ORDERING INFORMATION.

6-6. To order replacement parts, address the order or inquiry to the nearest Hewlett-Packard Sales and Service Office. Refer to the list at the back of this manual for addresses. Specify the following information for each part ordered:

a. Identification of the instrument, kit or assembly containing the part (refer to paragraph 1-8).

b. Hewlett-Packard part number for each part.

c. Description of each part.

d. Circuit reference designation for each part (if applicable).



Table 6-1. Numerical Listing of Replaceable Parts

HP PART NO.	DESCRIPTION	MFR CODE	MFR PART NO.	TQ
0140-0191	Capacitor, Fxd, Mica, 56 pF, 5%	28480	0140-0191	8
0140-0192	Capacitor, Fxd, Mica, 68 pF, 5%	28480	0140-0192	1
0140-0198	Capacitor, Fxd, Mica, 200 pF, 5%	28480	0140-0198	9
0160-0153	Capacitor, Fxd, My, 1000 pF, 10%, 200 VDCW	28480	0160-0153	2
0160-0154	Capacitor, Fxd, My, 2200 pF, 10%	28480	0160-0154	2
0180-0197	Capacitor, Fxd, Elect, 2.2 uF, 10%, 20 VDCW	56289	150D225X9020A2	10
0698-0082	Resistor, Fxd, Flm, 464 ohms, 1%, 1/8W	28480	0698-0082	1
0698-3440	Resistor, Fxd, Flm, 196 ohms, 1%, 1/8W	28480	0698-3440	3
0698-3445	Resistor, Fxd, Flm, 348 ohms, 1%, 1/8W	28480	0698-3445	3
0757-0280	Resistor, Fxd, Flm, 1k, 1%, 1/8W	28480	0757-0280	4
0757-0401	Resistor, Fxd, Flm, 100 ohms, 1/8W	28480	0757-0401	2
0757-0417	Resistor, Fxd, Flm, 562 ohms, 1%, 1/8W	28480	0757-0417	9
0757-0442	Resistor, Fxd, Flm, 10.0 ohms, 1%, 1/8W	28480	0757-0442	9
0757-1094	Resistor, Fxd, Flm, 1.47k, 1%, 1/8W	28480	0757-1094	1
1251-0332	Connector, PC	02660	143-024-08 (1158)	1
1810-0008	Resistor Network (6 fxd flm resistors)	28480	1810-0008	10
1810-0020	Resistor Network (7 fxd flm resistors)	28480	1810-0020	4
1820-0054	Integrated Circuit, TTL	56289	USN7400A	8
1820-0068	Integrated Circuit, TTL	56289	USN7410A	2
1820-0069	Integrated Circuit, TTL	56289	USN7420A	1
1820-0071	Integrated Circuit, TTL	56289	USN7440A	2
1820-0301	Integrated Circuit, TTL	01295	SN7475N	4
1820-0956	Integrated Circuit, CTL	07263	SL3459	3
1820-0974	Integrated Circuit, CTL	07263	SL4817	4
1854-0215	Transistor, Si, NPN	04713	SPS3611	18
1901-0040	Diode, Si, 30 mA, 30 WV	07263	FDG 1088	9
8159-0005	Jumper Wire	28480	8159-0005	7
12597-6001	Tape Punch Interface Card	28480	12597-6001	1
12597-60061	Cable	28480	12597-60061	1
12597-90025	Operating and Service Manual	28480	12597-90025	1

Table 6-2. Reference Designations and Abbreviations

REFERENCE DESIGNATIONS		
A = assembly B = motor BT = battery C = capacitor CR = diode DL = delay line DS = indicator (lamp) E = misc hardware F = fuse FL = filter J = receptacle connector	K = relay L = inductor M = meter MC = microcircuit P = plug connector Q = transistor R = resistor RT = thermistor S = switch T = transformer	TB = terminal board TP = test point U = integrated circuit V = vacuum tube, neon bulb, photocell, etc. VR = voltage regulator W = cable, jumper X = socket Y = crystal Z = tuned cavity, network
ABBREVIATIONS		
A = amperes ac = alternating current ad = anode Al = aluminum AR = as required adj = adjust Assy = assembly B = base bp = bandpass bfo = beat frequency oscillator blk = black blu = blue brn = brown brs = brass Btu = British thermal unit bwc = backward wave oscillator Be Cu = beryllium copper C = collector cw = clockwise ccw = counterclockwise cer = ceramic cmo = cabinet mount only com = common crt = cathode-ray tube CTL = capacitor-transistor logic cath = cathode cd pl = cadmium plate Comp = composition conn = connector compl = complete dc = direct current dr = drive DTL = diode-transistor logic depc = deposited carbon dpdt = double-pole, double-throw dpst = double-pole, single-throw E = emitter ext = external encap = encapsulated elctlt = electrolytic F = farads FF = flip-flop flh = flat head flm = film fxd = fixed filh = fillister head G = giga (10^9) Ge = germanium gl = glass	gnd = ground(ed) gra = gray grn = green H = henries Hg = mercury hr = hour(s) Hz = hertz hdw = hardware hex = hexagon, hexagonal ID = inside diameter IF = intermediate frequency in. = inch, inches I/O = input/output int = internal incl = include(s) insul = insulation, insulated impgrg = impregnated incand = incandescent k = kilo (10^3), kilohm lp = low pass m = milli (10^{-3}) M = mega (10^6), megohm My = Mylar mfr = manufacturer mom = momentary mtg = mounting misc = miscellaneous met ox = metal oxide mintr = miniature n = nano (10^{-9}) nc = normally closed or no connection Ne = neon no. = number or normally open np = nickel plated NPN = negative-positive-negative NPO = negative positive zero (zero temperature coefficient) NSR = not separately replaceable NRFR = not recommended for field replacement OD = outside diameter OBD = order by description orn = orange ovh = oval head oxd = oxide p = pico (10^{-12}) PC = printed circuit	ph = Phillips head pk = peak p-p = peak-to-peak pt = point PIV = peak inverse voltage PNP = positive-negative-positive PWV = peak working voltage porc = porcelain posn = position(s) pozi = pozidrive ph brz = phosphor bronze rf = radio frequency rdh = round head rmo = rack mount only rms = root-mean-square RWV = reverse working voltage rect = rectifier r/min = revolutions per minute s = second SB = slow-blow Se = selenium Si = silicon scr = silicon-controlled rectifier sil = silver sst = stainless steel stl = steel spcl = special spdt = single-pole, double-throw spst = single-pole, single-throw semicond = semiconductor Ta = tantalum td = time delay Ti = titanium tgl = toggle thd = thread tol = tolerance TTL = transistor-transistor logic term = terminal U (μ) = micro (10^{-6}) V = volt(s) var = variable vio = violet VDCW = direct current working volts W = watts ww = wirewound wht = white WIV = working inverse voltage yel = yellow

Table 6-3. Code List of Manufacturers

The following code numbers are from the Federal Supply for Manufacturers Cataloging Handbooks H4-1 and H4-2, and the latest supplements.					
CODE NO.	MANUFACTURER	ADDRESS	CODE NO.	MANUFACTURER	ADDRESS
01295	Texas Instruments, Inc., Transistor Products Div.	Dallas, Texas	07263	Fairchild Camera & Instr. Corp., Semi-conductor Div.	Mountain View, Cal.
02660	Amphenol—Borg Electronics Corp.	Broadview, Ill.	28480	Hewlett-Packard Co.	Palo Alto, Cal.
04713	Motorola, Inc., Semiconductor Prod. Div. .	Phoenix, Ariz.	56289	Sprague Electric Co.	North Adams, Mass.



SALES & SERVICE OFFICES



UNITED STATES

ALABAMA
8290 Whitesburg Dr., S.E.
P.O. Box 4207
Huntsville 35802
Tel: (205) 881-4591
TWX: 810-726-2204

Medical Only
228 W. Valley Ave.,
Room 302
Birmingham 35209
Tel: (205) 879-2081/2

ARIZONA
2336 E. Magnolia St.
Phoenix 85034
Tel: (602) 244-1361
TWX: 910-951-1331
2424 East Aragon Rd.
Tucson 85706
Tel: (602) 889-4661

***ARKANSAS**
Medical Service Only
Little Rock 72205
Tel: (501) 664-8773

CALIFORNIA
1430 East Orangethorpe Ave.
Fullerton 92631
Tel: (714) 870-1000
TWX: 910-592-1288

3939 Lankershim Boulevard
North Hollywood 91604
Tel: (213) 877-1282
TWX: 910-499-2170

6305 Arizona Place
Los Angeles 90045
Tel: (213) 649-2511
TWX: 910-328-6147

***Los Angeles**
Tel: (213) 776-7500
3003 Scott Boulevard
Santa Clara 95050
Tel: (408) 249-7000
TWX: 910-338-0518

***Ridgcrest**
Tel: (714) 446-6165
2220 Watt Ave.
Sacramento 95825
Tel: (916) 482-1463
TWX: 910-367-2092

8606 Aero Drive
P.O. Box 23333
San Diego 92123
Tel: (714) 279-3200
TWX: 910-335-2000
Calculators Only
601 California St.
San Francisco 94108
Tel: (415) 989-8470

COLORADO
5600 South Ulster Parkway
Englewood 80110
Tel: (303) 771-3455
TWX: 910-935-0705

CONNECTICUT
12 Lunar Drive
New Haven 06525
Tel: (203) 389-6551
TWX: 910-465-2029

FLORIDA
P.O. Box 24210
2806 W. Oakland Park Blvd.
Ft. Lauderdale 33307
Tel: (305) 731-2020
TWX: 510-955-4099

***Jacksonville**
Medical Service Only
Tel: (904) 725-6333
P.O. Box 13910
6177 Lake Ellenor Dr.
Orlando 32809
Tel: (305) 859-2900
TWX: 810-850-0113

21 East Wright St.
Suite 1
Pensacola 32501
Tel: (904) 434-3081

GEORGIA
P.O. Box 28234
450 Interstate North
Atlanta 30328
Tel: (404) 434-4000
TWX: 810-766-4890

HAWAII
2875 So. King Street
Honolulu 96814
Tel: (808) 955-4455

ILLINOIS
5500 Howard Street
Skokie 60076
Tel: (312) 677-0400
TWX: 910-223-3613

Calculators Only
***St. Joseph**
Tel: (217) 469-2133

INDIANA
7301 North Shadeland Ave.
Indianapolis 46250
Tel: (317) 842-1000
TWX: 910-260-1796

IOWA
1902 Broadway
Iowa City 52240
Tel: (319) 338-9466
Night: (319) 338-9467

***KANSAS**
Derby
Tel: (316) 267-3655

LOUISIANA
P.O. Box 840
3239 Williams Boulevard
Kenner 70052
Tel: (504) 721-6201
TWX: 810-955-5524

KENTUCKY
Medical/Calculator Only
8003 Troutwood Court
Louisville 40291
Tel: (502) 426-4341

MARYLAND
6707 Whitestone Road
Baltimore 21207
Tel: (301) 944-5400
TWX: 710-862-9157

4 Choke Cherry Road
Rockville 20850
Tel: (301) 948-6370
TWX: 710-828-9685

710-828-0487
P.O. Box 1648
2 Choke Cherry Road
Rockville 20850
Tel: (301) 948-6370
TWX: 710-828-9684

MASSACHUSETTS
32 Hartwell Ave.
Lexington 02173
Tel: (617) 861-8960
TWX: 710-326-6904

MICHIGAN
23855 Research Drive
Farmington 48024
Tel: (313) 476-6400
TWX: 810-242-2900

MINNESOTA
2400 N. Prior Ave.
Roseville 55113
Tel: (612) 636-0700
TWX: 910-563-3734

MISSISSIPPI
***Jackson**
Medical Service Only
Tel: (601) 982-9363

MISSOURI
11131 Colorado Ave.
Kansas City 64137
Tel: (816) 763-8000
TWX: 910-771-2087
148 Weldon Parkway
Maryland Heights 63043
Tel: (314) 567-1455
TWX: 910-764-0830

NEBRASKA
Medical Only
11902 Elm Street
Suite 4C
Omaha 68144
Tel: (402) 333-6017

NEW JERSEY
W. 120 Century Rd.
Paramus 07652
Tel: (201) 265-5000
TWX: 710-990-4951

NEW MEXICO
P.O. Box 11634
Station E
11300 Lomas Blvd., N.E.
Albuquerque 87123
Tel: (505) 292-1330
TWX: 910-989-1185

156 Wyatt Drive
Las Cruces 88001
Tel: (505) 526-2485
TWX: 910-983-0550

NEW YORK
6 Automation Lane
Computer Park
Albany 12205
Tel: (518) 458-1550
TWX: 710-441-8270

Calculators Only
1251 Avenue of the Americas
Floor 32 - Suite 3296
New York City 10020
Tel: (212) 265-5575

New York City
Manhattan, Bronx
Contact Paramus, NJ Office
Tel: (201) 265-5000
Brooklyn, Queens, Richmond
Contact Woodbury, NY Office
Tel: (516) 921-0300

201 South Avenue
Poughkeepsie 12601
Tel: (914) 454-7330
TWX: 510-248-0012

39 Saginaw Drive
Rochester 14623
Tel: (716) 473-9500
TWX: 510-253-5981

5858 East Molloy Road
Syracuse 13211
Tel: (315) 455-2486
TWX: 710-541-0482

1 Crossways Park West
Woodbury 11797
Tel: (516) 921-0300
TWX: 510-221-2168

NORTH CAROLINA
P.O. Box 5188
1923 North Main Street
High Point 27262
Tel: (919) 885-8101
TWX: 510-926-1516

OHIO
16500 Sprague Road
Cleveland 44130
Tel: (216) 243-7300
Night: 243-7305
TWX: 810-423-9431

330 Progress Rd.
Dayton 45449
Tel: (513) 859-8202
TWX: 810-459-1925
1041 Kingsmill Parkway
Columbus 43229
Tel: (614) 436-1041

OKLAHOMA
P.O. Box 32008
Oklahoma City 73132
Tel: (405) 721-0200
TWX: 910-638-6862

OREGON
17890 SW Boones Ferry Road
Tualatin 97062
Tel: (503) 620-3350
TWX: 910-467-8714

PENNSYLVANIA
111 Zeta Drive
Pittsburgh 15238
Tel: (412) 782-0400
Night: 782-0401
TWX: 710-795-3124

1021 8th Avenue
King of Prussia Industrial Park
King of Prussia 19406
Tel: (215) 265-7000
TWX: 510-660-2670

SOUTH CAROLINA
6941-0 N. Trenholm Road
Columbia 29260
Tel: (803) 782-6493

TENNESSEE
***Memphis**
Medical Service Only
Tel: (901) 274-7472

***Nashville**
Medical Service Only
Tel: (615) 244-5448

TEXAS
P.O. Box 1270
201 E. Arapahoe Rd.
Richardson 75080
Tel: (214) 231-6101
TWX: 910-867-4723

UTAH
2890 South Main Street
Salt Lake City 84115
Tel: (801) 487-0715
TWX: 910-925-5681

VIRGINIA
Medical Only
P.O. Box 12778
No. 7 Koger Exec. Center
Suite 212
Norfolk 23502
Tel: (804) 497-1026/7

P.O. Box 9854
2914 Hungary Springs Road
Richmond 23228
Tel: (804) 285-3431
TWX: 710-955-0157

WASHINGTON
Bellefield Office Pk.
1203-114th SE
Bellevue 98004
Tel: (206) 454-3971
TWX: 910-443-2446

***WEST VIRGINIA**
Medical/Analytical Only
Charleston
Tel: (304) 345-1640

WISCONSIN
9431 W. Beloit Road
Suite 117
Milwaukee 53227
Tel: (414) 541-0550

***Service Only**

P.O. Box 27409
6300 Westpark Drive
Suite 100
Houston 77027
Tel: (713) 781-6000
TWX: 910-881-2645
205 Billy Mitchell Road
San Antonio 78226
Tel: (512) 434-8241
TWX: 910-871-1170

UTAH
2890 South Main Street
Salt Lake City 84115
Tel: (801) 487-0715
TWX: 910-925-5681

VIRGINIA
Medical Only
P.O. Box 12778
No. 7 Koger Exec. Center
Suite 212
Norfolk 23502
Tel: (804) 497-1026/7

P.O. Box 9854
2914 Hungary Springs Road
Richmond 23228
Tel: (804) 285-3431
TWX: 710-955-0157

WASHINGTON
Bellefield Office Pk.
1203-114th SE
Bellevue 98004
Tel: (206) 454-3971
TWX: 910-443-2446

***WEST VIRGINIA**
Medical/Analytical Only
Charleston
Tel: (304) 345-1640

WISCONSIN
9431 W. Beloit Road
Suite 117
Milwaukee 53227
Tel: (414) 541-0550

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

***Service Only**

CANADA

ALBERTA
Hewlett-Packard (Canada) Ltd.
11748 Kingsway Ave.
Edmonton T5G 0X5
Tel: (403) 452-3670
TWX: 610-831-2431

Hewlett-Packard (Canada) Ltd.
915-42 Avenue S.E. Suite 102
Calgary T2G 1Z1
Tel: (403) 287-1672

BRITISH COLUMBIA
Hewlett-Packard (Canada) Ltd.
837 E. Cordova Street
Vancouver V6A 3R2
Tel: (604) 254-0531
TWX: 610-922-5059

MANITOBA
Hewlett-Packard (Canada) Ltd.
513 Century St.
St. James
Winnipeg R3H 0L8
Tel: (204) 786-7581
TWX: 610-671-3531

NOVA SCOTIA
Hewlett-Packard (Canada) Ltd.
800 Windmill Road
Dartmouth B3C 1L1
Tel: (902) 469-7820

ONTARIO
Hewlett-Packard (Canada) Ltd.
1785 Woodward Dr.
Ottawa K2C 0P9
Tel: (613) 225-6530
TWX: 610-562-8968

Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
Mississauga L4V 1L9
Tel: (416) 678-9430
TWX: 610-492-4246

QUEBEC
Hewlett-Packard (Canada) Ltd.
275 Hymus Blvd.
Pointe Claire H9R 1G7
Tel: (514) 697-4232
TWX: 610-422-3022
TLX: 05-821521 HPCL

Hewlett-Packard (Canada) Ltd.
2378 Galvani Street
St-Foy G1N 4G4
Tel: (418) 688-8710

FOR CANADIAN AREAS NOT LISTED:
Contact Hewlett-Packard (Canada)
Ltd. in Mississauga.

CENTRAL AND SOUTH AMERICA

ARGENTINA
Hewlett-Packard Argentina
S.A. C.E. I.
Lavalle 1171-3° Piso
Buenos Aires
Tel: 35-0436, 35-0627, 35-0341
Cable: HEWPACK ARG

BOLIVIA
Stambuk & Mark (Bolivia) Ltda.
Av. Mariscal, Santa Cruz 1342
La Paz
Tel: 40626, 53163, 52421
Telex: 3560014
Cable: BUKMAR

BRAZIL
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Frei Caneca, 1.152-Bela Vista
01307-São Paulo-SP
Tel: 288-71-11, 287-81-20,
287-61-93
Telex: 309151/2/3
Cable: HEWPACK São Paulo

Hewlett-Packard Do Brasil
I.E.C. Ltda.
Praça Dom Feliciano, 78-8°
andar (Sala 806/8)
Porto Alegre-RS
Tel: 25-84-70-DDO (0512)
Cable: HEWPACK Porto Alegre
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Siqueira Campos, 53, 4°
andar Copacabana
2000-Rio de Janeiro-GB
Tel: 257-80-94-DDO (021)
Telex: 2100 79 HEWPACK
Cable: HEWPACK
Rio de Janeiro

CHILE
Calcagni & Metcalfe Ltda.
Calle Lira 61, Oficina 5
Casilla 2118
Santiago, 1
Tel: 287-71-11, 287-81-20,
287-61-93
Telex: 309151/2/3
Cable: HEWPACK São Paulo

COLOMBIA
Instrumentación
Henrik A. Langebaek & Kier S.A.
Carrera 7 No. 48-59
Apartado Aéreo 6287
Bogotá, 1 O.E.
Tel: 45-78-06, 45-55-46
Cable: AARIS Bogotá
Telex: 44400INSTCO

COSTA RICA
Científica Costarricense S.A.
Apartado 10159
San José
Tel: 21-86-13
Cable: GALGUR San José

GUATEMALA
IPESA
Avenida La Reforma 3-48,
Zona 9
Guatemala
Tel: 63627, 64786
Telex: 4192 TELLTRO GU

MEXICO
Hewlett-Packard Mexicana,
S.A. de C.V.
Torres Adalid No. 21, 1° Piso
Col. del Valle
México, 12, D.F.
Tel: (905) 543-42-32
Telex: 017-74-507
Hewlett-Packard Mexicana,
S.A. de C.V.
Ave. Constitución No. 2184
Monterrey, N.L.
Tel: 48-71-32, 48-71-84

NICARAGUA
Roberto Terán G.
Apartado Postal 689
Edificio Terán
Managua
Tel: 3451, 3452
Cable: ROTERAN Managua

PANAMA
Eléctrico Balboa, S.A.
P.O. Box 4929
Calle Samuel Lewis
Ciudad de Panamá
Tel: 64-2700
Telex: 3431103 Curunda,
Canal Zone
Cable: ELECTRON Panama

PARAGUAY
Z.J. Melamed S.R.L.
Division: Aparatos y Equipos
Médicos
Division: Aparatos y Equipos
Investigación
P.O. Box 676
Chile, 482, Edificio Victoria
Asunción
Tel: 4-5069, 4-6272
Cable: RAMEL

PERU
Compañía Electro Médica S.A.
Ave. Enrique Canaval 312
San Isidro
Casilla 1030
Lima
Tel: 22-3900
Cable: ELMED Lima
PUERTO RICO
San Juan Electronics, Inc.
P.O. Box 5167
Ponce de León 154
Pda. 3-PTA de Tierra
San Juan 00906
Tel: (809) 725-3342, 722-3342
Cable: SATRONICS San Juan
Telex: SATRON 3450 332

URUGUAY
Pablo Ferrando S.A.
Comercial e Industrial
Avenida Italia 2877
Casilla de Correo 370
Montevideo
Tel: 40-3102
Cable: RADIUM Montevideo

VENEZUELA
Hewlett-Packard de Venezuela
C.A.
Apartado 50933
Edificio Segre
Torre Transversal
Los Ruices Norte
Caracas 107
Tel: 21146 HEWPACK
Cable: HEWPACK Caracas

FOR AREAS NOT LISTED, CONTACT:
Hewlett-Packard
Inter-Américas
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 493-1501
Telex: 910-373-1260
Cable: HEWPACK Palo Alto
Telex: 034-8300, 034-8493

EUROPE

AUSTRIA

Hewlett-Packard Ges.m.b.H.
Handelska 52/3
P.O. Box 7
A-1205 Vienna
Tel: (0222) 33 66 06 to 09
Cable: HEWPAK Vienna
Telex: 75923 hewpak a

BELGIUM

Hewlett-Packard Benelux
S.A./N.V.
Avenue de Col-Vert, 1.
(Groenkraklaan)
B-1170 Brussels
Tel: (02) 672 22 40
Cable: PALOEN Brussels
Telex: 23 494 paloben br

DENMARK

Hewlett-Packard A/S
Datavej 32
DK-3460 Birkerød
Tel: (01) 81 66 40
Cable: HEWPAK AS
Telex: 166 40 hp as
Hewlett-Packard A/S
Navevej 1
DK-8600 Silkeborg
Tel: (06) 82 71 66
Telex: 166 40 hp as
Cable: HEWPAK AS

FINLAND

Hewlett-Packard Oy
Nahkahousintie 5
P.O. Box 6
SF-00211 Helsinki 21
Tel: 6923031
Cable: HEWPAKDY Helsinki
Telex: 12-15363

FRANCE

Hewlett-Packard France
Quartier de Courtois
Boite Postale No. 6
F-91401 Orsay
Tel: (1) 90 78 25
Cable: HEWPAK Orsay
Telex: 60048
Hewlett-Packard France
Agence Régionale
Chemin des Mouilles
Boite Postale No. 12
F-69130 Ecully
Tel: (78) 33 81 25
Cable: HEWPAK Ecully
Telex: 31 617
Hewlett-Packard France
Agence Régionale
Zone Aéronautique
Avenue Clément Ader
F-31770 Colomiers
Tel: (61) 78 11 55
Telex: 51957

Hewlett-Packard France
Agence Régionale
Centre d'aviation générale
F-13721 Aéroport de
Marignane
Tel: (91) 89 12 36
TWX: 41770 F

Hewlett-Packard France
Agence Régionale
63, Avenue de Rochester
F-35000 Rennes
Tel: 74912 F
Telex: 74 912 F

Hewlett-Packard France
Agence Régionale
74, Allée de la Robertsau
F-67000 Strasbourg
Tel: (88) 35 23 20/21
Telex: 89141
Cable: HEWPAK STRBG
Medical/Calculator Only
Hewlett-Packard France
Agence Régionale
Centre Vauban
201, rue Colbert
Entrée Az
F-59000 Lille
Tel: (20) 51 44 14

GERMAN FEDERAL REPUBLIC

Hewlett-Packard GmbH
Vertriebszentrale Frankfurt
Bernersstrasse 117
Postfach 560 140
D-6000 Frankfurt 56
Tel: (0611) 50 04-1
Cable: HEWPAKSA Frankfurt
Telex: 41 32 49 tra
Hewlett-Packard GmbH
Technisches Büro Böblingen
Herrenbergerstrasse 110
D-7030 Böblingen, Württemberg
Tel: (07031) 66 72 87
Cable: HEPAK Böblingen
Telex: 72 65 739 bbn
Hewlett-Packard GmbH
Technisches Büro Düsseldorf
Vogelsanger Weg 38
D-4000 Düsseldorf
Tel: (0211) 63 80 31/5
Telex: 85 86 533 hdd d
Hewlett-Packard GmbH
Technisches Büro Hamburg
Wendlandstrasse 23
D-2000 Hamburg 1
Tel: (040) 24 13 93
Cable: HEWPAKSA Hamburg
Telex: 21 63 032 hph d

Hewlett-Packard GmbH
Technisches Büro Hannover
Mellendorfer Strasse 3
D-3000 Hannover-Kleefeld
Tel: (0511) 55 60 46
Telex: 092 3259
Hewlett-Packard GmbH
Technisches Büro Nuremberg
Hersbruckerstrasse 42
D-8500 Nuremberg
Tel: (0911) 57 10 66
Telex: 623 860

Hewlett-Packard GmbH
Technisches Büro München
Unterhanger Strasse 28
ISAR Center
D-8012 Ottobrunn
Tel: (089) 601 30 61/7
Telex: 52 49 85
Cable: HEWPAKSA München

(West Berlin)

Hewlett-Packard GmbH
Technisches Büro Berlin
Keith Strasse 2-4
D-1000 Berlin 30
Tel: (030) 24 90 86
Telex: 18 34 05 hpbh d

GREECE

Kostas Karayannis
18, Ermou Street
GR-Athens 126
Tel: 3230-303 Sales/SVC
3230-305 Adm. Order Proc.
D-8000 Frankfurt 56
Tel: (0611) 50 04-1
Cable: HEWPAKSA Frankfurt
Telex: 41 32 49 tra
Hewlett-Packard GmbH
Technisches Büro Böblingen
Herrenbergerstrasse 110
D-7030 Böblingen, Württemberg
Tel: (07031) 66 72 87
Cable: HEPAK Böblingen
Telex: 72 65 739 bbn
Hewlett-Packard GmbH
Technisches Büro Düsseldorf
Vogelsanger Weg 38
D-4000 Düsseldorf
Tel: (0211) 63 80 31/5
Telex: 85 86 533 hdd d
Hewlett-Packard GmbH
Technisches Büro Hamburg
Wendlandstrasse 23
D-2000 Hamburg 1
Tel: (040) 24 13 93
Cable: HEWPAKSA Hamburg
Telex: 21 63 032 hph d

Analytical Only
"INTECO" G. Papathanassiou & Co.
Marni 17
GR - Athens 103
Tel: 521 915
Cable: INTEKNIKA
Telex: 21 5329 INTE GR
Medical Only
Technomet Hellas Ltd.
52, Skoufa Street
GR - Athens 135
Tel: 626 972
Cable: ETALAK Athens
Telex: 21-4693 ETAL GR

IRELAND

Hewlett-Packard Ltd.
King Street Lane
Winnersh, Wokingham
GB-Berkshire RG11 5AR
Tel: Wokingham 784774
Telex: 847178/848179
Hewlett-Packard Ltd.
"The Graftons"
Stanford New Road
GB-Altrincham, Cheshire
Tel: (061) 928-9021
Telex: 668068

ITALY

Hewlett-Packard Italiana S.p.A.
Via Amerigo Vespucci 2
I-20124 Milan
Tel: (2) 6251 (10 lines)
Cable: HEWPAKIT Milan
Telex: 32046
Hewlett-Packard Italiana S.p.A.
Via Pietro Maroncelli 40
(ang. Via Vercelli)
I-35100 Padova
Tel: 66 40 62/66 31 88
Telex: 32046 via Milan

Medical Only

Hewlett-Packard Italiana S.p.A.
Via Medaglia d'Oro, 2
I-56100 Pisa
Tel: (050) 2 32 04
Telex: 32046 via Milan
Hewlett-Packard S.p.A.
Via G. Armetini 10
I-00143 Rome-Eur
Tel: (6) 5912544/5
Telex: 61514
Cable: HEWPAKIT Rome
Hewlett-Packard Italiana S.p.A.
Via San Quintino, 46
I-10121 Turin
Tel: 53 82 64/54 84 68
Telex: 32046 via Milan
Medical/Calculators Only
Hewlett-Packard Italiana S.p.A.
Via Principe Nicola 43 G/C
I-95126 Catania
Tel: (095) 370505

LUXEMBURG

Hewlett-Packard Benelux
S.A./N.V.
Avenue de Col-Vert, 1.
(Groenkraklaan)
B-1170 Brussels
Tel: (02) 672 22 40
Cable: PALOEN Brussels
Telex: 23 494

NETHERLANDS

Hewlett-Packard Benelux N.V.
Weerdestein 117
P.O. Box 7825
NL-Amsterdam, 1011
Tel: (020) 5411522
Cable: PALDBEN Amsterdam
Telex: 13 216 hepa nl
NORWAY
Hewlett-Packard Norge A/S
Nesveien 13
Box 149
N-1344 Haslum
Tel: (02) 53 83 60
Telex: 16621 hpnas n

POLAND

Analysical/Medical Only
Hewlett-Packard
Warsaw Technical Office
Szpitalna 1
00-120 Warsaw
Tel: 268031
Telex: 812453

PORTUGAL

Teletra-Empresa Técnica de
Equipamentos Eléctricos S.à r.l.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-Lisbon 1
Tel: (01) 98 18 21
Cable: TELETRISA Lisbon
Telex: 12598
Mundinter
Intercomércio Mundial de Comércio
San Avenida Antonio Augusto
de Aguiar 138
P.O. Box 2761
P - Lisbon
Tel: (01) 53 21 31/7
Cable: INTERCAMBIO Lisbon

SPAIN

Hewlett-Packard Española S.A.
Jeréz No. 3
E-Madrid 16
Tel: (1) 458 26 00 (10 lines)
Telex: 23515 hpe
Hewlett-Packard Española S.A.
Mianesado 21-23
E-Barcelona 17
Tel: (3) 203 6200 (5 lines)
Telex: 52603 hpe e
Hewlett-Packard Española S.A.
Av. Ramon y Cajal, 1
Edificio Sevilla I, planta 9ª
E-Seville
Tel: 64 44 54/58

Hewlett-Packard Española S.A.
Edificio Albia II 7ª B
E-Bilbao
Tel: 23 83 06/23 82 06
Tel: (020) 5411522
Cable: PALDBEN Amsterdam
Telex: 13 216 hepa nl
NORWAY
Hewlett-Packard Norge A/S
Nesveien 13
Box 149
N-1344 Haslum
Tel: (02) 53 83 60
Telex: 16621 hpnas n

SWEDEN

Hewlett-Packard Sverige AB
Enighetsvägen 1-3
Fack
S-161 20 Bromma 20
Tel: (08) 730 05 50
Cable: MEASUREMENTS
Stockholm
Telex: 10721
Hewlett-Packard Sverige AB
Hagagatan 9C
S-431 41 Mölndal
Tel: (031) 27 68 00/01
Telex: 74 Bromma

SWITZERLAND

Hiltel-Packard (Schweiz) AG
Zürcherstrasse 20
P.O. Box 64
CH-8952 Schlieren Zurich
Tel: (01) 98 18 21
Cable: HPAG CH
Telex: 53933 hpag
Hewlett-Packard (Schweiz) AG
9, chemin Louis-Pictet
CH-1214 Vernier-Geneva
Tel: (022) 41 49 50
Cable: HEWPAKSA Geneva
Telex: 27 333 hpsa ch

TURKEY

Telekom Engineering Bureau
Saglik Sok No. 15/1
Ayaspaşa-Beyoğlu
P.O. Box 437 Beyoğlu
TR-Istanbul
Tel: 49 40 40
Cable: TELEMATION Istanbul

UNITED KINGDOM

Hewlett-Packard Ltd.
King Street Lane
Winnersh, Wokingham
GB-Berkshire RG11 5AR
Tel: Wokingham 784774
Telex: 847178/848179
Hewlett-Packard Ltd.
"The Graftons"
Stanford New Road
GB-Altrincham, Cheshire
Tel: (061) 928-9021
Telex: 668068

Hewlett-Packard Ltd.
c/o Makro
South Service Wholesale Centre
Amber Way
Halesowen Industrial Estate
GB-Halesowen, Worcs
Tel: Birmingham 7860
Hewlett-Packard Ltd.
4th Floor
Wedge House
799, London Road
GB-Thornorton Heath CR4 6XL,
Surrey
Tel: (01) 684 0105
Telex: 946825

Hewlett-Packard Ltd.
c/o Makro
South Service Wholesale Centre
Wear Industrial Estate
Washington
GB-New Town, County Durham
Tel: Washington 464001 ext. 57/58
Hewlett-Packard Ltd. s registered
address for V.A.T. purposes
only:
70, Finsbury Pavement
London, EC2A1SX
Registered No. 690597

USSR

Hewlett-Packard USSR
c/o Commercial Office
American Embassy (Box M)
A-1091 Vienna, Austria
Tel: 221-79-71
Telex: 7825 hewpak SU
YUGOSLAVIA
Iskra-Standard/Hewlett-Packard
Topniska 58/3
61000 Ljubljana
Tel: 315-879/321-674
Telex: 31300

SOCIALIST COUNTRIES

PLEASE CONTACT:
Hewlett-Packard S.A.
7, rue du Bois-du-Lan
P.O. Box 349
CH-1217 Meyrin 1 Geneva
Switzerland
Tel: (022) 41 54 00
Cable: HEWPAKSA Geneva
Telex: 2 24 86

AFRICA, ASIA, AUSTRALIA

ANGOLA

Teletra
Empresa Técnica de
Equipamentos
Eléctricos, S.A. R.L.
R. Barbosa Rodrigues, 42-1º DT.
Caixa Postal, 6487-Luanda
Tel: 35515-6
Cable: TELETRISA Luanda

AUSTRALIA

Hewlett-Packard Australia
Pty. Ltd.
31-41 Joseph Street
Blackburn, Victoria 3130
Tel: 89-6351, 89-6306
Telex: 31-024
Cable: HEWPAK Melbourne
Hewlett-Packard Australia
Pty. Ltd.
31 Bridge Street
Pymble
New South Wales, 2073
Tel: 449 6566
Telex: 21561
Cable: HEWPAK Sydney
Hewlett-Packard Australia
Pty. Ltd.
97 Churchill Road
Prospect 5082
South Australia
Tel: 44 8151
Cable: HEWPAK Adelaide
Hewlett-Packard Australia
Pty. Ltd.
141 Stirling Highway
Claremont, W.A. 6010
Tel: 86-5455
Telex: 53859
Cable: HEWPAK
Hewlett-Packard Australia
Pty. Ltd.
121 Wollongong Street
Fyshwick, A.C.T. 2609
Tel: 95 3733
Hewlett-Packard Australia
Pty. Ltd.
5th Floor
Teachers Union Building
495-499 Boundary Street
Spring Hill, 4000 Queensland
Tel: 29-1544
Telex: AA-42133
CEYLON
United Electricals Ltd.
P.O. Box 681
60, Park St
Colombo 2
Tel: 26096
Cable: HOTPOINT Colombo
CYPRUS
Kyronics
19 Gregorios & Xenopoulos Rd.
P.O. Box 1152
CY-Nicosia
Tel: 45628/29
Cable: KYPRONICS PANDEHIS

HONG KONG

Schmidt & Co. (Hong Kong) Ltd.
P.O. Box 297
Connaught Centre
39th Floor
R. Barbosa Rodrigues, 42-1º DT.
Caixa Postal, 6487-Luanda
Tel: 35515-6
Cable: TELETRISA Luanda
Hewlett-Packard Australia
Pty. Ltd.
31-41 Joseph Street
Blackburn, Victoria 3130
Tel: 89-6351, 89-6306
Telex: 31-024
Cable: HEWPAK Melbourne
Hewlett-Packard Australia
Pty. Ltd.
31 Bridge Street
Pymble
New South Wales, 2073
Tel: 449 6566
Telex: 21561
Cable: HEWPAK Sydney
Hewlett-Packard Australia
Pty. Ltd.
97 Churchill Road
Prospect 5082
South Australia
Tel: 44 8151
Cable: HEWPAK Adelaide
Hewlett-Packard Australia
Pty. Ltd.
141 Stirling Highway
Claremont, W.A. 6010
Tel: 86-5455
Telex: 53859
Cable: HEWPAK
Hewlett-Packard Australia
Pty. Ltd.
121 Wollongong Street
Fyshwick, A.C.T. 2609
Tel: 95 3733
Hewlett-Packard Australia
Pty. Ltd.
5th Floor
Teachers Union Building
495-499 Boundary Street
Spring Hill, 4000 Queensland
Tel: 29-1544
Telex: AA-42133
CEYLON
United Electricals Ltd.
P.O. Box 681
60, Park St
Colombo 2
Tel: 26096
Cable: HOTPOINT Colombo
CYPRUS
Kyronics
19 Gregorios & Xenopoulos Rd.
P.O. Box 1152
CY-Nicosia
Tel: 45628/29
Cable: KYPRONICS PANDEHIS

Blue Star Ltd.
1-1-117/1
Sarajini Devi Road
Secunderabad 500 003
Cable: BLUEFROST
Tel: 458
Blue Star Ltd.
23/24 Second Line Beach
Madras 600 001
Tel: 379
Telex: 23954
Blue Star Ltd.
Nathraj Mansions
2nd Floor, Bishopsgate
Jamshedpur 831 001
Tel: 38 04
Cable: BLUESTAR
Telex: 240
INDONESIA
BERCA Indonesia P.T.
P.O. Box 496
1st Floor J.L. Cikini Raya 61
Jakarta
Tel: 56038, 40369 49886
Telex: 2895 Jakarta
IRAN
Multi Corp International Ltd.
Avenue Soraya 130
P.O. Box 1212
IR-Teheran
Tel: 83 10 35-39
Cable: MULTICORP Tehran
Telex: 2893 mci ir
ISRAEL
Electronics & Engineering
Div. of Motorola Israel Ltd.
17 Aminadav Street
Tel: 23-0131
Cable: BASTEL Tel-Aviv
Telex: 33569
JAPAN
Yokogawa-Hewlett-Packard Ltd.
Ohashi Building
1-59-1 Yoyogi
Shibuya-ku, Tokyo
Tel: 03-370-2281/92
Telex: 232-2024YHP
Cable: YHPMARKET TOK 23-724
Yokogawa-Hewlett-Packard Ltd.
Nissei Ibaragi Bldg.
2-2-8 Kasuga
Ibaragi-Shi
Osaka
Tel: (0726) 23-1641
Telex: 5332-385 YHP OSAKA
Yokogawa-Hewlett-Packard Ltd.
Nakano Building
No. 24 Kamissazima-cho
Nakamura-ku, Nagoya City
Tel: (052) 571-5171

Yokogawa-Hewlett-Packard Ltd.
Tanigawa Building
2-24-1 Tsuruya-cho
Kanagawa-ku
Yokohama, 221
Tel: 045-312-1252
Telex: 382-3204 YHP YOK
Yokogawa-Hewlett-Packard Ltd.
Mito Mitsui Building
1-4-73 San-no-maru
Mito, 310
Tel: 0292-25-7470
Yokogawa-Hewlett-Packard Ltd.
Inoue Building
1348-3, Asahi-cho, 1-chome
Atsugi, 243
Tel: 0462-24-0452

KENYA

Technical Engineering Services
P.O. Box 18311
Nairobi, Kenya
Cable: PROTON

KOREA

American Trading Company
Korea
I.P.O. Box 1103
Dae Kyung Bldg., 8th Floor
107 Sejong-Ro
Chongro-Ku, Seoul
Tel: (4 lines) 73-8924-7
Cable: AMTRACO Seoul

KUWAIT

Al-Khaldiya Trading &
Contracting Co.
Al Soor Street
Michaan Bldg. No. 4
Kuwait
Tel: 42 99 10
Cable: VISCOUNT

LEBANON

Samir & Company, Ltd.
Osmann Chambers
Adullah Haron Road
Karachi 3
Tel: 511027, 512927
Cable: COOPERATOR Karachi
Mushko & Company, Ltd.
388, Satellite Town
Rawalpindi
Tel: 41524
Cable: FEMUS Rawalpindi

MALAYSIA

MECOMB Malaysia Ltd
2 Lorong 13/6A
Section 13
Petaling Jaya, Selangor
Cable: MECOMB Kuala Lumpur
MOZAMBIQUE
A.N. Gonçalves, Lda
162, 1º Apt., 14 Av. D. Luis
Caixa Postal 107
Lourenço Marques
Tel: 27091, 27114
Telex: 6-203 Negon Mo
Cable: NEGON

NEW ZEALAND

Hewlett-Packard (N.Z.) Ltd
94-96 Dixon Street
P.O. Box 9443
Courtenay Place,
Wellington
Tel: 58-559
Telex: 3698
Cable: HEWPAK Wellington
Hewlett-Packard (N.Z.) Ltd.
Pukaranga Professional Centre
267 Pukaranga Highway
Box 51092
Pukaranga
Tel: 568-651
Cable: HEWPAK, Auckland
Analytical/Medical Only
Dental & Medical Supply Co. Ltd.
Scientific Division
79 Carlton Gore Road
Newmarket
P.O. Box 1234
Auckland
Tel: 75-289
Cable: DENTAL Auckland

NIGERIA

The Electronics
Instrumentation Ltd.
N6B/770 Oyo Road
Oluseun House
P.M.B. 5402
Ibadan
Tel: 22325
Cable: THETEL Ibadan
The Electronics Instrumenta-
tions Ltd. (TEL)
16th Floor Cocoa House
P.M.B. 5402
Ibadan
Tel: 22325
Cable: THETEL Ibadan

PAKISTAN

Mushko & Company, Ltd.
Osmann Chambers
Adullah Haron Road
Karachi 3
Tel: 511027, 512927
Cable: COOPERATOR Karachi
Mushko & Company, Ltd.
388, Satellite Town
Rawalpindi
Tel: 41524
Cable: FEMUS Rawalpindi
PHILIPPINES
Electromex, Inc.
Development Corp. Bldg.
Ayala Avenue, Makati, Rizal
C.C.P.O. Box 1028
Makati, Rizal
Tel: 86-18-87, 87-76-77,
Cable: ELEMEX Manila

SINGAPORE

Mechanical & Combustion
Engineering Company Pte.,
Ltd.
10/12, Jalan Kilang
Red Hill Industrial Estate
Singapore, 3
Tel: 647151 (7 lines)
Cable: MECOMB Singapore
Hewlett-Packard Singapore
(Pte.) Ltd.
Bik 2, 6th FLOOR, Jalan
Bukit Merah
Redhill Industrial Estate
Alexandra P.O. Box 87,
Singapore 3
Tel: 633022
Telex: HPSG RS 21486
Cable: HEWPAK, Singapore

SOUTH AFRICA

Hewlett-Packard South Africa
(Pty.) Ltd.
Hewlett-Packard House
Daphne Street, Wendywood
Sandton, Transvaal 2001
Tel: 802-1040
Cable: SA43-4782JH
Cable: HEWPAK
Hewlett-Packard South Africa
(Pty.) Ltd.
Breecastle House
Bree Street
Cape Town
Tel: 2-6941/2/3
Cable: HEWPAK Cape Town
Telex: 0006 CT
Hewlett-Packard South Africa
(Pty.) Ltd.
641 Ridge Road, Durban
P.O. Box 37099
Overport, Durban, 4067
Tel: 88-6102
Telex: 6-7954

TAIWAN

Hewlett-Packard Taiwan
39 Chung Shiao West Road
Sec. 1 Overseas Insurance
Corp. Bldg. 7th Floor
Taipei
Tel: 383160, 1, 2
Cable: TP824 HEWPAK
Telex: 41524
Cable: FEMUS Rawalpindi
Hewlett-Packard Taiwan
38, Po-Ai Lane, San Min Chu,
Kaohsiung
Tel: 297319
THAILAND
UNIMESA Co., Ltd.
Elsom Research Building
Bangkok Sukumvit Ave.
Bangkok
Tel: 83-2387, 930338
Cable: UNIMESA Bangkok

UGANDA

Uganda Tele-Electric Co., Ltd.
P.O. Box 4449
Kampala
Tel: 57279
Cable: COMCO Kampala
VIETNAM
Peninsular Trading Inc.
P.O. Box H-3
216 Hien-Vuong
Saigon
Tel: 20-805, 93398
Cable: PENIRA, SAIGON 242
ZAMBIA
R.J. Tilbury (Zambia) Ltd.
P.O. Box 2792
Lusaka
Zambia, Central Africa
Tel: 73793
Cable: ARJAYTEE, Lusaka

MEDITERRANEAN AND MIDDLE EAST COUNTRIES

NOT SHOWN PLEASE CONTACT:
Hewlett-Packard S.A.
Mediterranean and Middle
East Operations
35, Kolokotroni Street
Platia Kallirion
GR-Kifissia-Athens
Tel: 21-6588
Cable: HEWPAKSA Athens
OTHER AREAS NOT LISTED, CONTACT:
Hewlett-Packard
Export Trade Company
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 493-1501
TWX: 910-373-1267
Cable: HEWPAK Palo Alto
Telex: 034-8300, 034-8493



MANUAL PART NO. 12597-90025
MICROFICHE PART NO. 12597-90029

PRINTED IN U.S.A.